Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ciays CIFP60TS-17-US

Ciays Smokeless Firepit 17-Inch Stainless Steel Instruction Manual

Model: CIFP60TS-17-US

1. Introduction

Thank you for choosing the Ciays 17-inch Smokeless Firepit. This manual provides essential information for the safe and efficient use of your new fire pit. Please read all instructions carefully before assembly and operation.

2. Important Safety Information

Always maintain a safe distance from the fire pit. Use only dry, seasoned wood. Keep the fire pit away from flammable materials. Ensure proper ventilation when in use. Allow the fire pit to cool completely before moving or storing. Always supervise children and pets when the fire pit is in use.

WARNING: For outdoor use only. Do not use indoors or in enclosed spaces. Keep away from structures, combustible materials, and overhanging trees. Do not use gasoline, kerosene, diesel fuel, lighter fluid, or alcohol to start or rekindle a fire.

3. Package Contents

Verify that all components are present before assembly:

- Firepit Base with Foldable Legs
- Upper Chamber
- Fire Bowl (Ash Pan)
- Flame Ring
- 304 Stainless Steel Grill Rack
- Wood & Steel Fire Poker (25.3 inches)
- Multipurpose Carrying Bag/Water-Resistant Cover



Figure 3.1: Included accessories: 304 Stainless Steel Grill Rack, Wood & Steel Fire Poker, and Multipurpose Carrying Bag.

4. Setup Instructions

The Ciays Smokeless Firepit features an easy-to-assemble, detachable stacked structure.

1. **Unfold the Base:** Take the Firepit Base. Unfold the integrated legs to ensure stability.
2. **Insert Fire Bowl:** Place the Fire Bowl (ash pan) into the Firepit Base. Ensure it sits securely at the bottom.
3. **Place Upper Chamber:** Position the Upper Chamber on top of the Firepit Base. Align the handles and snap them into place to secure the two sections.
4. **Add Flame Ring:** Place the Flame Ring on the top rim of the Upper Chamber. This directs the flames for optimal smokeless performance.



Figure 4.1: The firepit's detachable stacked structure for easy assembly.

Setup Video Guide

Your browser does not support the video tag.

Video 4.1: A quick guide demonstrating the assembly of the Ciays Smokeless Firepit.

5. Operating Instructions

5.1 Starting a Fire

1. **Prepare Fuel:** Use dry, seasoned hardwood for best results. Avoid using softwoods or treated wood, as they can produce more smoke and creosote.
2. **Arrange Wood:** Place kindling (small sticks, paper, or fire starters) in the Fire Bowl. Stack larger pieces of wood in a crisscross pattern on top of the kindling, ensuring good airflow.
3. **Ignite:** Carefully ignite the kindling. The patented Waterfallflame Technology™ with triple-layer combustion and 360° Airflow Heat will maximize heat output and minimize smoke once the fire is established.



Figure 5.1: The Ciays Smokeless Firepit in operation, showcasing its efficient combustion.

5.2 Using the Grill Rack

The included 304 stainless steel grill rack is food-grade quality, suitable for outdoor cooking.

1. **Place Grill Rack:** Once the fire has established a good bed of coals, carefully place the grill rack over the top of the fire pit.
2. **Cook:** Place food directly on the grill rack. Use the provided fire poker to adjust logs and manage the heat as needed.
3. **Remove:** After cooking, use heat-resistant gloves or the fire poker to carefully remove the hot grill rack.



Figure 5.2: The firepit with the stainless steel grill rack in place, ready for cooking.

5.3 Managing the Fire

Use the long 25.3-inch wood and steel fire poker to safely stoke logs and adjust the fire. This tool helps maintain optimal airflow and combustion.



Figure 5.3: The included 25.3-inch fire poker for safe fire management.

6. Maintenance & Cleaning

Regular cleaning ensures longevity and optimal performance.

1. **Cool Down:** Always allow the fire pit to cool completely before attempting any cleaning or maintenance.
2. **Remove Ash:** The removable fire bowl simplifies ash cleanup. Once cooled, lift the fire bowl and dispose of the ashes responsibly.
3. **Clean Components:** Wipe down the stainless steel components with a damp cloth. For stubborn residue, a mild soap and water solution can be used. Avoid abrasive cleaners that may scratch the surface.
4. **Grill Rack Care:** The 304 stainless steel grill rack can be cleaned with a grill brush and warm soapy water.

7. Storage

The portable design with foldable legs and a multipurpose bag makes storage convenient.

1. **Disassemble:** Once cooled and cleaned, disassemble the fire pit by reversing the setup steps. The components nest together for

compact storage.

2. **Pack in Bag:** Place all components into the provided multipurpose carrying bag. The bag can also be used as a water-resistant cover when the fire pit is assembled and not in use.
3. **Store:** Store the packed fire pit in a dry, protected area away from extreme temperatures.

Storage Video Guide

Your browser does not support the video tag.

Video 7.1: A demonstration of how to disassemble and store the Ciays Smokeless Firepit in its carrying bag.

8. Troubleshooting

If you encounter issues with your Ciays Smokeless Firepit, consider the following:

- **Excessive Smoke:** Ensure you are using dry, seasoned hardwood. Wet or green wood will produce more smoke. Also, check that the airflow vents are not obstructed.
- **Difficulty Starting Fire:** Use adequate kindling and ensure proper stacking of wood for good airflow. A fire starter can assist in ignition.
- **Low Heat Output:** Verify that the fire pit has sufficient airflow. The triple-layer combustion relies on proper air circulation. Add more wood if necessary.

For further assistance, please contact Ciays customer support.

9. Specifications

Brand	Ciays
Model Number	CIFP60TS-17-US
Material	Stainless Steel
Product Dimensions	17"D x 17"W x 16.6"H
Item Weight	9.91 Kilograms (21.8 pounds)
Fuel Type	Wood
Color	Stainless Steel
UPC	810174341935

10. Warranty & Support

For warranty information or customer support, please refer to the product packaging or visit the official Ciays website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DKXNMY43

More documents and user manuals: **https://manuals.plus/**