

SOFTSEA x76

SOFTSEA Twin Over Twin Metal Bunk Bed with Storage (Model x76) Instruction Manual

Your guide to safe assembly, operation, and maintenance.

1. IMPORTANT SAFETY INFORMATION

Read all instructions carefully before assembling and using this bunk bed. Keep this manual for future reference.

- **Top Bunk Age Limit:** The top bunk is not suitable for children under six years of age.
- **Guardrails:** Always use the guardrails on the top bunk. Ensure they are properly installed and secured.
- **Mattress Thickness:** The maximum mattress thickness for the upper bunk should not exceed 6 inches. For the lower bunk, the recommended mattress thickness is 6-8 inches. Ensure the mattress surface is at least 5 inches below the upper edge of the guardrails.
- **Weight Capacity:** The upper bunk has a maximum weight capacity of 300 lbs. The lower bunk has a maximum weight capacity of 400 lbs. Do not exceed these limits.
- **No Jumping:** Do not allow jumping on the bed.
- **Ladder Safety:** Always use the ladder for entering and exiting the top bunk. Ensure the ladder is securely attached.
- **Assembly:** Ensure all connections are tight and secure before use. Periodically check and tighten all fasteners.
- **Ventilation:** Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.

2. PRODUCT OVERVIEW

The SOFTSEA Twin Over Twin Metal Bunk Bed with Storage (Model x76) is designed for space-saving and functionality. It features a sturdy metal frame, integrated bookcase headboards, and can be converted into two separate twin beds.



Image 2.1: Fully assembled SOFTSEA Twin Over Twin Metal Bunk Bed with integrated bookcase headboards.



Image 2.2: The bunk bed can be separated into two individual twin beds, each with its own bookcase headboard.

3. SETUP AND ASSEMBLY

This bunk bed requires full assembly. It is recommended that two people assemble the unit. All necessary tools are included.

3.1. Before You Begin

- Verify all parts are present by checking against the included parts list.
- Clear a spacious area for assembly.
- Keep children and pets away from the assembly area.
- The product will arrive in 2 separate packages, which may arrive on different days. Ensure both packages have been received before starting assembly.

3.2. Assembly Steps

Follow the detailed instructions and diagrams provided in the separate assembly manual included with your product. Reserved holes simplify the process.

1. Unpack all components and lay them out on a soft, clean surface to prevent scratches.
2. Assemble the lower bed frame first, ensuring all connections are finger-tight.
3. Attach the bookcase headboards to the lower bed frame.
4. Assemble the upper bed frame.
5. Carefully lift and secure the upper bed frame onto the lower bed frame, ensuring all connecting points are aligned and secured.
6. Install the ladder and guardrails, ensuring they are firmly attached.
7. Once fully assembled, tighten all fasteners with the provided tools. Do not overtighten.



Image 3.1: Illustration of the bunk bed frame structure, useful during assembly.



Image 3.2: Dimensional drawing of the bunk bed, showing overall length, width, height, and internal measurements.

4. OPERATING INSTRUCTIONS

4.1. Using the Bunk Bed Configuration

- Ensure mattresses are correctly sized and placed within the bed frames.
- Always use the built-in ladder to access the top bunk.
- Utilize the integrated bookcase headboards for storing books, small toys, or personal items.

4.2. Converting to Two Separate Twin Beds

The bunk bed can be converted into two independent twin beds. This process requires two adults.

1. Remove mattresses from both bunks.

2. Carefully detach the upper bunk from the lower bunk by unscrewing the connecting fasteners.
3. Remove the ladder and guardrails from the upper bunk.
4. Position the two separate bed frames in your desired location.
5. Ensure all components are stable and secure in their new configuration.



Image 4.1: Detail of the integrated bookcase headboard, providing convenient storage.

5. MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your bunk bed.

- **Cleaning:** Wipe down metal surfaces with a soft, damp cloth. For the MDF bookcase sections, use a dry or slightly

damp cloth. Avoid harsh chemicals or abrasive cleaners.

- **Fasteners:** Periodically check all bolts, screws, and connections to ensure they remain tight. Retighten as necessary to maintain stability and safety.
- **Inspection:** Regularly inspect the bed for any signs of wear, damage, or loose parts. Address any issues promptly.
- **Environment:** Avoid placing the bed in direct sunlight or near heat sources, which can affect the MDF components.

6. TROUBLESHOOTING

If you encounter any issues with your bunk bed, refer to the following common solutions:

6.1. Bed Wobbles or Squeaks

- **Solution:** Check all bolts and screws. Tighten any loose fasteners. Ensure the bed is placed on a level surface.

6.2. Difficulty Assembling

- **Solution:** Review the assembly manual carefully. Ensure all parts are correctly oriented. Do not force parts together. If a part seems incorrect, double-check the diagram. Confirm all packages have arrived.

6.3. Missing or Damaged Parts

- **Solution:** Contact SOFTSEA customer support immediately with your purchase details and a description of the missing or damaged part.

7. SPECIFICATIONS

Feature	Detail
Model Number	x76
Type	Twin Over Twin Bunk Bed
Material	Metal + MDF
Color	Black
Overall Dimensions (Bunk Bed)	88.8"L x 42.6"W x 63"H
Upper Bed Inner Space	75" x 39"
Lower Bed Inner Space	75" x 39"
Upper Bed Weight Capacity	300 LBS
Lower Bed Weight Capacity	400 LBS
Recommended Upper Mattress Thickness	4-6 inches
Recommended Lower Mattress Thickness	6-8 inches

Overall Product Weight	167 LBS
Assembly Required	Yes (Full Assembly)
Number of Packages	2
Country of Origin	Vietnam

8. WARRANTY INFORMATION

This SOFTSEA bunk bed comes with a one-year warranty against manufacturing defects. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover damage resulting from improper assembly, misuse, abuse, accidents, modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

9. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact SOFTSEA customer support.

- **Online Support:** Visit the official SOFTSEA website for FAQs and support resources.
- **Email Support:** Refer to your purchase documentation for specific contact email.
- **Phone Support:** Refer to your purchase documentation for specific contact number.

Please have your model number (x76) and purchase date ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DKXT5TGZ>

More documents and user manuals: <https://manuals.plus/>