



[Manuals.plus](#) /

› [WMSNUH](#) /

› WMSNUH T-4530U Toner Cartridge Instruction Manual for Toshiba E-Studio Printers

WMSNUH T-4530U

WMSNUH T-4530U Toner Cartridge Instruction Manual

Model: T-4530U

INTRODUCTION

This manual provides essential instructions for the proper installation, operation, and maintenance of your WMSNUH T-4530U toner cartridge. Following these guidelines will help ensure optimal print quality and extend the life of your cartridge and printer. Please read this manual thoroughly before use.

COMPATIBLE PRINTER MODELS

The WMSNUH T-4530U toner cartridge is compatible with the following Toshiba E-Studio printer models:

- Toshiba E-Studio 205L
- Toshiba E-Studio 205SE
- Toshiba E-Studio 255
- Toshiba E-Studio 305
- Toshiba E-Studio 305SE
- Toshiba E-Studio 355
- Toshiba E-Studio 355sd
- Toshiba E-Studio 455
- Toshiba E-Studio 455sd

Compatible Printers List

**e-Studio 205L
205SE 255
305 305SE 355
355sd 455 455sd**



This image displays the list of Toshiba E-Studio printer models that are compatible with the T-4530U toner cartridge.

PRODUCT FEATURES

- **High Page Yield:** Each T-4530U black toner cartridge is designed to produce approximately 10,000 pages at 5% coverage on A4 paper, ensuring long-lasting performance for high-volume printing needs.

High Yield Printout

At 5% coverage of A4 Paper



10,000 Pages



This image illustrates the high page yield of 10,000 pages per black cartridge.

- **Reliable Print Quality:** Experience crisp, clear texts and sharp images with every print. The toner formulation is engineered to prevent fading, powder leakage, and streaking, ensuring consistent and professional results.
- **Upgraded Intelligent Chip:** Equipped with the latest intelligent chip, the cartridge ensures stable compatibility and accurate toner level monitoring with your Toshiba E-Studio printer.

Latest Intelligent Chips



With Upgraded Chip



Excellent Performance



Higher Page Yield



This image highlights the intelligent chip integrated into the toner cartridge, contributing to its performance.

- **Premium Performance:** The toner delivers pure color and high definition, resulting in superior printing outcomes with vibrant colors and clear details.

Brilliant Printout



This image showcases the brilliant print quality achievable with the toner cartridge.

- **Robust Product Design:** The cartridge is constructed with high-quality imported parts and undergoes strict testing to ensure durability and consistent print quality throughout its lifespan.

Product Display




With Upgraded Chip



Excellent Performance



Higher Page Yield



This image provides a detailed view of the toner cartridge's components and design.

INSTALLATION GUIDE

Follow these steps to install the WMSNUH T-4530U toner cartridge into your Toshiba E-Studio printer:

- 1. Prepare the Printer:** Ensure your printer is turned on. Open the front cover or the toner compartment access door of your Toshiba E-Studio printer. Refer to your printer's specific manual for exact access instructions.
- 2. Remove the Old Cartridge:** Carefully grasp the handle of the used toner cartridge and pull it straight out of the printer. Place the old cartridge in a protective bag for recycling.
- 3. Unpack the New Cartridge:** Remove the new WMSNUH T-4530U toner cartridge from its packaging. Avoid touching the drum or electrical contacts.
- 4. Shake the Cartridge:** Gently rock the new toner cartridge horizontally 5-6 times to distribute the toner evenly inside.
- 5. Remove Protective Seals:** Carefully pull off any protective tapes, seals, or orange clips from the cartridge. Do not touch the green drum surface.
- 6. Insert the New Cartridge:** Align the new cartridge with the guides inside the printer and slide it firmly into the slot until it clicks into place. Ensure it is seated securely.

7. **Close the Printer Cover:** Close the front cover or toner compartment access door. The printer should automatically detect the new cartridge and begin initialization.

8. **Print a Test Page:** Once the printer is ready, print a test page to confirm proper installation and print quality.

OPERATING INSTRUCTIONS

After successful installation, your WMSNUH T-4530U toner cartridge is ready for use. Simply send print jobs from your computer or device as you normally would. The intelligent chip will monitor toner levels and communicate with your printer.

For optimal results, ensure your printer drivers are up to date. You can typically find the latest drivers on the Toshiba support website for your specific printer model.

MAINTENANCE TIPS

- **Storage:** Store unused toner cartridges in their original sealed packaging in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Always handle toner cartridges carefully. Avoid dropping them or exposing them to excessive vibration.
- **Cleaning:** If you notice smudges or streaks, consult your printer's manual for instructions on cleaning the printer's internal components, such as the drum unit or fuser. Do not attempt to clean the toner cartridge itself.
- **Recycling:** When a cartridge is empty, recycle it responsibly according to local regulations. Many office supply stores offer recycling programs for used toner cartridges.

TROUBLESHOOTING

If you encounter issues with your WMSNUH T-4530U toner cartridge, consider the following common solutions:

Problem	Possible Cause	Solution
Poor Print Quality (streaks, faded prints)	Uneven toner distribution, low toner, dirty printer components.	Gently rock the cartridge to redistribute toner. Check toner levels. Perform a printer cleaning cycle as per your printer manual.
Cartridge Not Recognized	Improper installation, dirty electrical contacts, chip issue.	Remove and reinsert the cartridge firmly. Turn the printer off and on. Gently clean the cartridge's electrical contacts with a lint-free cloth.
Paper Jams	Incorrect paper loading, worn rollers, foreign objects.	Ensure paper is loaded correctly. Clear any jammed paper carefully. Refer to your printer manual for specific jam clearing instructions.
Error Messages	Various printer issues.	Note the exact error message and consult your printer's manual or the Toshiba support website for specific troubleshooting steps.

SPECIFICATIONS

Specification	Detail
Model Number	T-4530U (also compatible with T-4530, T4530, T4530U)
Color	Black
Page Yield	Up to 10,000 pages (at 5% coverage on A4 paper)
Brand	WMSNUH
Compatible Printer Series	Toshiba E-Studio 205L, 205SE, 255, 305, 305SE, 355, 355sd, 455, 455sd

CONTACT AND SUPPORT

For further assistance or inquiries regarding your WMSNUH T-4530U toner cartridge, please contact our customer support. Refer to the retailer's website or your purchase documentation for specific contact information.

© 2024 WMSNUH. All rights reserved.