

Ninja FS301EU

Ninja SLUSHi FS301EU Frozen Drink Machine User Manual

Model: FS301EU | Brand: Ninja

1. INTRODUCTION

The Ninja SLUSHi FS301EU is designed to create a variety of frozen beverages, including slushies, cocktails, frappes, milkshakes, and juices, without requiring pre-chilled ingredients or ice. Its advanced WhisperChill Technology ensures consistent results and quiet operation.

Key Features:

- **Effortless Frozen Drinks:** Prepare your favorite frozen beverages at home with a single touch.
- **Five Preset Settings:** Choose from Slush, Frozen Cocktail, Frappe, Milkshake, and Frozen Juice for optimal consistency.
- **1.9 L Capacity:** The 2.5 L reservoir (1.9 L liquid capacity) allows for serving multiple portions.
- **Rapid Chill Technology:** Transforms liquid into a frozen drink in approximately 30 minutes and maintains freshness for up to 12 hours without dilution.
- **WhisperChill Compressor:** Maintains ideal temperature and consistency quietly.

2. SETUP AND ASSEMBLY

Before first use, ensure all parts are clean and the unit is placed on a flat, stable surface.

1. **Install Condensation Collector:** Slide the condensation collector into the grooves beneath the evaporator.
2. **Insert Auger:** Place the auger onto the evaporator shaft and rotate until it locks into place.
3. **Position Reservoir:** Lift the handle on the main unit, then slide the reservoir over the auger and evaporator.

Push the handle back to securely lock the reservoir.

4. **Attach Drip Tray:** Place the top part of the drip tray into the plate and insert it into the front of the main unit.



Image: All components of the Ninja SLUSHi machine, including the main unit, reservoir, auger, condensation collector, and drip tray, laid out before assembly.

Your browser does not support the video tag.

Video: A step-by-step guide demonstrating the assembly process of the Ninja SLUSHi machine, from installing the condensation collector to securing the reservoir and drip tray.

3. OPERATING INSTRUCTIONS

The Ninja SLUSHi machine simplifies the creation of frozen beverages with its intuitive controls and Rapid Chill Technology.

1. **Prepare Ingredients:** Ensure your liquid ingredients contain sugar for optimal freezing results.
2. **Fill Reservoir:** Pour your liquid mixture into the reservoir. Do not exceed the 'MAX FILL' line.
3. **Select Program:** Choose one of the five preset programs (Slush, Frozen Cocktail, Frappe, Milkshake, Frozen Juice) using the control panel.
4. **Start Process:** Press the power button to begin the freezing cycle. The machine will automatically churn and freeze the liquid.
5. **Dispense Drink:** Once the desired consistency is reached (indicated by the machine or after the program completes), pull the dispensing lever to serve your frozen drink.



RECIPIENTE FACILE DA RIEMPIRE

Facile da riempire, aprire e rimuovere per la pulizia.

Image: A hand carefully pouring a red liquid into the transparent reservoir of the Ninja SLUSHi machine, demonstrating the filling process.



DALLA MATTINA ALLA SERA
Inizia la tua giornata in dolcezza o concediti una bevanda serale.

Image: A detailed view of the control panel on the Ninja SLUSHi machine, showing the power button, five preset drink options (Slush, Frozen Cocktail, Frappe, Milkshake, Frozen Juice), and a rinse button.

Your browser does not support the video tag.

Video: An overview of the Ninja SLUSHi machine in operation, showcasing the process of adding ingredients, selecting a program, and dispensing various frozen beverages.

4. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your Ninja SLUSHi machine. All removable parts are dishwasher safe, except the main unit and evaporator.

1. **Rinse Cycle:** After dispensing the last drink, press the 'RINSE' button on the control panel. Add water to the reservoir to cover the evaporator. Let the rinse cycle run for 1-2 minutes.
2. **Empty Reservoir:** Slowly dispense the water from the reservoir into a bowl or sink.

- 3. **Disassemble:** Turn off the unit. Unlock the handle by pulling it forward, then gently separate the reservoir from the main unit. Remove the auger and condensation collector.
- 4. **Clean Components:** Wash the reservoir, auger, and condensation collector with warm, soapy water or place them in the dishwasher.
- 5. **Clean Main Unit:** Wipe the main unit and evaporator with a damp cloth. Do not immerse the main unit in water.
- 6. **Dry and Reassemble:** Ensure all components are completely dry before reassembling or storing the unit.



Image: A hand placing a removable part of the Ninja SLUSHi machine into a dishwasher, illustrating the ease of cleaning for most components.

Your browser does not support the video tag.

Video: A demonstration of the cleaning process for the Ninja SLUSHi machine, including using the rinse function, disassembling parts, and cleaning individual components.

5. TROUBLESHOOTING

If you encounter issues with your Ninja SLUSHi machine, refer to the following common solutions:

- **Machine Not Turning On:** Ensure the power cord is securely plugged into a working outlet. Check for any tripped circuit breakers.
- **Drink Not Freezing:** Verify that the liquid contains sufficient sugar, as sugar is essential for proper freezing. Ensure the reservoir is correctly seated and the handle is locked.
- **Inconsistent Consistency:** Make sure the auger is properly installed and rotates freely. Check that the correct preset program for your desired drink type has been selected.
- **Leaking:** Confirm that the reservoir is securely locked into place and the drip tray is correctly installed.

For further assistance, please contact Ninja customer support.

6. SPECIFICATIONS

Feature	Detail
Brand	Ninja

Feature	Detail
Model	FS301EU
Color	Blue and Grey
Capacity	1.9 Liters (liquid)
Material	Metal
Special Features	Five preset settings, Rapid Chill Technology (freezes in 30-60 minutes*, maintains for up to 12 hours**), WhisperChill compressor. *Preparation time varies by ingredients, volume, and initial temperature. Sugar is required. **For recipes without dairy ingredients.
Item Weight	11 Kilograms

Image: A diagram illustrating the dimensions of the Ninja SLUSHi machine, including height, width, and depth, along with its weight and liquid capacity.

2,5 L^{*}

RECIPIENTE

OLTRE 7 PORZIONI
ALLA VOLTA**

L: 16,6 CM

A: 42,9 CM

L: 41,4 CM

PESO DELL'UNITÀ: 11 KG

CICLO DI RISCIAQUO

FACILE DA PULIRE GRAZIE
ALLE PARTI LAVABILI
IN LAVASTOVIGLIE

Capacità massima: 1,9 L

1,9 L

CAPACITÀ MASSIMA



OPPURE



BOTTIGLIE DA 2 L

5 LATTINE

ADATTA ANCHE
A BICCHIERI DA
COCKTAIL DA 19 CM



7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Ninja website. Keep your purchase receipt as proof of purchase.

© 2023 Ninja. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question