Igloo 27775

Igloo Kool Tunes Retro Bluetooth Boombox Cooler User Manual

Model: 27775

Introduction

The Igloo Kool Tunes Retro Bluetooth Boombox Cooler combines the classic Igloo Playmate cooler design with modern Bluetooth audio technology. This 14-quart cooler features integrated speakers, allowing you to keep your beverages chilled while enjoying your favorite music. It is designed for portability and durability, making it ideal for outdoor activities.



Figure 1: Front view of the Igloo Kool Tunes Retro Bluetooth Boombox Cooler.

Product Features

- **Integrated Speakers:** Two low-profile 5-watt speakers with passive radiators deliver a premium sound experience with punchy bass and a dynamic frequency response range of 80Hz-20kHz.
- **Bluetooth 5.0:** Advanced wireless pairing technology for stable and efficient audio streaming.
- **KoolSync Technology:** Allows syncing the Bluetooth speakers of two KoolTunes coolers for an enhanced surround sound experience. Both units must feature KoolSync technology.
- **Durable Design:** IP56-rated water- and dust-resistant construction ensures durability in various environments.
- **Extended Playtime:** Up to 10 hours of audio playtime on a single charge.
- **Cooler Capacity:** 14-quart capacity, designed to hold beverages and ice.

Setup

1. Initial Charging

Before first use, fully charge the Kool Tunes cooler. Locate the charging port, typically on the back or side panel near the control buttons. Use the provided charging cable to connect the cooler to a power source. The charging indicator light will show the charging status.



Figure 2: Close-up of the KoolSync enabled panel, showing the charging port and control buttons.

2. Bluetooth Pairing

1. Ensure the Kool Tunes cooler is powered on.
2. Activate Bluetooth on your mobile device (smartphone, tablet, etc.).

3. On your device, search for available Bluetooth devices. The cooler should appear as "Igloo Kool Tunes" or similar.
4. Select the cooler from the list to pair. A confirmation sound or light indicator on the cooler will confirm successful pairing.

3. KoolSync Pairing (for two Kool Tunes units)

To achieve a surround sound experience, you can pair two Kool Tunes coolers that both feature KoolSync technology. This feature is not backward compatible with older models.

1. Ensure both Kool Tunes coolers are powered on and not currently paired to any other device.
2. On one cooler, press and hold the KoolSync button (refer to the control panel diagram in the operating section). The indicator light will flash, indicating it's searching for another KoolSync unit.
3. Repeat the process on the second cooler.
4. Once connected, both coolers will play audio simultaneously, creating a stereo effect.



Figure 3: Back view of the cooler, highlighting the KoolSync enabled panel.

Operating Instructions

Power On/Off

Press and hold the power button on the control panel to turn the cooler's audio system on or off. An audible cue will indicate the power status.

Volume Control

Use the volume up (+) and volume down (-) buttons on the control panel to adjust the audio output level. You can also control the volume from your paired Bluetooth device.

Audio Playback

Once paired, audio from your device will automatically stream to the Kool Tunes cooler. Use your device to control playback (play, pause, skip tracks).

Using as a Cooler

The cooler functions as a standard Igloo Playmate cooler. Open the lid by pushing the button on the side and swinging the lid open. Fill with ice and your desired beverages or food items. Ensure the lid is securely closed to maintain cooling efficiency.



Figure 4: Top view of the cooler with the lid open, showing the interior compartment.



Figure 5: The cooler in use, filled with ice and beverages.

Maintenance

Cleaning

To clean the cooler, wipe the exterior with a damp cloth and mild soap. For the interior, use a solution of mild soap and water, then rinse thoroughly. Ensure the speaker grilles and control panel are dry before use. Do not submerge the cooler in water.

Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Recharge the cooler regularly, especially if it will be stored for an extended period. Store in a cool, dry place.

Storage

When not in use, store the cooler in a clean, dry environment away from direct sunlight and extreme temperatures. Ensure the lid is slightly ajar to prevent moisture buildup and odors.

Troubleshooting

- **No Power:** Ensure the battery is charged. Connect the cooler to a power source and allow it to charge for at least 30 minutes before attempting to power on again.
- **No Sound:** Check the volume level on both the cooler and your paired device. Ensure the cooler is successfully paired via Bluetooth. Try unpairing and re-pairing the device.

- **Bluetooth Disconnection:** Ensure your device is within the Bluetooth range (typically up to 33 feet or 10 meters). Avoid obstacles that may interfere with the signal. Try restarting both the cooler and your Bluetooth device.
- **KoolSync Not Pairing:** Verify that both units are KoolSync enabled and not currently paired to other devices. Ensure they are within close proximity during the pairing process.
- **Poor Sound Quality:** Check for interference from other electronic devices. Ensure the audio source is of good quality.

Specifications

Model Name	Igloo Playmate Kool Tunes Blue Red
Model Number	27775
Product Dimensions	10.91"D x 14.57"W x 13.9"H
Capacity	14 Quarts
Speaker Output	2 x 5 Watts (Total 10 Watts)
Bluetooth Version	5.0
Water/Dust Resistance	IP56 Rated
Battery Type	1 Lithium Ion (included)
Audio Playtime	Up to 10 hours
Material	Plastic
UPC	034223277758

Warranty and Support

Warranty Information

Igloo Products Corp. warrants the electronic components in the KoolTunes Playmate® cooler to be free from defects in material or workmanship under normal use and service for **ninety (90) days** from the date of original purchase. The Kool Tunes™ Playmate® cooler and all non-electronic parts are warranted to be free from defects in material or workmanship under normal use and service for **one (1) year** from the date of original purchase.

Customer Support

For technical assistance, warranty claims, or general inquiries, please visit the official Igloo website or contact their customer service department. You can find more information and support resources by visiting the Igloo Store on Amazon or their official brand website.
For additional information regarding KoolSync technology, you may scan the QR code found on the product or visit delivr.com/25y48-qr.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question