

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Wildgame Innovations](#) /
- › [Wildgame Innovation 7-Inch HD Backlit TFT Touchscreen Trail Pad Tablet User Manual](#)

Wildgame Innovations FC-CR1_K205

Wildgame Innovation 7-Inch HD Backlit TFT Touchscreen Trail Pad Tablet User Manual

Model: FC-CR1_K205

1. PRODUCT OVERVIEW

The Wildgame Innovation Trail Pad Tablet is a compact, weather-resistant device designed for viewing and managing images and videos captured by trail cameras. It features an oversized 7-inch HD backlit TFT touchscreen, dual standard-size SD card ports, and a built-in speaker, making it suitable for outdoor use and game tracking.



TRAIL PAD TABLET



The Trail Pad Tablet looks and performs like a tablet, with HD images and videos filling the oversized 7-inch touch screen. But this isn't just any other tablet. It's a hunter's tablet designed to cater to all your game tracking needs.

Image 1.1: The Wildgame Innovation Trail Pad Tablet. This image shows the tablet displaying a trail camera photo of a deer in a forest setting, highlighting its primary function as a viewer for game tracking.

Key Features:

- Oversized 7-inch HD Backlit TFT Touchscreen for clear viewing.
- Dual Standard-Size SD Card Ports for easy file management.
- Weather-Resistant Housing for durability in outdoor conditions.
- Built-in Speaker for audio playback of video files.
- Designed for game tracking, allowing users to view and archive trail camera footage.

2. WHAT'S IN THE BOX

Verify that all components are present in your package:

- Wildgame Innovation 7-Inch HD Backlit TFT Touchscreen Compact Trail Pad Tablet
- Card Reader
- 4 x 32GB Ultra SDHC UHS-I Memory Cards

WHAT'S IN THE BOX



- **Wildgame Innovation 7 In HD Backlit Trail Pad Tablet**
- **4 x SanDisk 32GB Ultra SDHC UHS-I Memory Card (100MB/s)**
- **BELOW ZERO 4-in-1 Card Reader**

Image 2.1: Package Contents. This image displays the Wildgame Innovation Trail Pad Tablet alongside four 32GB SD cards and a multi-format card reader, illustrating all items included in the bundle.

3. SETUP

3.1. Inserting SD Cards

1. Locate the dual standard-size SD card ports on the side of the Trail Pad Tablet.
2. **For Viewing:** Insert an SD card from your trail camera into the designated 'Library' port. Ensure the card is inserted correctly with the contacts facing down.
3. **For Archiving:** Insert one of the included 32GB Ultra SDHC UHS-I Memory Cards into the 'Archive' port. This card will be used to store selected images and videos.

The weather-resistant tablet features dual, standard-size SD card ports to sift through the hundreds of images and videos that every hunting season brings.




Image 3.1: Inserting an SD Card. This image shows a user's hands inserting an SD card into one of the dual ports on the side of the Wildgame Innovation Trail Pad Tablet, demonstrating the card insertion process.

3.2. Powering On

Press and hold the power button, typically located on the side or top edge of the tablet, until the screen illuminates. The tablet will boot up and display the main interface.

4. OPERATING INSTRUCTIONS

4.1. Navigating the Interface

The Trail Pad Tablet features a touchscreen interface. Use your finger to tap icons, swipe through content, and interact with menus.

4.2. Viewing Images and Videos

1. After inserting your trail camera's SD card into the 'Library' port, tap the 'Library' icon on the main screen.
2. Browse through the images and videos. The 7-inch HD screen provides clear playback.
3. Tap on an image or video thumbnail to view it in full screen.

Insert an SD card from your favorite trail cam into the library port to view every deer, hog and turkey in HD quality.



Image 4.1: Viewing Media. This image shows a user's finger tapping on a 'Video' icon on the Wildgame Innovation Trail Pad Tablet screen, indicating the process of selecting and viewing media files.

4.3. Archiving Files

To save important images or videos from your trail camera's SD card to the archive SD card:

1. While viewing an image or video, look for an 'Archive' or 'Save' option on the screen.
2. Tap this option to transfer the selected file to the SD card in the 'Archive' port. This allows you to curate your best footage without endless scrolling through the original card.

5. MAINTENANCE

5.1. Cleaning the Device

- Use a soft, lint-free cloth to gently wipe the touchscreen and exterior of the tablet.
- For stubborn smudges, slightly dampen the cloth with water. Avoid harsh chemicals or abrasive materials.

5.2. Storage

When not in use, store the Trail Pad Tablet in a cool, dry place away from direct sunlight and extreme temperatures. Ensure all SD cards are properly ejected or stored securely.

6. TROUBLESHOOTING

6.1. Device Not Powering On

- Ensure the battery is charged. Connect the tablet to a power source and allow it to charge for at least 30 minutes before attempting to power it on again.
- Press and hold the power button firmly for several seconds.

6.2. SD Card Not Recognized

- Ensure the SD card is fully and correctly inserted into the port.
- Check if the SD card is locked (small switch on the side of the card). Unlock it if necessary.
- Try a different SD card to determine if the issue is with the card or the tablet.
- Ensure the SD card is formatted to a compatible file system (e.g., FAT32).

6.3. No Image/Video Display

- Verify that the SD card contains images or videos.
- Ensure the correct SD card port (Library) is selected on the tablet's interface.
- Check the file formats of the images/videos; the tablet supports standard formats.

7. SPECIFICATIONS

Feature	Detail
Model Number	FC-CR1_K205
Display Size	7 Inches
Display Type	HD Backlit TFT LCD
Human Interface Input	Touchscreen (Capacitive)
Connectivity Technology	USB
Memory Storage Capacity	32 GB (per included SD card)
Item Weight	1 Pound
Product Dimensions	9.1 x 9.1 x 9.1 inches
Special Feature	Hunting-specific Game Tracking Features

8. WARRANTY AND SUPPORT

8.1. Warranty Information

For specific warranty details, please refer to the warranty card included with your product or visit the official Wildgame Innovations website. Keep your proof of purchase for warranty claims.

8.2. Customer Support

If you encounter issues not covered in this manual or require further assistance, please contact Wildgame Innovations customer support. Contact information can typically be found on the manufacturer's website or in the product packaging.