Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MiLESEEY PFS2

MiLESEEY PFS2 Golf Rangefinder User Manual

Model: PFS2 | Brand: MiLESEEY

1. Introduction and Overview

The MiLESEEY PFS2 Golf Rangefinder is a high-performance device designed to enhance your golfing experience with precise distance measurements and advanced features. It offers a dual display for clear visibility, wide field of view, and cutting-edge slope technology for accurate readings. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your rangefinder.



Figure 1: MiLESEEY PFS2 Golf Rangefinder, showcasing its compact and ergonomic design.

2. Package Contents

Upon unboxing your MiLESEEY PFS2 Golf Rangefinder, please ensure all the following items are included:

- MiLESEEY PFS2 Golf Rangefinder (Non-Magnet style)
- High-quality Carrying Pouch with a hook
- CR2 Battery
- User Manual (this document)
- Mirror Polishing Cloth




Figure 2: The MiLESEEY PFS2 Golf Rangefinder and its included accessories.

3. Setup

3.1 Battery Installation

The MiLESEEY PFS2 Golf Rangefinder operates on a CR2 battery. To install or replace the battery:

1. Locate the battery compartment on the side of the rangefinder.
2. Twist the battery cap counter-clockwise to open.
3. Insert the CR2 battery with the positive (+) terminal facing inwards.
4. Replace the battery cap and twist clockwise to secure it.

3.2 Adjusting the Eyepiece

For clear viewing, adjust the eyepiece by rotating it until the display appears sharp and in focus. This is especially useful for users with varying eyesight or those wearing glasses.

4. Operating Instructions

The PFS2 rangefinder is designed for intuitive operation with a focus on speed and accuracy.

4.1 Powering On and Basic Measurement

To power on the device and take a basic distance measurement:

1. Press the power/measurement button (usually the larger button on top) once to activate the display.
2. Aim the crosshairs at your desired target.
3. Press the power/measurement button again to take a measurement. The distance will be displayed instantly.

4.2 Flag-Locking with Pulse Vibration

The PFS2 features rapid 0.1-second flag-locking with pulse vibration confirmation, ensuring you accurately target the flagstick even with background objects.




Figure 3: Visual representation of the flag-locking feature, showing the target acquisition.

Video 1: Official MiLESEEY demonstration of the PFS2 Golf Range Finder's features, including flag-locking and general usage on the golf course. This video highlights the product's design and functionality in a practical setting.

4.3 Slope On/Off Switch

The PFS2 includes advanced slope-adjusted distance technology. For tournament play, the slope function can be easily toggled on or off using the dedicated switch on the device.




Figure 4: Illustration of the physical slope switch on the rangefinder, showing both 'on' and 'off' positions.

4.4 P2P (Point-to-Point) Mode

Utilize the P2P mode to measure the distance between any two points. This is particularly useful when the green is out of sight, allowing a partner to measure the distance to the flagpole for you.

4.5 Scan Mode

Quickly scan crucial areas of the course to construct strategic planning. This mode allows for continuous measurement as you pan across targets.



Figure 5: Depiction of the rangefinder's display in scan mode, showing multiple distance readings.

4.6 Red-Green Dual Optical Display

The PFS2 features a manually adjustable Red-Green dual optical display with 90% optical transmission, ensuring clear visibility in various lighting and weather conditions.




Figure 6: View through the rangefinder's eyepiece, showing the red and green display options for enhanced visibility.

4.7 Rain and Fog Mode

This mode allows the rangefinder to perform accurately even in challenging weather conditions by ignoring weather interference, providing reliable readings.

5. Maintenance

Proper care will extend the life and performance of your MiLESEEY PFS2 Golf Rangefinder.

- **Cleaning the Lenses:** Use the provided mirror polishing cloth to gently wipe the lenses. Avoid using abrasive materials or excessive force, which can scratch the optical surfaces.
- **Storage:** When not in use, store the rangefinder in its high-quality carrying pouch to protect it from dust, moisture, and physical damage.
- **Battery Care:** If the device will not be used for an extended period, remove the CR2 battery to prevent leakage and potential damage to the electronics.
- **Water Resistance:** The device has a waterproof rating (IP54). While it can withstand rain and splashes, avoid submerging it in water.

6. Troubleshooting

If you encounter issues with your rangefinder, try the following common solutions:

- **No Display/Power:** Check if the CR2 battery is correctly installed and has sufficient charge. Replace the battery if necessary.
- **Inaccurate Readings:** Ensure the lenses are clean. Make sure you are aiming at a clear target and not through obstructions. Inquire about the target's reflectivity.
- **Display Not Clear:** Adjust the eyepiece focus until the display is sharp.
- **Flag-Locking Issues:** Ensure you are steady when targeting the flag. The pulse vibration confirms successful lock.

For persistent issues, please refer to the Warranty and Support section.

7. Specifications

Feature	Detail
Brand	MiLESEEY
Model Name	PFS2
Measuring Range	1100 Yards
Accuracy	±0.5 Yard
Flag-locking Speed	0.1 seconds
Magnification	6x
Field of View	7.5°
Optical Transmission	90%
Laser Class	Class 1 (905nm <1mW)
Water Resistance Level	IP54 (Waterproof)
Material	Magnesium Aluminium Alloy
Item Weight	1.21 Pounds
Product Dimensions	5.91"L x 4.72"W x 2.64"H

8. Warranty and Support

MiLESEEY offers comprehensive support for your PFS2 Golf Rangefinder:

- **Warranty:** Enjoy 24 months of warranty support from the date of purchase.
- **Customer Support:** Lifetime dedicated customer assistance is available for any questions or issues you may encounter.

For assistance, please visit the official MiLESEEY website or contact their customer service directly.

© 2024 MiLESEEY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DL2W7KLZ

More documents and user manuals: **https://manuals.plus/**