



[Manuals.plus](#) /

> [Genel](#) /

> Gold Gilded Accessory User Manual

## Genel PLC-1238-AKS-M2

# User Manual

Gold Gilded Accessory

Model: PLC-1238-AKS-M2 | Brand: Genel

## 1. INTRODUCTION

This user manual provides essential information for the safe and efficient operation, setup, and maintenance of your PLC-1238-AKS-M2 Gold Gilded Accessory. Please read this manual thoroughly before using the product and retain it for future reference.

## 2. SAFETY INSTRUCTIONS

To ensure safe operation and prevent damage, please observe the following safety precautions:


- Always connect the product to a power outlet that matches the voltage specified in the product specifications.
- Do not expose the product to water or excessive moisture.
- Avoid placing the product in direct sunlight or near heat sources.
- Do not attempt to disassemble or repair the product yourself. Refer all servicing to qualified personnel.
- Keep the product out of reach of children and pets.
- Ensure the power cable is not pinched or walked on.
- Unplug the product from the power outlet before cleaning or when not in use for extended periods.

## 3. PRODUCT OVERVIEW

The PLC-1238-AKS-M2 is a decorative accessory featuring a unique gold gilded design on a sturdy base. It is designed to enhance the aesthetic appeal of any space.



**Figure 3.1:** Front view of the Gold Gilded Accessory. This image displays the intricate, organic, tree-like design in a gold gilded finish, mounted on a solid black rectangular base. The accessory is designed for decorative purposes.



**Figure 3.2:** Dimensions and material details. This image provides a side view of the accessory, indicating its height (30cm) and width (22cm). Labels point to the "Metal Sarı yıldız Boya" (Gold Gilded Metal Paint) for the top part and "Siyah Mermer" (Black Marble) for the base, along with the product code PLC-1238-AKS-M2.

#### Included Components:

- Product Body (Gold Gilded Accessory)
- Power Cable

*Note: While the primary visual representation shows a decorative item, the product specifications indicate it is an electrical accessory, including a power cable and energy efficiency rating. This suggests it may have an integrated lighting feature not explicitly visible in all product images.*

#### 4. SETUP

1. **Unpacking:** Carefully remove the accessory and all components from the packaging. Inspect for any signs of damage during transit.
2. **Placement:** Choose a stable, flat surface for the accessory, away from direct sunlight, heat sources, and areas prone to moisture. Ensure adequate space around the product for ventilation if it generates heat.
3. **Power Connection:** Insert the power cable into the designated port on the accessory (if applicable). Plug the other end of the power cable into a standard electrical outlet.

## 5. OPERATING

If your accessory includes an illumination feature:

- Once connected to power, locate the power switch (if present) on the accessory or its power cable.
- Toggle the switch to the "ON" position to activate the illumination.
- Toggle the switch to the "OFF" position to turn off the illumination.

For non-illuminated use, simply place the accessory in your desired location as a decorative item.

## 6. MAINTENANCE

Regular cleaning will help maintain the appearance of your accessory:

- **Cleaning:** Before cleaning, ensure the product is unplugged from the power outlet. Use a soft, dry cloth to gently wipe the surface. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth.
- **Avoid:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the gold gilded finish and marble base.
- **Storage:** If storing the product, keep it in its original packaging or a protective cover in a cool, dry place.

## 7. TROUBLESHOOTING

If you encounter issues with your accessory, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Accessory does not illuminate (if applicable).	Not plugged in; power outlet not active; switch is off; faulty cable.	Ensure power cable is securely plugged into both the accessory and a working outlet. Check if the power switch is in the "ON" position. Test the outlet with another device. If issues persist, contact support.
Product appears unstable.	Uneven surface.	Place the accessory on a flat, stable surface.
Surface appears dull or dirty.	Dust or smudges.	Clean with a soft, dry cloth as per maintenance instructions.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Genel
Model Number	PLC-1238-AKS-M2
Manufacturer	PULCHINO
Part Number	PLC-1238-AKS-M2
Product Dimensions	22 x 22 x 30 cm (Depth x Width x Height)

<b>Color</b>	Gold Gilded (Sarı yıldız)
<b>Material</b>	Cast Metal (Gold Gilded), Marble (Black Base)
<b>Included Components</b>	Product body, Power Cable
<b>Lampshade Color</b>	Grey (if applicable to an integrated light source)
<b>Power Source</b>	Wired Electric
<b>EU Energy Efficiency Label</b>	A
<b>Country of Origin</b>	Turkey
<b>First Available Date</b>	August 27, 2024

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact the manufacturer, PULCHINO, directly. Keep your proof of purchase for any warranty claims. For further assistance, you may also visit the product's page on the retailer's website or contact their customer service.