Hzuaneri DFC84301B

Hzuaneri DFC84301B Dog Crate Furniture Instruction Manual

Model: DFC84301B

Introduction

Thank you for choosing the Hzuaneri Dog Crate Furniture. This product is designed to provide a comfortable and secure space for your small dog while blending seamlessly with your home decor as a piece of furniture. This manual contains important information regarding the assembly, operation, and maintenance of your dog crate. Please read it thoroughly before use and retain it for future reference.

Safety Information

- Ensure all parts are securely fastened before allowing your pet to use the crate.
- Do not overload the top surface of the crate.
- Regularly inspect the crate for any loose parts or damage. Discontinue use if any damage is found.
- This product is intended for indoor use only.
- Ensure the crate size is appropriate for your dog to stand, turn around, and lie down comfortably.
- Keep small parts and packaging materials away from children and pets during assembly.

Package Contents

Before assembly, please verify that all components listed below are present and undamaged.

- 1 x Dog Crate Furniture (main panels)
- 1 x Accessory Bag (screws, bolts, tools)
- 1 x Instructions Manual (this document)

Assembly Instructions

Assembly typically requires one person and approximately 90 minutes. No additional tools are needed beyond what is provided. Follow the visual instructions carefully.

1. **Unpack and Identify Parts:** Lay out all components and hardware. Each part is labeled for easy identification.
2. **Assemble the Base:** Attach the side panels to the bottom panel using the provided hardware. Ensure all connections are snug.
3. **Install Metal Bar Panels:** Secure the metal bar panels to the designated slots on the side and front sections.
4. **Attach the Top Panel:** Place the top panel onto the assembled structure and secure it with screws.
5. **Install Sliding Barn Door:** Mount the sliding door mechanism and attach the barn door. Ensure it slides smoothly.
6. **Attach Locks:** Install the anti-escape locks on the sliding door and the side door. Test their functionality.
7. **Final Check:** Verify that all screws are tightened and the crate is stable.



Image: The assembled dog crate with a dog entering, showcasing the barn door design.



Image: View of the dog crate with both side and front doors open, illustrating access options.



Image: Detailed features including the sliding door, easy-clean surface, and secure locks.



Image: Detail of the thickened metal frame for enhanced durability.

Operating Instructions

Using the Sliding Barn Door

The front of the dog crate features a unique sliding barn door. To open, simply slide the door along its track. To close, slide it back into position and engage the two anti-escape locks for security.

Using the Side Door

The crate also includes a hinged side door for alternative access. To open, unlatch the two locks and swing the door outwards. To close, swing the door back and secure both locks.



Image: The crate with both doors open, demonstrating flexible access.



Image: A dog comfortably inside the crate with the front door open.

Video: This video demonstrates the stylish appearance and safe functionality of the dog crate in a home environment, including a dog entering and exiting.

Video: This video highlights the heavy-duty construction and the smooth operation of the barn door on a similar model.

Maintenance and Care

To ensure the longevity and cleanliness of your Hzuaneri Dog Crate Furniture, follow these care guidelines:

- **Cleaning:** The engineered wood surface is wear-resistant and easy to clean. Wipe down with a damp cloth and mild detergent. Avoid harsh chemicals that may damage the finish.
- **Metal Bars:** Clean metal bars with a damp cloth. Dry thoroughly to prevent rust.

- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Tighten any loose hardware as needed.
- **Avoid Moisture:** While the surface is water-resistant, prolonged exposure to liquids should be avoided. Promptly wipe up any spills.



Image: The easy-to-clean surface of the crate.

Troubleshooting

Door Not Sliding Smoothly

- Check the sliding track for any obstructions or debris.
- Ensure the door is properly aligned on its rollers.
- Verify that all assembly screws related to the door mechanism are tightened.

Locks Not Engaging

- Inspect the lock mechanism for any misalignment or damage.
- Ensure the door is fully closed and aligned with the locking points.
- If a lock is loose, tighten its mounting screws.

Crate Instability

- Check all connection points and tighten any loose screws.
- Ensure the crate is placed on a flat, level surface.
- If one leg seems slightly off, a small furniture pad can be used to stabilize it.

Specifications

Feature	Detail
Model Number	DFC84301B

Product Dimensions (External)	27.2"L x 19.3"W x 25.4"H
Interior Dimensions	24.6"L x 16.9"W x 21.3"H
Material	Engineered Wood, Metal
Color	Rustic Brown
Gap Size (Metal Bars)	0.4 inches
Item Weight	13.7 kg (30.2 pounds)
Breed Recommendation	Small Dogs (e.g., Poodle, Pug, Chihuahua)



Image: Product dimensions and dog measurement guide.

Warranty and Support

For any questions, concerns, or assistance with your Hzuaneri Dog Crate Furniture, please contact our customer support. Refer to your purchase documentation for specific warranty details. We are committed to providing quality products and support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question