

750, 750H, 760, 760H, 800, 800H, 850, 850H, 860H, Ektagraphic AF-1, AF-2, AF-3, B2

Instruction Manual: Repair Kit for Kodak Carousel Slide Projector with Focus Motor

Model Compatibility: Kodak Carousel Slide Projectors 750, 750H, 760, 760H, 800, 800H, 850, 850H, 860H and Ektagraphic AF-1, AF-2, AF-3, B2 models.

1. PRODUCT OVERVIEW

This repair kit is designed to address common issues with Kodak Carousel Slide Projectors that feature a focus motor, specifically when the slide tray fails to advance or reverse. The primary cause of this malfunction is often the breakage of a small link and focus motor gears within the projector mechanism.

Kit Contents:

- 1 Link
- 1 Lock Pin
- 1 Focus Motor Gear
- 1 Gear Next to Focus Motor Gear



Figure 1: Components included in the repair kit. From top left, clockwise: Focus Motor Gear, Lock Pin, Link, and Gear Next to Focus Motor Gear.

2. INSTALLATION INSTRUCTIONS

Repairing your Kodak Carousel Slide Projector requires careful attention to detail. It is highly recommended to consult the online repair manual provided with the kit and watch instructional videos for visual guidance. A general search for
