

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [HOMCOM](#) /

> [HOMCOM Radiator Cover with Drawer \(Model: 820-398V00GY\) - Instruction Manual](#)

HOMCOM 820-398V00GY

HOMCOM Radiator Cover with Drawer (Model: 820-398V00GY) - Instruction Manual

1. PRODUCT OVERVIEW

This HOMCOM radiator cover is designed to provide a protective and decorative enclosure for your radiator. Constructed from a blend of MDF and particle board, it features a slatted design to ensure efficient heat dissipation while preventing direct contact with the hot radiator surface. The unit also includes a convenient top drawer for additional storage.



Image 1.1: Front view of the HOMCOM Radiator Cover with Drawer in grey finish.

2. SAFETY INFORMATION

Please read and adhere to the following safety guidelines to ensure safe use and prevent damage or injury:

- Always follow the provided assembly instructions carefully.

- Keep the radiator cover away from flammable materials.
- Do not place heavy objects on the drawer or top surface that exceed the specified weight limit (4 kg for the drawer).
- Always turn off the radiator before performing any maintenance, assembly, or disassembly work on the cover.
- Ensure the cover is securely installed to prevent tipping.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Radiator cover panels (side panels, top panel, front slatted panel, back support)
- Drawer components (drawer front, sides, back, bottom)
- Drawer handle and associated fasteners
- Assembly hardware (screws, dowels, clips for wall attachment)
- Instruction manual

4. SETUP AND ASSEMBLY

Assembly of this radiator cover is required. Follow the detailed instructions provided in the included manual. The following points highlight key aspects of the setup:

4.1 Pre-Assembly Considerations

Before purchasing and assembling, measure your radiator to ensure compatibility. The cover is suitable for radiators up to 81 cm in height and 73 cm in width.



Image 4.1: Guide for measuring your radiator to ensure proper fit.

4.2 Skirting Board Compatibility

The radiator cover features a pre-cut-out design at the bottom to accommodate skirting boards, allowing for a flush fit against the wall.



Image 4.2: Detail of the pre-cut-out designed to fit over skirting boards.



Image 4.3: Close-up view illustrating the skirting board cut-out for a seamless installation.

4.3 Secure Installation

The cover includes clips for easy and secure attachment to the wall, ensuring stability. These clips also facilitate simple removal for cleaning or inspection.

PRE CUT-OUT

Fits for skirting board



Image 4.4: Illustration of the clips used to fix the radiator cover in place.

5. OPERATING INSTRUCTIONS

5.1 Heat Dissipation

The horizontal slatted design of the front panel allows heat to travel out efficiently, ensuring your room remains warm and cozy while the radiator is covered.

5.2 Drawer Usage

The integrated top drawer provides additional storage space for small items. To open, gently pull the handle. To close, push the drawer back until it is flush with the cover's front.

CLIPS

 Cleaning

 Inspecting



Image 5.1: The top drawer opened, demonstrating the extra storage capacity.



Image 5.2: A close-up view of the drawer containing various small items.

6. MAINTENANCE

Regular maintenance helps prolong the life and appearance of your radiator cover:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the painted finish.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight. Re-tighten if necessary.
- **Removal:** The cover can be easily removed from its wall clips for thorough cleaning of the radiator or the cover itself. Ensure the radiator is cool before removal.

7. TROUBLESHOOTING

If you encounter issues with your radiator cover, consider the following:

- **Instability:** Ensure all assembly screws are tightened and the wall clips are securely fastened to a suitable wall surface.
- **Drawer sticking:** Check that the drawer runners are clean and free from obstructions. Ensure the drawer

is assembled correctly and not overloaded.

- **Heat not escaping:** While the slatted design is optimized for heat flow, ensure no objects are blocking the slats or the top opening of the cover.

8. SPECIFICATIONS

Model Name	Radiator Cover
Model Number	820-398V00GY
Overall Dimensions (H x W x D)	95.5 cm x 78 cm x 19 cm (37.6 x 30.71 x 7.48 inches)
Maximum Radiator Dimensions (H x W)	81 cm x 73 cm
Material	Engineered Wood (MDF and Particle Board)
Color	Grey
Drawer Weight Limit	4 kg
Assembly Required	Yes



Image 8.1: Detailed dimensional drawing of the radiator cover.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact HOMCOM customer service through their official website or the retailer where the product was purchased. Please have your model number (820-398V00GY) and purchase date available when contacting support.