



Manuals.plus /

- › **Aeitto** /
- › Aeitto Ice Makers Countertop User Manual

Aeitto WBJ10D3

Aeitto Ice Makers Countertop User Manual

Model: WBJ10D3

INTRODUCTION

Thank you for choosing the Aeitto Ice Makers Countertop. This appliance is designed to provide you with fresh ice quickly and conveniently. Please read this manual thoroughly before operating your ice maker to ensure safe and efficient use. Keep this manual for future reference.



Figure 1: Aeitto Ice Makers Countertop with ice and a drink. This image illustrates the compact design and the type of ice produced by the machine.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not touch the evaporator or ice basket when the unit is in operation.
- Do not immerse cord, plug, or any part of the unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not use the appliance for other than intended use.
- Ensure the voltage of the appliance corresponds to your local power supply.
- This appliance must be grounded.

PRODUCT OVERVIEW

The Aeiitto Ice Maker is designed for ease of use and efficient ice production. Key features include:

- **Control Panel:** Features ON/OFF, SELECT buttons, and indicator lights for Power, Small/Large ice size, Add Water, Ice Full, and Clean.
- **Ice Basket:** Removable basket for collecting ice cubes.
- **Water Reservoir:** Located beneath the ice basket, where water is stored for ice production.
- **Viewing Windows:** Two windows allow monitoring of ice production and ice storage levels.
- **Drain Plug:** Located at the bottom for easy water drainage.

SETUP

1. **Unpacking:** Carefully remove the ice maker from its packaging. Remove all packing materials, including tape and labels.
2. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the "Maintenance" section for detailed cleaning instructions.
3. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and other heat sources (e.g., stove, furnace, radiator). Ensure there is at least 10 cm (4 inches) of space around the unit for proper ventilation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

1. **Fill Water Reservoir:** Open the lid and remove the ice basket. Fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
2. **Power On:** Press the **ON/OFF** button to turn on the ice maker. The "Power" indicator light will illuminate.
3. **Select Ice Size:** Press the **SELECT** button to choose between Small or Large ice cubes. The corresponding indicator light will illuminate. Small cubes are ideal for drinks, while large cubes are suitable for chilling or smoothies.
4. **Ice Production:** The ice maker will begin the ice-making cycle. The first batch of ice typically takes about 6-10 minutes, depending on the selected size and ambient temperature.
5. **"ADD WATER" Indicator:** If the "Add Water" indicator light illuminates, it means the water reservoir is low. Add more water to continue ice production.
6. **"ICE FULL" Indicator:** When the ice basket is full, the "Ice Full" indicator light will illuminate, and the ice maker will automatically stop producing ice. Remove ice from the basket to resume production.
7. **Power Off:** To turn off the ice maker, press the **ON/OFF** button again.

MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and longevity of your ice maker.

Self-Cleaning Function

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the **ON/OFF** button for 5 seconds. The "Clean" indicator light will illuminate, and the unit will begin its self-cleaning cycle.
3. The cleaning cycle typically takes several minutes. Once complete, the unit will stop.
4. Drain the water from the reservoir using the drain plug at the bottom of the unit.
5. It is recommended to perform the self-cleaning function once a week for optimal hygiene.

Manual Cleaning

- Unplug the ice maker before cleaning.
- Remove the ice basket.
- Drain any remaining water from the reservoir.
- Clean the interior with a soft cloth dampened with a mild detergent solution. Rinse thoroughly with clean water.
- Wipe the exterior with a soft, damp cloth.
- Ensure all parts are dry before plugging the unit back in.
- Do not use abrasive cleaners or sharp objects to clean the ice maker.

Storage

If the ice maker will not be used for an extended period, drain all water, clean the unit thoroughly, and allow it to dry completely before storing in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
"ADD WATER" indicator light is on.	Water reservoir is empty or water level is too low.	Add potable water to the reservoir up to the MAX fill line.
"ICE FULL" indicator light is on.	Ice basket is full.	Remove ice from the basket. The unit will resume ice production automatically.
Ice cubes are too small or clumpy.	Water temperature is too high or ambient temperature is too high.	Use colder water. Place the unit in a cooler environment. Ensure proper ventilation.
Ice maker is not producing ice.	No power, water shortage, or internal malfunction.	Check power connection. Add water if "ADD WATER" light is on. If problem persists, contact customer support.
Unusual noise during operation.	Normal operational sounds (compressor, water pump) or potential malfunction.	Some noise is normal. If the noise is excessively loud or unusual, ensure the unit is on a stable surface and not vibrating against anything. If the noise is persistent and concerning, discontinue use and contact customer support.

SPECIFICATIONS

Brand: Aeitto

Model Name: WBJ10D3

Product Dimensions: 24.2D x 18.7W x 27H Centimetres (9.53D x 7.36W x 10.63H inches)

Weight: 6.5 kg (14.33 lbs)

Capacity: 408 g (ice basket capacity)

Refrigerant: R600a

Ice Production: Approximately 9 ice cubes in 6 minutes; up to 26 lbs per 24 hours.

WARRANTY AND SUPPORT

For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Aeitto website. Please have your model number (WBJ10D3) and purchase details ready when contacting support.