

BHNYBWUL S66

BHNYBWUL S66 Wireless Earbuds

USER MANUAL

Model: S66 | Brand: BHNYBWUL

1. Introduction

Thank you for choosing the BHNYBWUL S66 Wireless Earbuds. These earbuds feature Bluetooth 5.3 technology, providing a stable connection and high-quality audio. Designed for comfort and durability, they are suitable for various activities, including sports and daily use. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.

2. Package Contents

Please verify that all items are present in your package:

- BHNYBWUL S66 Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- User Manual
- Multiple Sizes of Eartips (S/M/L)



Image: Contents of the BHNYBWUL S66 Wireless Earbuds package, showing the earbuds, charging case, USB-C cable, user manual, and various eartip sizes.

3. Product Overview

The BHNYBWUL S66 earbuds are designed for an immersive audio experience with powerful bass, clear mids, and bright highs. They feature an ergonomic design for comfortable wear and an IPX7 waterproof rating for durability.



Image: An exploded diagram of the earbud's internal components, highlighting the dual-layer 12mm diaphragm drivers responsible for superior Hi-Fi stereo sound.




Image: The BHNYBWUL S66 charging case with its lid open, displaying the accurate LED digital power display for both the earbuds and the charging case.

4. Setup

4.1 Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the USB-C charging cable to the charging port on the case and a power source. The LED display on the case will indicate the charging status.

4.2 Pairing with Your Device

1. Ensure the charging case is charged and the earbuds are inside.
2. Open the charging case. The earbuds will automatically power on and enter pairing mode.

3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for available Bluetooth devices and select "S66" from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

The earbuds will automatically reconnect to the last paired device when removed from the case, provided Bluetooth is enabled on the device.



Image: The BHNYBWUL S66 earbuds and charging case, illustrating the one-step pairing process with Bluetooth 5.3 technology for easy connection to iOS, Android, and Windows devices.

5. Operating Instructions

5.1 Wearing the Earbuds

Select the eartip size that provides the most comfortable and secure fit. Gently insert the earbuds into your ears and rotate them slightly to ensure a snug seal for optimal sound quality and stability.



Image: A visual guide demonstrating the ergonomic design of the S66 earbuds and the selection of S/M/L eartips for a comfortable and secure fit.

5.2 Touch Controls

The earbuds feature smart touch controls for easy management of audio playback and calls:

- **Play/Pause:** Single tap on either earbud.
- **Next Song:** Double tap on the right earbud.
- **Previous Song:** Double tap on the left earbud.

- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold either earbud for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Press and hold either earbud for 3 seconds.

5.3 Power On/Off

- **Power On:** The earbuds automatically power on when removed from the charging case.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will automatically disconnect and power off.

6. Charging

The BHNYBWUL S66 earbuds offer extended playback time with their charging case:

- **Earbud Battery Life:** Up to 6 hours on a single charge.
- **Total Playback Time:** Up to 50 hours with the charging case.
- **Quick Charge:** A 10-minute charge provides approximately 2 hours of playtime.

The LED display on the charging case shows the battery percentage of the case and the individual charging status of each earbud.




Image: The BHNYBWUL S66 earbuds in their charging case, illustrating the 6 hours of single charge playback, 50 hours total with the case, and 1.5 hours for a quick charge.

7. Maintenance

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Eartips:** Remove and clean the eartips periodically with water and mild soap, then dry thoroughly before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Water Resistance:** The earbuds are IPX7 waterproof, meaning they can withstand submersion in up to 1 meter of water for 30 minutes. However, the charging case is not waterproof. Avoid exposing the charging case to liquids.

8. Troubleshooting

If you encounter issues with your BHNYBWUL S66 Wireless Earbuds, please refer to the following common solutions:

Problem	Solution
Earbuds not pairing/connecting	<ul style="list-style-type: none">◦ Ensure earbuds are charged.◦ Place earbuds back in the case, close, then reopen to re-enter pairing mode.◦ Turn off and on Bluetooth on your device.◦ Forget/delete "S66" from your device's Bluetooth list and re-pair.
No sound or low volume	<ul style="list-style-type: none">◦ Adjust volume on both your device and via earbud touch controls.◦ Ensure earbuds are properly seated in your ears.◦ Check if the earbuds are connected to the correct device.
Earbuds not charging	<ul style="list-style-type: none">◦ Ensure the charging cable is securely connected to both the case and power source.◦ Check if the charging case has power.◦ Clean the charging contacts on both the earbuds and the case.
Intermittent connection	<ul style="list-style-type: none">◦ Ensure there are no obstructions between the earbuds and your device.◦ Move closer to your device.◦ Avoid environments with strong Wi-Fi or other wireless interference.

9. Specifications

Feature	Detail
Model Name	S66
Brand	BHNYBWUL
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Version	5.3
Earbud Battery Life	Up to 6 hours
Total Playback Time (with case)	Up to 50 hours
Water Resistance Level	IPX7 Waterproof (earbuds only)
Control Method	Touch
Compatible Devices	Laptops, Phones, Smart Speakers, Televisions
Material	Plastic
Item Weight	3.2 ounces
Package Dimensions	3.7 x 3.43 x 1.34 inches

10. Warranty & Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official BHNYBWUL website. Keep your proof of purchase for warranty claims.