

## Hivento Ventiladores de Torre-aromaterapia 01

# Hivento Tower Fan with Aroma Box: User Manual

MODEL: VENTILADORES DE TORRE-AROMATERAPIA 01

## 1. Introduction

---

Thank you for choosing the Hivento Tower Fan with Aroma Box. This manual provides essential information for the safe and efficient operation of your new appliance. Please read it thoroughly before use and retain it for future reference.



Image 1.1: Hivento Tower Fan and its remote control. The fan is a sleek, black tower design with a digital display on top, and the remote is compact with clearly labeled buttons.

## 2. Safety Instructions

---

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using this fan.
- Always unplug the fan from the power outlet before cleaning, servicing, or moving it.
- Do not insert fingers or foreign objects into any openings of the fan.
- Do not operate any fan with a damaged cord or plug. If the cord or plug is damaged, contact customer

service.

- Ensure the fan is placed on a stable, level surface to prevent tipping.
- Do not use the fan in wet or damp locations, such as bathrooms or laundry areas.
- Keep children and pets away from the fan during operation. The fan features a child lock for added safety.
- This appliance has a safety plug with a fuse to prevent damage from overvoltage and power surges. Do not attempt to modify or bypass this safety feature.

### 3. Package Contents

---

Verify that all items are present in the package:

- Hivento Tower Fan Unit
- Base (2 halves)
- Remote Control
- User Manual

### 4. Setup

---

The Hivento Tower Fan requires minimal assembly. Follow these steps to set up your fan:

1. Carefully remove all components from the packaging.
2. Assemble the two halves of the base by aligning them and twisting or clicking them together.
3. Align the assembled base with the bottom of the main fan unit. Secure the base to the fan unit, typically by twisting or using screws if provided (check packaging for specific fasteners).
4. Place the fan on a firm, level surface. Ensure there are no obstructions around the fan for optimal airflow.
5. Plug the power cord into a standard 120V AC electrical outlet.

### 5. Operating Instructions

---

Your Hivento Tower Fan can be operated using the touch control panel on top of the unit or the included remote control.

#### 5.1 Control Panel Overview

The touch control panel features intuitive icons for various functions:

- **Power Button:** Turns the fan on or off.

- **Speed Button:** Adjusts fan speed (Low, Medium, High).
- **Mode Button:** Cycles through different modes (Normal, Natural, Sleep, ECO).
- **Timer Button:** Sets the auto-off timer.
- **Oscillation Button:** Activates or deactivates the 70° oscillation.
- **Child Lock Button:** Engages or disengages the child lock.
- **Silent Mode Button:** Activates a low-noise operation mode.
- **Aroma Function Indicator:** Indicates aroma box operation.

## 5.2 Remote Control Overview

The remote control duplicates most functions of the control panel for convenient operation from a distance.

- **POWER:** Turns the fan on or off.
- **SPEED:** Adjusts fan speed.
- **TIMER:** Sets the auto-off timer.
- **MODE:** Cycles through different modes.
- **SILENT MODE:** Activates silent operation.
- **OSC:** Activates or deactivates oscillation.

## MANDO A DISTANCIA

Puedes controlarlo directamente a distancia sin tener que levantarte.



Image 5.1: A hand holding the remote control, pointing it towards the Hiventio Tower Fan. This illustrates the convenience of remote operation.

### 5.3 Power On/Off

Press the **Power** button on the control panel or remote control to turn the fan on or off.

### 5.4 Speed Settings

Press the **Speed** button repeatedly to cycle through the 3 available fan speeds: Low, Medium, and High. The current speed setting will be displayed on the LED screen.

# PERSONALICE SU FLUJO DE AIRE DESEADO

Más velocidades y modos para estar cómodo en cualquier situación



Image 5.2: Diagram illustrating the Hivento Tower Fan's 3 modes (Natural, Sleep, ECO) and 3 speeds (Low, Medium, High), with an arrow indicating a 7.5m/s airflow.

## 5.5 Mode Selection

Press the **Mode** button repeatedly to select from the following airflow modes:

- **Normal Mode:** Provides a constant airflow at the selected speed.
- **Natural Mode:** Simulates natural breezes by varying fan speed.
- **Sleep Mode:** Operates at a lower speed and noise level for undisturbed sleep. The LED display will dim automatically after 10 seconds in this mode.
- **ECO Mode:** Adjusts fan speed based on ambient temperature for energy efficiency.

## 5.6 Oscillation Function

Press the **Oscillation** (OSC) button to activate the 70° wide-angle oscillation, distributing air across a larger area. Press it again to stop oscillation.

## ROTACIÓN DE 70°

Gracias a la rotación de 70°, el viento puede soplar hacia la mayoría de los lugares de la casa




Image 5.3: An illustration showing the Hivento Tower Fan oscillating 70 degrees, indicating wide air distribution in a room.

### 5.7 Timer Function

Press the **Timer** button to set the auto-off timer. Each press increases the timer by 1 hour, up to a maximum of 15 hours. The fan will automatically turn off after the set time has elapsed.

### 5.8 Aroma Box Usage

The fan includes an integrated aroma box for diffusing essential oils.

1. Locate the aroma box compartment, typically at the bottom rear of the fan unit.
2. Gently open or pull out the aroma box.
3. Add a few drops of your preferred essential oil onto the cotton pad inside the box.
4. Close the aroma box securely. The fan will now circulate air with the added fragrance.

## AROMA BREEZE

Tenemos una caja especial de aromaterapia para que tu viento huela a aromaterapia



Image 5.4: A close-up of the Hivento Tower Fan's aroma box, showing a hand adding essential oil to the pad. The fan is shown in the background, circulating air.

### 5.9 Child Lock Function

To prevent accidental changes to settings, activate the child lock by pressing the **Child Lock** button on the control panel. Press it again to deactivate.

# DISEÑO DE SEGURIDAD SIN CUCHILLAS

El diseño sin cuchilla le permite evitar cualquier problema de seguridad



Enchufe de seguridad



Bloqueo para niños



Image 5.5: An image highlighting the Hivento Tower Fan's safety features, including a child lock and safety plug, with a child playing near the fan.

## 6. Maintenance

---

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Hivento Tower Fan.

### 6.1 Cleaning the Fan

1. Always unplug the fan before cleaning.
2. Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
3. Use a vacuum cleaner with a brush attachment to gently remove dust from the air intake and outlet grilles.
4. Ensure the fan is completely dry before plugging it back in.

## 6.2 Cleaning the Aroma Box

Periodically clean the aroma box and replace the cotton pad to prevent residue buildup and ensure effective diffusion.

1. Remove the aroma box from the fan.
2. Remove the cotton pad. You can wash the pad with mild soap and water, or replace it with a new one.
3. Wipe the inside of the aroma box with a damp cloth.
4. Ensure all parts are dry before reassembling and placing back into the fan.

## 7. Troubleshooting

---

If you encounter any issues with your Hivento Tower Fan, refer to the following common problems and solutions:

- **Fan does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the safety plug's fuse is intact. If blown, replace it according to electrical safety guidelines.
  - Press the Power button on the control panel or remote control.
- **No airflow or weak airflow:**
  - Increase the fan speed using the Speed button.
  - Ensure the air intake and outlet grilles are not blocked by dust or obstructions. Clean if necessary.
- **Fan is not oscillating:**
  - Press the Oscillation (OSC) button to activate the oscillation function.
- **LED display dims or turns off in Sleep Mode:**
  - This is a normal function of Sleep Mode. Press any button on the control panel or remote to temporarily reactivate the display.
- **Unusual noise during operation:**
  - Ensure the fan is placed on a stable, level surface.
  - Check for any foreign objects that may have fallen into the fan grilles. Unplug the fan before inspecting.

If the problem persists after attempting these solutions, please contact Hivento customer support.

## 8. Specifications

---

| Feature | Specification |
|---------|---------------|
| Brand   | Hivento       |

| Feature                | Specification  |
|------------------------|--|
| Model Number           | Ventiladores de Torre-aromaterapia 01  |
| Voltage                | 120 Volts  |
| Material               | Plastic  |
| Number of Speeds       | 3  |
| Special Features       | Tower base, Remote control, Oscillating, Aroma Box, Child Lock, 15H Timer, Silent Operation (30dB) |
| Dimensions (L x W x H) | 30 x 30 x 110.7 cm (approx. 11.8 x 11.8 x 43.6 inches)   |
| Weight                 | 5.22 Kilograms (approx. 11.5 lbs)  |
| Oscillation Angle      | 70°  |

## 9. Warranty and Support

---

**Warranty Information:** For detailed information regarding the product warranty, including terms, conditions, and duration, please refer to the warranty card included with your purchase or contact Hivento customer service directly. Keep your proof of purchase for warranty claims.

**Customer Support:** If you have any questions, require technical assistance, or need support regarding your Hivento Tower Fan, please contact our customer service team. Contact details can typically be found on the product packaging or the official Hivento website.