

[Manuals.plus](#) /

› [STAEDTLER](#) /

› STAEDTLER triplus Fineline Pens 334 C12 - Instruction Manual

## STAEDTLER 334 C12

# STAEDTLER triplus Fineline Pens

MODEL: 334 C12 - INSTRUCTION MANUAL

### 1. Product Overview

The STAEDTLER triplus fineline pens are designed for precise writing, drawing, and coloring. This set includes 12 pens in assorted vibrant colors. Featuring an ergonomic triangular barrel, these pens provide a comfortable grip for extended use. The superfine, metal-clad tip ensures consistent line quality, and the water-based ink is formulated to be 'DRY SAFE', preventing the pens from drying out even if left uncapped for several days. The ink is also washable from most textiles.



12 triplus® fineliner



note  
~0.3 mm



Image 1.1: STAEDTLER triplus Fineliner Pen (Red)

## 2. Setup

Your STAEDTLER triplus fineliner pens are ready for immediate use upon unpacking.

1. **Unpacking:** Carefully remove the pens from their packaging.
2. **Initial Use:** Remove the cap from the desired pen. The pen is now ready for writing or drawing.

### What's Included:

- 12 STAEDTLER triplus fineliner pens in assorted colors.

## 3. Operating Instructions

Using your STAEDTLER triplus fineliner pens is straightforward. Follow these guidelines for optimal performance:

- **Holding the Pen:** The ergonomic triangular barrel is designed for a comfortable and natural grip. Hold the pen as you would a standard writing instrument.
- **Writing/Drawing:** Apply light to moderate pressure to the paper or desired surface. The superfine tip produces a consistent line of approximately 0.3mm.
- **Capping:** After use, always replace the cap firmly with a click to protect the tip and prevent accidental marks. While the pens feature DRY SAFE technology, proper capping extends their lifespan.
- **DRY SAFE Feature:** These pens can be left uncapped for several days without drying out, thanks to the DRY SAFE ink technology. This provides convenience during creative sessions.



Image 3.1: Proper grip and usage of the fineliner pen.



~ 0.3 mm

Image 3.2: Approximate line width of 0.3mm.

## 4. Maintenance

To ensure the longevity and performance of your STAEDTLER triplus fineliner pens, follow these maintenance tips:

- **Storage:** Store pens horizontally when not in use to ensure even ink distribution. Keep them away from direct sunlight and extreme temperatures.
- **Cleaning:** The water-based ink is washable from most textiles. In case of accidental marks on fabric, wash promptly with water and soap. Do not attempt to clean the pen tips with harsh chemicals.
- **Cap Replacement:** Always replace the cap securely after each use. The ventilated cap meets ISO 11540 standards for safety.

## 5. Troubleshooting

If you encounter any issues with your fineliner pens, refer to the following common solutions:

- **Pen not writing or ink flow is inconsistent:**
  - Ensure the cap has been removed.
  - Gently try writing on a scrap piece of paper to re-prime the tip.
  - If the pen has been left uncapped for an extended period beyond the DRY SAFE limit, the tip may have dried out. Consider replacing the pen.
- **Ink appears faded:**
  - The ink level may be low. Replace the pen with a new one.
- **Accidental ink stains on clothing:**
  - Due to the water-based ink, most stains can be washed out of textiles. Treat the stain promptly with water and a mild detergent.

## 6. Specifications

Detailed specifications for the STAEDTLER triplus Fineliner Pens, Model 334 C12:

|                        |                                                                                      |
|------------------------|--------------------------------------------------------------------------------------|
| Brand                  | STAEDTLER                                                                            |
| Model Number           | 334 C12                                                                              |
| Included Components    | 12 Fineliners                                                                        |
| Ink Color              | Yellow, orange, red, pink, purple, blue, green, turquoise, black, grey, white, brown |
| Point Type             | Fine                                                                                 |
| Line Size              | 0.3 mm                                                                               |
| Ink Base               | Water                                                                                |
| Water Resistance Level | Not Water Resistant                                                                  |
| Grip Type              | Contoured (Triangular Body Shape)                                                    |
| Closure Type           | Click-Off Cap                                                                        |
| Additional Features    | DRY SAFE, Environmentally friendly (97% recycled plastic housing)                    |
| Recommended Uses       | Colouring, Note Taking, Writing                                                      |
| Target Audience        | Adult, Kid (Age Range 14+)                                                           |




Image 6.1: Key features of STAEDTLER triplus fineliner pens.

## 7. Warranty and Support

For product support, inquiries, or information regarding warranty, please contact STAEDTLER directly through their official website or customer service channels. Keep your purchase receipt as proof of purchase.

**Official Website:** [www.staedtler.com](http://www.staedtler.com)

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details.](#)

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question