

24Six 24SIXSOLO3

24Six Solo3 MP3 Player User Manual

Model: 24SIXSOLO3

Brand: 24Six

INTRODUCTION

The 24Six Solo3 MP3 Player is designed to provide a secure and advanced listening experience for Jewish music, children's stories, and Torah shiurim. Featuring the new X3 Chip/PCBA Board and a brilliant HD display, Solo3 is 20% thinner and 25% faster than previous models. It is powered by Chein, a musical intelligence system that personalizes your listening experience.

This manual provides essential information for setting up, operating, and maintaining your Solo3 device.

WHAT'S IN THE BOX

- 24Six Solo3 MP3 Player
- Case
- Charger
- Plastic Screen Protector
- USB-C Cable
- Wired Earbuds

KEY FEATURES

- **64GB Internal Memory:** Ample space for tens of thousands of songs and thousands of shiurim/stories.
- **X3 Chip/PCBA Board:** Ensures a secure and advanced kosher product.
- **HD Display:** Gorgeous, seamlessly embedded display for enhanced user experience.
- **Chein Musical Intelligence:** Customizes and tailors the listening experience based on data from over 300 million listens.

- **SearchSense:** Patented musical intelligence search that anticipates queries, corrects spelling, and factors in trends and listening history.
- **Autoplay:** Learns in real-time to recommend the perfect next song.
- **Your Daily Mix:** Generates daily custom playlists based on preferences and time of day.
- **Secure Device:** Music-only MP3 player with no home screen, no apps, and no MicroSD card slot. Content is 100% secure, vetted, and approved kosher Jewish Music.
- **No Video or Podcasts:** Strictly a music, shiurim, and children's stories player.
- **Limited Connectivity:** While featuring Aux, Bluetooth, and Wi-Fi, the device is designed for security. You cannot Bluetooth content to Solo3, take content off of Solo3, or access the Wi-Fi password directly. There are no hidden menus.

SETUP

1. **Charging the Device:** Connect the Solo3 to the charger using the provided USB-C cable. Ensure the device is fully charged before first use.
2. **Account Creation and Management:** All account creation, profile creation, and content filters for 24Six Solo3 must be done on the official website: www.24Six.app. Due to the small screen size, there is no account or profile management directly on the Solo3 device.
3. **Subscription Requirement:** Please note that the 24Six Solo3 does not include a subscription to 24Six. A separate 24Six subscription is required to access content.
4. **Downloading Content:** Once your account is set up and subscribed via the website, you can download music, stories, and shiurim to your Solo3 device.

OPERATING INSTRUCTIONS

Basic Navigation

The Solo3 features an HD display for easy navigation. Use the touch screen to select options such as Playlists, Artists, Albums, Songs, Torah, Downloads, Stories, and Recent.

Listening to Music, Stories, and Shiurim

- **Playing Content:** Select your desired song, story, or shiur from the available categories. Tap to play.
- **Creating Playlists:** Organize your favorite content by creating custom playlists.
- **New Releases:** Stay updated with the latest content by checking the "Featured New Releases" section.

Advanced Features (Powered by Chein)

- **SearchSense:** Use the search function to find specific content. SearchSense intelligently anticipates your needs, factoring in spelling mistakes, differences, trending songs, new releases, popular artists, and your personal listening and search history. You can even search by lyrics.
- **Autoplay:** Enable Autoplay for continuous listening. The device will learn your preferences in real-time and recommend the perfect next song based on your listening history and taste.
- **Your Daily Mix:** Access your personalized daily playlist, generated by Chein based on how you like to listen to music and the time of day. This feature adapts to your routine, providing suitable music for activities like exercise or relaxation.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid abrasive materials or harsh chemicals.
- **Screen Protection:** Apply the provided plastic screen protector to help prevent scratches on the HD display.
- **Storage:** Store the Solo3 in a cool, dry place away from direct sunlight and extreme temperatures to ensure longevity.
- **Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Charge it regularly using the provided charger and USB-C cable.

TROUBLESHOOTING

Problem	Possible Solution
Device not turning on	Ensure the device is fully charged. Connect to charger and wait a few minutes before attempting to power on.
Cannot access content	Verify your 24Six subscription is active on www.24Six.app . Ensure content has been downloaded to the device.
Slow performance	Restart the device. Ensure there is sufficient free memory.
Search results are not accurate	Ensure your device is connected to Wi-Fi for optimal SearchSense performance. Check your search terms for accuracy.

PRODUCT IMAGES



Image 1: The 24Six Solo3 MP3 Player lineup, showcasing the available colors including purple, pink, green, black, and blue, with the blue model displaying the main interface.





Image 2: A side profile view of the pink 24Six Solo3 MP3 Player, highlighting its slim design and physical control buttons.

OFFICIAL PRODUCT VIDEOS

Video 1: An introductory video showcasing the 24Six Solo3 MP3 Player and its Chein Musical Intelligence features, including its design, X3 chip, SearchSense, Autoplay, and Daily Mix functionalities.

SPECIFICATIONS

Specification	Detail
Product Dimensions	9.1 x 9.1 x 9.1 inches
Item Weight	11.3 ounces
Manufacturer	24Six
ASIN	B0DL86RCPF
Item Model Number	24SIXSOLO3
Customer Reviews	4.1 out of 5 stars (60 ratings)
Best Sellers Rank	#47,027 in Electronics, #264 in MP3 & MP4 Players
Date First Available	November 13, 2024
Brand	24Six
Model Name	24Six Solo3 Mp3 Player - Jewish Music, Children's Stories and Torah Shiurim Powered by Chein (Music Intelligence)
Special Feature	Built-In Speaker, Touch Screen
Connectivity Technology	Aux, Bluetooth, Wi-Fi
Memory Storage Capacity	64 GB

Specification	Detail
Color	Pink
Screen Size	3.99 Inches
Compatible Devices	Headphone, Speaker
Included Components	Case, Charger, Plastic Screen Protector, USB-C Cable, Wired Earbuds
Display Technology	LCD



WARRANTY AND SUPPORT

For detailed warranty information, please refer to the documentation included with your purchase or visit the official 24Six website. Support for account management, profiles, and content filters is available at www.24Six.app.

Please note that there is no upgrade, trade-in, or device swapping program. Each device is sold separately.

© 2024 24Six. All rights reserved.

Related Documents - 24SIXSOLO3

	<p>24Six Solo 4 Quick Guide: Your MP3 Music Player</p> <p>Get started with your 24Six Solo 4 MP3 music player. This quick guide covers specifications, device overview, setup, 24SixOS features, automatic updates, and FCC compliance information.</p>
	<p>24Six Solo Quick Guide - MP3 Player Setup and Features</p> <p>Concise guide to setting up and using the 24Six Solo MP3 Music Player, covering specifications, device overview, operating system, and FCC compliance.</p>



[24Six FamilyPlayer Quick Guide](#)

A quick guide to setting up and using the 24Six FamilyPlayer, a device dedicated to playing 24Six content with customizable user profiles.