

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [CHUWELL](#) /

› [CHUWELL Farmhouse Storage Cabinet, 31.5" Buffet Cabinet with 2 Doors and Adjustable Shelf - Instruction Manual](#)

CHUWELL 2 doors-1 cabinet

CHUWELL Farmhouse Storage Cabinet - Model: 2 doors-1 cabinet

Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your CHUWELL Farmhouse Storage Cabinet. Please read all instructions carefully before assembly and use to ensure safe and proper functionality.

The CHUWELL Farmhouse Storage Cabinet, model 2 doors-1 cabinet, is a versatile furniture piece designed to offer both aesthetic appeal and practical storage solutions for various rooms, including kitchens, dining rooms, and living rooms. It features a modern farmhouse design with grille-stripped doors and an adjustable interior shelf.

SAFETY INFORMATION

WARNING:

- Always secure the cabinet to the wall using the provided anti-tipping device to prevent tipping, especially in households with children or pets.
- Do not overload the cabinet, as this may compromise stability and lead to tipping.
- Keep the cabinet away from direct heat sources, such as radiators or fireplaces, to prevent warping or damage to the material.
- Ensure all screws and fasteners are tightened securely during assembly and periodically check for tightness.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. Refer to the assembly video for a visual guide to components.

Your browser does not support the video tag.

Video: Assembly overview and component identification for the CHUWELL Storage Cabinet. This video demonstrates the step-by-step assembly process and identifies the various parts required.

The package includes all necessary hardware and panels for assembly. Each part is individually packaged and labeled for ease of identification.

ASSEMBLY INSTRUCTIONS

Assembly is required for this cabinet. Clear instructions are provided with the product, and all parts are individually packaged and labeled to make installation easier. It is recommended to assemble the cabinet on a soft, clean surface to prevent scratches.

Step 1: Prepare the Base and Side Panels

Attach the cam lock screws to the designated holes on the base panel and side panels. Ensure they are securely fastened.



Image: Illustration of cam lock screw insertion into a panel, a crucial first step in securing the cabinet's structure.

Step 2: Connect Panels

Join the side panels to the base and top panels using the cam locks. Rotate the cam locks clockwise to secure the connection. Repeat for all main structural panels.



Image: Visual guide on how to connect cabinet panels using cam locks, ensuring a stable frame.

Step 3: Install Back Panel and Legs

Slide the back panel into the grooves and secure it with small nails or screws. Attach the solid wood legs to the bottom of the cabinet using the provided screws.



Image: Detail of the solid wood legs, highlighting their sturdy construction and attachment points.

Step 4: Attach Doors and Hinges

Mount the hinges to the cabinet doors and then attach the doors to the main cabinet frame. Ensure the doors open and close smoothly.



Image: Detailed view of the door panel adjustment screws on the hinges, allowing for precise alignment.

Step 5: Install Adjustable Shelf

Insert the shelf pins into the desired height holes inside the cabinet. Place the adjustable shelf on top of the pins. The shelf can be repositioned as needed.

Detail-Oriented Design



Solid Wood Leg



Sturdy Hinges



Slatted Door Design



Adjustable Shelves

Image: The interior of the cabinet with an adjustable shelf, demonstrating its flexible storage capabilities.

Step 6: Secure Anti-Tipping Device

Attach the anti-tipping device to the back of the cabinet and then to a wall stud using the provided hardware. This step is crucial for safety.



Image: A detailed view of the anti-tipping device, showing how it secures the cabinet to the wall for enhanced safety.

PRODUCT FEATURES

- **Modern Farmhouse Design:** Grille-stripped doors blend rustic charm with modern elegance, making it a stylish addition to any room.
- **Spacious and Flexible Storage:** Features two compartments with an inner shelf adjustable in height to accommodate various item sizes. The wide tabletop provides space for display or appliances.
- **Versatile Placement:** Suitable for use as a sideboard in the dining room, a TV table in the living room, or a storage organizer in an office. Multiple units can be combined for extended storage.
- **Durable and Stable Construction:** Made of high-grade engineered wood with a strong weight capacity. Includes an anti-tipping device for safety. The slatted door design ensures ventilation.

PRODUCT SIZE



cabinet 175 lbs | shelf 66 lbs

Image: Product dimensions, showing the overall size and internal measurements of the cabinet.

Ample Storage Space



Image: Three cabinets arranged together, showcasing their ample storage capacity for kitchenware, pantry items, and decorative objects.

OPERATING INSTRUCTIONS

Opening and Closing Doors

The cabinet features two doors that open outwards. Gently pull the door to open and push to close. Ensure no items obstruct the door's path.

Adjusting Shelves

The inner shelf is adjustable. To change its height, remove all items from the shelf. Lift the shelf slightly and remove the four shelf pins from their current holes. Reinsert the pins into the desired height holes, ensuring they are level, then place the shelf back onto the pins.

Your browser does not support the video tag.

Video: Demonstration of the adjustable shelves feature, showing how to reposition the shelf to different heights within the cabinet.

MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals or

abrasive cleaners, as they may damage the finish.

- **Dusting:** Regularly dust the cabinet with a dry, soft cloth to prevent dust buildup.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Tighten if necessary.

Sturdy & Convenient

Anti-Tipping Device
Easy to Clean



Image: A robot vacuum operating beneath the cabinet, illustrating the clearance for easy cleaning underneath the unit.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Doors do not align properly.	Hinges are not adjusted correctly.	Adjust the screws on the hinges (refer to the "Door Panel Adjustment" image in Assembly Instructions) to align the doors. There are typically three adjustment screws for depth, height, and side-to-side movement.
Cabinet feels unstable or wobbly.	Screws are loose; anti-tipping device not installed or improperly secured.	Ensure all assembly screws are tightened. Verify that the anti-tipping device is correctly installed and securely fastened to a wall stud.

Problem	Possible Cause	Solution
Shelf does not sit level.	Shelf pins are not inserted evenly.	Remove the shelf and reinsert the shelf pins, ensuring they are fully seated and at the same height on both sides.

SPECIFICATIONS

- **Brand:** CHUWELL
- **Model:** 2 doors-1 cabinet
- **Color:** Black
- **Material:** Engineered Wood
- **Product Dimensions:** 31.5"D x 15.8"W x 30.7"H
- **Item Weight:** 46.3 pounds
- **Number of Doors:** 2
- **Number of Shelves:** 1 (adjustable)
- **Mounting Type:** Floor Mount
- **Assembly Required:** Yes
- **Special Feature:** Anti-tipping device, Slatted door design for ventilation

WARRANTY AND SUPPORT

For any problems with assembly, missing parts, or general inquiries, please contact CHUWELL customer support. We are committed to providing a solution within 24 hours.

Please refer to your purchase documentation for specific warranty details.

Thank you for choosing CHUWELL.