

[Manuals.plus](#) /

› [BlitzRock](#) /

› BlitzRock CT3 Pro Open Ear Headphones User Manual

BlitzRock CT3 Pro

BlitzRock CT3 Pro Open Ear Headphones User Manual

Model: CT3 Pro

INTRODUCTION

Welcome to the BlitzRock CT3 Pro Open Ear Headphones user manual. This guide provides detailed instructions on how to set up, operate, and maintain your new headphones. The BlitzRock CT3 Pro offers a unique open-ear design for comfort and situational awareness, combined with rich, balanced sound and clear call quality.

PACKAGE CONTENTS

Before you begin, please ensure all items are present in the package:

- BlitzRock CT3 Pro Open Ear Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual (this document)



Image: The BlitzRock CT3 Pro open ear headphones, consisting of two earbuds with earhooks, and their compact black charging case.

PRODUCT OVERVIEW

The BlitzRock CT3 Pro headphones are designed for comfort and high-quality audio. Key features include:

- **Open-Ear Design:** Allows you to hear your surroundings while enjoying audio.
- **Rich, Balanced Sound:** Features Pure HiFi and LISO balance sound technology for detailed audio.
- **AI ENC 4-Mics:** Ensures crystal-clear calls by filtering background noise.
- **Long Playtime:** Up to 40 hours of total battery life with the charging case.
- **IPX5 SweatSafe:** Provides protection against sweat and light rain.
- **App Control:** Customize EQ settings and touch controls via the BlitzRock App.

Premium Stereo, Rich Details

True HiFi sound deliver **4X** more crystal-clear and rich detail sound.



Image: An exploded view diagram of the BlitzRock CT3 Pro earbud, highlighting the Bluetooth 5.4 chip, 12mm Rubidium Drivers, and PureEcho technology for premium stereo sound.

Zero Pressure Design

Gravity balanced allows for painless wearing.



Skin-soft liquid silicone



Flexible memory
titanium wire



0.3oz Ultra Light

Image: A visual explanation of the Zero Pressure Design, showing the skin-soft liquid silicone, flexible memory titanium wire, and the ultra-light 0.3oz weight of the earbud, designed for comfortable wear.

SETUP

1. Charging the Headphones and Case

Before first use, fully charge both the headphones and the charging case.

1. Place the CT3 Pro earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and the other end to a USB power source (e.g., computer, wall adapter).
3. The indicator light on the charging case will show charging status. Once fully charged, the light will indicate completion (refer to specific light patterns in the quick start guide if available).

A full charge provides up to 8 hours of listening time for the earbuds, and the charging case extends this to a total of 40 hours.



Image: An illustration detailing the battery life of the BlitzRock CT3 Pro, showing 8 hours on a single charge and a total of 40 hours with the charging case.

2. Pairing with Your Device

The CT3 Pro headphones use Bluetooth 5.4 for a stable connection.

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth on.
3. Search for available devices and select "BlitzRock CT3 Pro" from the list.
4. Once connected, you will hear an audio prompt, and the indicator light on the earbuds will change (refer to specific light patterns in the quick start guide if available).

The headphones will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Wearing the Headphones

The CT3 Pro features an ergonomic earhook design for a secure and comfortable fit.

1. Identify the Left (L) and Right (R) earbuds.
2. Gently hook the earbud over your ear, ensuring the speaker part is positioned correctly near your ear canal without entering it, thanks to the open-ear design.
3. Adjust the earhook for a snug and comfortable fit.

Simple Touch, Customizable Touch Keys

Touch keys can be customized on the APP "KEY SETTING".

 L/R Single tap	 Four tap Turn on game mode	
 L/R Single tap	 L/R Triple Click	 L/R Hold Volume
 L Double tap Previous song	 R Double tap Next song	




Image: A three-step visual guide demonstrating the easy and quick way to wear the BlitzRock CT3 Pro headphones, showing how to position the earhook and earbud correctly.

Touch Controls

The CT3 Pro earbuds feature intuitive touch controls. These can be customized via the BlitzRock App.

Action	Function
Single Tap (L/R)	Play/Pause music, Answer/End call
Double Tap (Left)	Previous song
Double Tap (Right)	Next song
Triple Tap (L/R)	Activate Voice Assistant
Quadruple Tap (L/R)	Turn on/off Game Mode
Long Press (Left)	Volume Decrease
Long Press (Right)	Volume Increase



Image: A visual representation of the touch controls on the BlitzRock CT3 Pro earbuds, alongside screenshots of the BlitzRock app showing options for key settings and EQ.

BlitzRock App Control

For enhanced personalization, download the official BlitzRock App from your device's app store. The app allows you to:

- Customize EQ settings (preset and custom modes).
- Adjust touch key functions.
- Check battery levels.
- Access additional features and firmware updates.

Enhanced Personalization Through Apps

Enjoy a variety of sound effects and customizable touch keys.



Image: Multiple smartphone screens displaying the BlitzRock app interface, showing options for key settings, sound tuning, and preset/custom EQ adjustments.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your BlitzRock CT3 Pro headphones.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in their charging case to protect them and keep them charged.
- **Water Resistance:** The headphones are IPX5 SweatSafe, meaning they are resistant to sweat and light splashes. Do not submerge them in water or expose them to heavy rain. Dry them thoroughly if they get wet.
- **Temperature:** Avoid exposing the headphones to extreme temperatures (hot or cold) or high humidity.

TROUBLESHOOTING

If you encounter issues with your BlitzRock CT3 Pro headphones, try the following solutions:

- **No Sound:**
 - Ensure the headphones are charged.
 - Check if they are properly paired with your device.
 - Adjust the volume on both the headphones and your device.
 - Try unpairing and re-pairing the headphones.
- **Cannot Pair:**
 - Ensure Bluetooth is enabled on your device.
 - Make sure the headphones are in pairing mode (open the case).
 - Move the headphones closer to your device (within 33 feet).
 - Turn off Bluetooth on other nearby devices that might be trying to connect.
 - Restart your device and try pairing again.
- **Poor Call Quality:**
 - Ensure the microphones are not obstructed.
 - Check your network signal strength.
 - Move to a quieter environment if there is excessive background noise.
- **Earbuds Not Charging:**
 - Ensure the earbuds are correctly seated in the charging case.
 - Check the charging cable and power source.
 - Clean the charging contacts on both the earbuds and the case with a dry cotton swab.

SPECIFICATIONS

Feature	Detail
Model Name	CT3 Pro
Connectivity Technology	Bluetooth 5.4
Wireless Communication Technology	Bluetooth 5.4
Included Components	Open Ear Earbuds CT3 Pro, Charging Case, USB Cable, User Manual
Material	Silicone
Control Type	APP and Touch Control
Item Weight	0.17 Kilograms (6 ounces)
Water Resistance Level	IPX5 SweatSafe (Waterproof)
Frequency Range	20 Hz - 20,000 Hz
Bluetooth Range	33 Feet
Battery Life (Earbuds)	Up to 8 hours (single charge)

Feature	Detail
Total Battery Life (with Case)	Up to 40 hours
Earpiece Shape	Earhooks
Manufacturer	BlitzRock

WARRANTY AND SUPPORT

BlitzRock products are designed for reliability and performance. For warranty information and customer support, please refer to the official BlitzRock website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, visit the [BlitzRock Store on Amazon](#).

© 2024 BlitzRock. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DL9HY1F4>

More documents and user manuals: <https://manuals.plus/>