



Manuals.plus /

› CAPXSNOB /

› Warriors1 5-in-1 Capsule Coffee Machine User Manual

CAPXSNOB SV835L EU (CE)

Warriors1 5-in-1 Capsule Coffee Machine User Manual

Model: SV835L EU (CE) | Brand: CAPXSNOB

INTRODUCTION

Thank you for choosing the Warriors1 5-in-1 Capsule Coffee Machine. This versatile appliance is designed to bring a wide variety of coffee experiences to your home or office, compatible with Nespresso Original, Lavazza A Modo Mio, Dolce Gusto, FAP Espresso Point capsules, and ground coffee. Please read this manual carefully before first use to ensure proper operation, maintenance, and to fully enjoy your coffee machine.



The Warriors1 5-in-1 Capsule Coffee Machine, showcasing its sleek design and compatibility with multiple coffee formats.

PRODUCT COMPONENTS

Familiarize yourself with the main components of your coffee machine:



Detailed view of the coffee machine components:

1. Removable 820 ml Water Tank
2. Coffee Spoon
3. Drip Tray
4. Ground Coffee Adapter
5. Adapter for Lavazza Point Pod
6. Adapter for Nespresso Original
7. Adapter for Dolce Gusto Capsules
8. Dosing Funnel for Ground Coffee

SETUP AND FIRST USE

Unboxing and Initial Cleaning

1. Remove all packaging materials and stickers from the machine.
2. Wash the water tank, drip tray, and all adapters (for capsules and ground coffee) with warm, soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the machine with a damp cloth.

Filling the Water Tank

1. Remove the water tank from the back of the machine.
2. Fill the tank with fresh, cold drinking water up to the MAX level indicator. Do not exceed the MAX line.
3. Place the water tank back onto the machine, ensuring it is securely seated.

Priming the Machine (First Use)

Before brewing your first coffee, it is essential to prime the machine to ensure water flows correctly and to clean the internal system.

1. Ensure the water tank is filled.
2. Place a large cup or container under the coffee outlet.
3. Press any brew button (small, medium, or large cup) without inserting any capsule or ground coffee adapter.

4. Allow water to flow through until the tank is almost empty. Repeat this process 2-3 times.
5. The machine is now primed and ready for use.

OPERATING INSTRUCTIONS

General Operation

1. Plug the machine into a power outlet. The indicator lights will flash as the machine heats up.
2. The machine is ready when the indicator lights stop flashing and remain solid. This typically takes about 35 seconds.

Using Coffee Capsules (Nespresso, Dolce Gusto, Lavazza A Modo Mio, FAP Espresso Point)

Simplifiez votre routine matinale et profitez des arômes et saveurs en deux étapes

Système de Levée Hydraulique Automatique : Design sans poignée, sur simple clic totalement automatique, évite les problèmes tels que les problèmes de pression, les difficultés de réinitialisation et la rupture de la poignée

Système de Détection Intelligent : Si l'adaptateur est inséré de manière incorrecte, la machine ne prépare pas de café, ce qui évite les fuites et le gaspillage des capsules

Étape 1



Placez la capsule dans l'adaptateur et appuyez fermement

Étape 2



Insérez l'adaptateur et sélectionnez la taille de tasse souhaitée pour l'infusion

Étape 1



Insérez la capsule et appuyez

Étape 2



Mettez le couvercle et verrouillez la poignée

Étape 3



Sélectionnez le volume et appuyez sur "Infuser"

Simplified brewing routine: Step 1 - Place the capsule in the adapter and close firmly. Step 2 - Insert the adapter and select the desired cup size for brewing.

1. Select the appropriate adapter for your capsule type (Nespresso, Dolce Gusto, Lavazza A Modo Mio, or FAP Espresso

Point).

2. Insert the capsule into its designated adapter. Ensure it is seated correctly.
3. Close the adapter firmly. The machine uses hydraulic technology for easy locking and unlocking.
4. Insert the loaded adapter into the machine's brewing chamber.
5. Place your cup on the drip tray.
6. Press one of the three brew buttons (small, medium, or large cup) to start brewing.
7. The machine will automatically stop when the selected volume is dispensed.

Using Ground Coffee



How to prepare ground coffee: Step 1 - Insert the dosing funnel into the adapter. Step 2 - Fill with 7-10g of ground coffee. Step 3 - Press with the tamper. Step 4 - Close the lid. Step 5 - Insert into the machine. Step 6 - Brew with one touch.

1. Use the Ground Coffee Adapter.
2. Insert the dosing funnel into the adapter.
3. Add 7-10 grams of your preferred ground coffee into the adapter.
4. Use the tamper to gently press the coffee grounds.
5. Close the lid of the ground coffee adapter firmly.
6. Insert the loaded ground coffee adapter into the machine's brewing chamber.
7. Place your cup on the drip tray.
8. Press one of the three brew buttons to start brewing.

Customizing Volume and Temperature

Réglages personnalisables du volume de café et de la température



40 ml



100 ml



150 ml

Réglages de Volume

Appuyez et maintenez le bouton "Grande Tasse" pendant 5 s, relâchez le bouton dès que l'infusion commence. Appuyez à nouveau sur le bouton pour arrêter lorsque le volume souhaité est atteint. Le réglage du volume est terminé et enregistré.



Faible



Moyen



Élevé

Réglages de Température

Appuyez et maintenez les boutons de la tasse moyenne/grande jusqu'à ce que la lumière verte clignote trois fois pour entrer dans les paramètres de TEMP.

- Appuyez sur le bouton de la petite tasse pour une TEMP basse
 - Appuyez sur le bouton de la tasse moyenne pour une TEMP moyenne
 - Appuyez sur le bouton de la grande tasse pour une TEMP élevée
- Attendez 5 s pour activer le réglage pour les futurs brassages



Customizable coffee volume and temperature settings.

Volume Settings:

- The machine offers preset volumes of 40 ml, 100 ml, and 150 ml.
- To customize a volume: Press and hold the desired brew button (e.g., "Large Cup") for 5 seconds. Release the button once brewing begins. Press the button again to stop when your desired volume is reached. The new volume setting will be saved.

Temperature Settings:

- The machine offers three adjustable temperatures: 88°C (for milky beverages), 92°C (for espresso), and 96°C (for cold environments).
- To enter temperature settings: Press and hold the medium/large cup buttons simultaneously until the green light flashes three times.
- Press the small cup button for a low temperature (88°C).
- Press the medium cup button for a medium temperature (92°C).
- Press the large cup button for a high temperature (96°C).

- Wait 5 seconds for the setting to activate for future brews.

MAINTENANCE

Cleaning the Machine

1. **Drip Tray:** Empty and clean the drip tray regularly, especially when the indicator floats up.
2. **Water Tank:** Clean the water tank weekly with warm, soapy water. Rinse thoroughly.
3. **Adapters:** After each use, remove and rinse the used adapter under running water.
4. **Automatic Cleaning:** The machine has an automatic cleaning function. Refer to the descaling section for a more thorough cleaning process.

Maintenance Tips for Ground Coffee Adapter

CONSIGLI DI MANUTENZIONE PER L'ADATTATORE PER CAFFÈ MACINATO

Automatico: Inserisci l'adattatore vuoto nella macchina e risciacqualo

Manuale: Pulisci i fori del filtro superiore e i filtri in acciaio inox inferiori per mantenere un flusso regolare di caffè, garantendo un'estrazione ottimale



Maintenance tips for the ground coffee adapter: Disassembly, Rinsing, and Reassembly.

- **Automatic:** Insert the empty adapter into the machine and run a rinse cycle.
- **Manual:** Clean the holes of the upper filter and the stainless steel filters below to maintain regular coffee flow and ensure optimal extraction. Follow the diagram for disassembly, rinsing, and reassembly.

Descaling

The Warriors1 SV835L machine features a descaling alert system. After approximately 200 extractions, three green lights will flash simultaneously, indicating that descaling is required.

1. **Prepare Descaling Solution:** Mix a descaling solution according to the manufacturer's instructions (or use white vinegar diluted with water).
2. **Fill Water Tank:** Pour the descaling solution into the water tank.
3. **Start Descaling Program:** Place a large container under the coffee outlet. Activate the descaling program (refer to your machine's specific button combination for descaling, usually by holding down certain buttons for several seconds).
4. **Rinse:** After the descaling cycle is complete, rinse the water tank thoroughly and fill it with fresh water. Run 2-3 full cycles with fresh water to remove any residual descaling solution.
5. The descaling alert will reset once the program is completed. Regular descaling ensures optimal performance and prolongs the machine's lifespan.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No water flow / Coffee not dispensing	Water tank empty; Machine not primed; Clogged nozzle; Descaling needed; Capsule inserted incorrectly.	Fill water tank; Prime the machine; Clean the nozzle; Perform descaling; Ensure capsule/adapter is correctly inserted and locked.
Coffee is cold or not hot enough	Temperature setting too low; Machine not fully heated.	Adjust temperature setting to a higher level (92°C or 96°C); Wait for indicator lights to be solid before brewing.
Water leaking from machine	Water tank not properly seated; Drip tray full; Adapter not correctly closed.	Ensure water tank is securely in place; Empty drip tray; Re-insert and firmly close the capsule/ground coffee adapter.
Descaling alert (3 green lights flashing)	Machine requires descaling.	Perform a descaling cycle as described in the Maintenance section.
Coffee tastes weak or watery	Incorrect volume setting; Old/stale coffee; Adapter/filter clogged.	Adjust volume setting to a smaller cup size; Use fresh coffee; Clean adapters and filters thoroughly.

SPECIFICATIONS

Feature	Specification
Brand	CAPXSNOB
Model Number	SV835L EU (CE)
Color	White
Dimensions (L x W x H)	28.5 x 13.7 x 27.5 cm
Weight	2.5 Kilograms
Water Tank Capacity	800 Milliliters
Power	1100 Watts
Voltage	230 Volts
Pump Pressure	20 Bar
Special Features	Automatic cleaning function, One-cup brewing, Adjustable brew strength, Programmable, Removable reservoir, Automatic shut-off.
Compatibility	Nespresso Original, Lavazza A Modo Mio, Dolce Gusto, FAP Espresso Point, Ground Coffee

WARRANTY AND SUPPORT

Your Warriors1 coffee machine comes with a 2-year limited manufacturer's warranty. Additionally, you may be eligible for

a 60-day money-back guarantee under certain conditions. By registering your product on our official website, you will also benefit from a 2-year replacement service.

For any questions, troubleshooting assistance, or warranty claims, please contact CAPXSNOB customer support through the official website or the contact information provided with your purchase.