

[Manuals.plus](#) /

› [HZD](#) /

› HZD Wireless Bluetooth Keyboard Instruction Manual

HZD B0DL9VFRND

HZD Wireless Bluetooth Keyboard Instruction Manual

Model: B0DL9VFRND

INTRODUCTION

Thank you for choosing the HZD Wireless Bluetooth Keyboard. This ultra-thin, portable keyboard is designed for seamless connectivity with a wide range of devices, offering a comfortable and efficient typing experience. Please read this manual carefully to ensure proper use and to maximize the lifespan of your device.



The HZD Wireless Bluetooth Keyboard is designed to be ultra-thin and lightweight, making it easy to carry in a backpack or bag for on-the-go use.

SETUP

1. Powering On/Off

Locate the ON/OFF switch on the keyboard. Slide the switch to the 'ON' position to power on the keyboard. Slide it to 'OFF' to power it down when not in use.

2. Bluetooth Pairing


Follow these steps to connect your keyboard via Bluetooth:

1. Turn the keyboard's power switch to the 'ON' position.
2. Press the 'CONNECT' button on the keyboard for 3 seconds. The Bluetooth indicator light will start blinking, indicating it is in pairing mode.
3. On your device (tablet, phone, PC), go to Bluetooth settings and search for available devices.
4. Select 'Bluetooth Keyboard' from the list of found devices to complete the pairing process.

Istruzioni per la connessione



1 Ruotare l'interruttore su ON.



2 Premere "CONNECT" per 3 secondi. **3** Accendi il Bluetooth, cerca la "Tastiera Bluetooth" e collegala.

Visual guide for Bluetooth connection: Power on, activate pairing mode, then connect via your device's Bluetooth settings.

3. System Switching

The keyboard supports Android, Windows, and iOS operating systems. To ensure correct key functionality, switch to the corresponding system mode:

- For Android devices: Press **Fn + Android**
- For Windows devices: Press **Fn + Windows**
- For iOS devices: Press **Fn + iOS**

Note: This keyboard is not compatible with Mac systems.



Use the Fn key in combination with the designated system key (Android, Windows, or iOS) to optimize keyboard functions for your device.

4. Language Switching

To change the input language on your connected device, use the following key combinations:

- For Android devices: Press **Shift + Space**
- For iOS devices: Press **Ctrl + Space**
- For Windows devices: Press **Win + Space**, **Shift + Alt**, or **Ctrl + Shift**

The Shift key is often used in combination with other keys to change the input language on various operating systems.

5. Charging the Keyboard

The keyboard features a built-in rechargeable lithium battery. Use the included USB charging cable to charge the device.

- **Battery Capacity:** 220 mAh
- **Charging Time:** Approximately 2 hours
- **Continuous Use:** Up to 30 days (based on typical usage)
- **Standby Time:** Up to 130 days

A flashing indicator light typically signifies a low battery. Connect the keyboard to a power source using the USB cable to charge.



Capacità della batteria al litio:
220 mAh



Tempo di ricarica: **2 ore**
Tempo di standby **>130 giorni**



Connect the keyboard via the USB port for charging. The image highlights the battery specifications and charging duration.

OPERATING INSTRUCTIONS

1. Key Features and Typing Experience

The HZD keyboard is equipped with stable scissor-structure feet under each key. This design ensures a smooth, responsive, and quiet typing experience, reducing noise and providing comfortable tactile feedback.

Tasti resistenti e silenziosi

Questi tasti sono compatti e dotati di interruttori a forbice per una digitazione silenziosa e confortevole.




Clic sensibile



Interruttore a forbice



Tasti silenziosi



The scissor-switch mechanism provides a sensitive, quiet, and comfortable typing experience.

2. Multimedia and Function Keys

The keyboard includes 13 multifunction keys (F1-F12, Esc) that allow for quicker access to various functions, improving work efficiency. These functions are typically accessed by pressing the **Fn** key in combination with the desired function key.

Function Key Overview

Key Combination	Function
Esc	Return to Home Page
F1	Search
F2	Select All
F3	Copy
F4	Paste
F5	Cut

Key Combination	Function
F6	Previous Song
F7	Play/Pause
F8	Next Song
F9	Volume Down
F10	Volume Up
F11	Brightness Down
F12	Brightness Up
Canc	Screen Lock

Design ultrasottile personalizzato

Tastiera wireless silenziosa





Nota: i sistemi MAC non sono supportati.

The keyboard features dedicated function keys for quick access to common tasks, enhancing productivity.

3. Wide Compatibility

The HZD Wireless Bluetooth Keyboard is designed for broad compatibility with various devices and operating systems, excluding Mac systems.

- **Supported Devices:** Tablets, Laptops, Smartphones, Smart TVs, PCs
- **Supported Operating Systems:** iOS, Android, Windows
- **Wireless Range:** Up to 10 meters (33 feet)

Ampia gamma di compatibilità



The keyboard offers broad compatibility with Windows, Android, and iOS devices, making it versatile for various computing needs.

MAINTENANCE

1. Cleaning

To clean your keyboard, gently wipe the surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the electronic components and finish. Ensure the keyboard is powered off before cleaning.

2. Battery Care

To prolong battery life:

- Avoid fully discharging the battery frequently.
- Charge the keyboard regularly, even if not in constant use.
- Store the keyboard in a cool, dry place when not in use for extended periods.

TROUBLESHOOTING

1. Keyboard Not Connecting via Bluetooth

- Ensure the keyboard is powered on and fully charged.
- Make sure the keyboard is in pairing mode (Bluetooth indicator blinking).
- Check that Bluetooth is enabled on your device.
- Try unpairing and re-pairing the keyboard from your device's Bluetooth settings.
- Ensure your device is within the 10-meter wireless range.

2. Incorrect Characters or Symbols Appearing

- Verify that you have switched the keyboard to the correct operating system mode (Fn + Android/Windows/iOS) for your device.
- Confirm that the language settings on your device match the physical layout of the keyboard (Italian QWERTY). Adjust language settings on your device if necessary.
- Use the appropriate language switching shortcuts for your operating system (e.g., Shift + Space for Android, Ctrl + Space for iOS).


3. Keyboard Not Responding

- Check the battery level and charge the keyboard if necessary.
- Restart the keyboard by turning it off and then on again.
- Restart your connected device.
- If the issue persists, try re-pairing the keyboard.

SPECIFICATIONS

Feature	Detail
Brand	HZD
Model	B0DL9VFRND
Connectivity Technology	Bluetooth
Compatible Devices	Laptops, PCs, Smart TVs, Smartphones, Tablets (iOS, Android, Windows)
Keyboard Description	Tenkeyless
Recommended Use	Mobile computing, Daily use
Special Features	Portable, Rechargeable, Silent
Color	White
Material	Plastic
Battery Type	Lithium (1 battery included)
Power Source	Battery Powered
Keyboard Layout	QWERTY (Italian Layout)
Water Resistance Level	Not water resistant

Feature	Detail
Dimensions (L x W x H)	290mm x 157mm x 5mm (11.4in x 6.2in x 0.2in)



The compact dimensions of the keyboard make it highly portable and suitable for various setups.

WARRANTY INFORMATION

This HZD product is covered by a standard manufacturer's warranty. Please retain your proof of purchase for any warranty claims. For specific details regarding warranty duration and terms, refer to the documentation provided at the time of purchase or contact the seller directly.

CUSTOMER SUPPORT

If you encounter any issues that cannot be resolved using the troubleshooting guide, or if you require further assistance, please contact the seller or HZD customer support. Provide your product model number (B0DL9VFRND) and a detailed description of the problem to facilitate a quicker resolution.

