

G200

Generic G200 Multifunctional Magnetic Bluetooth Speaker User Manual

Model: G200

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Generic G200 Multifunctional Magnetic Bluetooth Speaker. Please read this manual thoroughly before using the product and retain it for future reference.

2. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures or direct sunlight.
- Avoid dropping or subjecting the speaker to strong impacts.
- Keep the speaker away from water and liquids, despite its IPX5 rating, to prevent damage to internal components.
- Do not attempt to disassemble or repair the speaker yourself. Contact qualified service personnel.
- Use only the specified charging voltage (5V).

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Generic G200 Magnetic Bluetooth Speaker
- Charging Cable (USB-C, typically)
- Magnetic Ring (for non-magnetic surfaces)
- User Manual

4. PRODUCT OVERVIEW

The Generic G200 is a compact, portable Bluetooth speaker featuring magnetic attachment capabilities and RGB lighting. It is designed for versatile use with various devices.



Image: The Generic G200 speaker in white, highlighting its compact size and magnetic attachment feature when used with a smartphone.

G200

MULTIFUNCTIONAL SPEAKER

Small size, loud music as you like



Image: The G200 speaker magnetically attached to a smartphone, illustrating its use as a phone stand and speaker combination.

HIGH DEFINITION SOUND QUALITY

40mm high sensitivity assembled unit, clearly displaying sound details



Image: A detailed view of the speaker's internal 40mm dynamic coil, indicating its sound output capabilities.

5. SETUP

5.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the charging cable to the speaker's charging port and the other end to a 5V USB power adapter (not included). The charging indicator light will show charging status and turn off when fully charged.

5.2 Power On/Off

- **Power On:** Press and hold the power button for approximately 3 seconds until you hear an audible prompt and the RGB lights illuminate.
- **Power Off:** Press and hold the power button for approximately 3 seconds until you hear an audible prompt and the lights turn off.

5.3 Bluetooth Pairing (Single Speaker)

1. Ensure the speaker is powered on and in pairing mode (indicated by a flashing light or audible prompt).

2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "G200" from the list.
4. Once connected, you will hear a confirmation sound. The speaker is now ready for audio playback.




Image: The G200 speaker demonstrating compatibility with multiple devices including phones, tablets, laptops, and gaming consoles.

5.4 True Wireless Stereo (TWS) Pairing (Two Speakers)

To achieve a stereo sound experience, you can pair two G200 speakers together:

1. Power on both G200 speakers. Do not connect them to any device via Bluetooth yet.
2. Double-click the power button on one of the speakers. It will automatically search for and pair with the other speaker.
3. Once successfully paired, you will hear a confirmation sound, and the speakers will indicate Left (L) and Right (R) channels.
4. Now, connect your device to one of the paired speakers via Bluetooth as described in section 5.3. Both speakers will play audio in stereo.

PAIRING TWO SPEAKERS

Power on both mini speakers, then double-click on one of the small speaker, then you can pair two speakers together.



True Wireless Pairing

Image: Two G200 speakers configured for True Wireless Stereo (TWS) pairing, showing the left and right channel assignment.

6. OPERATING INSTRUCTIONS

6.1 Audio Playback

- **Play/Pause:** Short press the power button to play or pause audio.
- **Volume Control:** Volume is primarily controlled via your connected device.

6.2 RGB Lighting Effects

The speaker features dynamic RGB lighting. The lighting effects typically cycle automatically. Refer to the product packaging or manufacturer's website for specific controls if available, as the provided information does not detail explicit control methods for the RGB lights.

6.3 Magnetic Attachment

The G200 speaker has a magnetic base allowing it to attach to metal surfaces such as refrigerators, whiteboards, or compatible phone cases. For non-magnetic surfaces, use the included magnetic ring:

1. Clean the desired non-magnetic surface.

2. Peel off the protective film from the adhesive side of the magnetic ring.
3. Firmly press the magnetic ring onto the clean surface and hold for a few seconds to ensure adhesion.
4. Once the magnetic ring is securely attached, you can magnetically attach the G200 speaker to it.

MAGNETIC MINI SPEAKER

Bluetooth 5.3 connectivity ensures a seamless and high-quality audio experience no matter where your are



Image: Examples of the G200 speaker's magnetic attachment feature, demonstrating its versatility for outdoor and everyday use.

Magnetic lock, one-touch fit

The bottom of the speaker has a magnetic function, which can be easily attached to items that support magnetic attraction. It is more convenient for daily use with a magnetic sheet




Image: A visual guide to the magnetic lock system, showing the speaker's magnetic bottom and the optional magnetic ring for extended use.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.

8. TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is fully charged. Press and hold the power button for 3 seconds.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode. Make sure Bluetooth is enabled on your device. Move the speaker closer to your device. Forget "G200" from your device's Bluetooth list and try pairing again.
No sound or low volume.	Increase the volume on both the speaker and your connected device. Ensure the speaker is properly connected via Bluetooth. Check if the audio source is playing.
TWS pairing fails.	Ensure both speakers are powered on and not connected to any other device. Double-click the power button on one speaker to initiate TWS pairing. Ensure speakers are within close proximity.

9. SPECIFICATIONS

Feature	Detail
Model Name	G200
Connectivity	Bluetooth
Speaker Unit	40mm Dynamic Coil
Output Power	3W
Frequency Response Range	250Hz - 15kHz
Battery Life	6-7 hours (playback)
Standby Time	300 hours
Waterproof Rating	IPX5
Dimensions	2.24 x 2.24 x 1.49 inches (5.7 x 5.7 x 3.8 cm)
Weight	75g (2.65 oz)
Control Method	Touch (Power button)

10. WARRANTY AND SUPPORT

This product comes with a limited warranty. For detailed warranty information, please refer to the documentation

included with your purchase or contact the retailer. For technical support or inquiries, please reach out to the manufacturer or your point of purchase.