

[Manuals.plus](#) /

› [Mcbazel](#) /

› Mcbazel Wireless Rechargeable Magnetic LED Strobe Lights (Model MT-led-060062) - Instruction Manual

Mcbazel MT-led-060062

Mcbazel Wireless Rechargeable Magnetic LED Strobe Lights

Model: MT-led-060062

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Mcbazel Wireless Rechargeable Magnetic LED Strobe Lights. These versatile lights are designed for various applications, including vehicles, outdoor activities, and emergency signaling. Please read this manual thoroughly before first use and retain it for future reference.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 4 x LED Strobe Lights
- 1 x Remote Controller
- 4 x Hook and Loop Stickers
- 8 x Rubber Rings
- 2 x USB Charging Cables
- 1 x User Manual

Package Includes

4x

LED Car Flashing
Warning Light

4x

Hook and Loop

8x

Rubber Ring

2x

Charging Cable

1x

Remote Control

1x

User Manual



Figure 1: Package Contents. This image displays all components included in the product package.

SETUP

First Time Use Activation

1. Remove the transparent film from the remote control before use.
2. Charge each light for 5 seconds using the provided USB charging cable, then unplug the cable.
3. Within 1 minute after unplugging, press and hold the "ON" button on the remote control for 2-3 seconds to activate the device.

Important: Do not use fast-charging adapters. Only standard 5V 1A adapters are permitted for charging.

Note for First Time Use

1



Remove the transparent film
from the remote before use

2



Charge each light 5 seconds
then unplug the cable

3



Long press the [ON] button to activate
the light (activation should be complet-
ed within 1 minute after stop charging)

WARNING

- **DEATH:** or serious injury can occur if ingested.
- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **A** swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.
- **KEEP** new and used batteries **OUT OF REACH OF CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body



Figure 2: First Time Use Activation Steps. This diagram visually guides users through the initial setup process.


Installation Methods

The LED strobe lights offer flexible installation options:

- **Magnetic Attachment:** Each light features a strong magnet for easy attachment to any metal surface.
- **Hook and Loop Stickers:** For non-metallic surfaces, use the provided hook and loop stickers. Tear off one sticker, paste it to the light, and paste another to your desired installation location.
- **Rubber Bands:** Utilize the rubber rings to secure the lights around bars or irregular shapes. Tie the band into the light groove, then tie it to the groove on the other side, and fix the strobe light in place.

Two Other Installation Methods

Hook and Loop Sticker



1
Tear off the Hook and Loop




2
Paste one sticker



3
Paste another one sticker to the light on install location

Figure 3: Hook and Loop Installation. This image demonstrates how to use the hook and loop stickers for secure mounting.

Rubber Band



1
Tie the band into



2
Tie to the groove



3
Fix the strobe light the light groove on the other side on install location

Figure 4: Rubber Band Installation. This image illustrates the process of attaching the lights using rubber bands.

Your browser does not support the video tag.

Video 1: How to Use the Product. This video demonstrates the basic usage and installation of the strobe lights.

OPERATING INSTRUCTIONS

Remote Control Functions

The included slim remote control allows for easy adjustment of light settings from a distance (within 8 meters). You can switch colors, change modes, or power the lights on/off with a single click.



Note for First Time Use

01

Remove the transparent film from the remote before use

02

Charge each light 5 seconds then unplug the cable

03

Long press the [ON] button to activate the light (activation should be completed within 1 minute after stop charging)



Figure 5: Wireless Remote Control. This image highlights the remote control and its functionality for changing light settings.

Color and Mode Selection

The lights feature 8 distinct colors (White, Yellow, Ice Blue, Red, Green, Purple, Pink, Blue) and multiple lighting modes. Use the remote to cycle through these options to suit your preference or application.



Figure 6: 8 Light Colors & Multi-Modes. This image demonstrates the range of colors and dynamic lighting effects.

Syncing Multiple Lights

To ensure all 4 units receive the signal simultaneously and operate in sync, press and hold the "ON" button on the remote for 2-3 seconds. A short click may only activate 1-2 units.

Wide Range of Uses



Car



Bike



Motorcycle



Scooters



Camping



Hiking

Figure 7: Syncing All 4 Lights. This image clarifies the correct method for synchronizing multiple lights.

Your browser does not support the video tag.

Video 2: Sync All 4 Lights with One Click! This video demonstrates the process of syncing multiple lights using the remote control.

MAINTENANCE

Charging the Lights

The lights feature a built-in 110mAh rechargeable lithium battery. A single full charge can provide up to 12 hours of illumination. Actual battery life varies based on the selected color mode and brightness level:

- **High Brightness Mode:** Approximately 2-7 hours (applies to white/red/green/blue/yellow/purple/pink/ice blue/8-color auto-cycle).
- **Medium Brightness Mode:** Approximately 4-14 hours.
- **Low Brightness Mode:** Approximately 8-28 hours.

The remote control enters sleep mode after 60 seconds of inactivity to conserve power.



Figure 8: Multi-Mode Runtime Reference. This chart provides estimated battery life based on brightness settings.

Cleaning

To clean the lights, gently wipe them with a soft, damp cloth. Do not use abrasive cleaners or solvents.

TROUBLESHOOTING

Problem	Solution
Strobe light does not turn on via remote control.	Press and hold the "OFF" button on the remote for 10 seconds to perform a reset. A successful reset is confirmed when the device remains off and does not respond after pressing the "ON" button. After a successful reset, press and hold the "ON" button for 2-3 seconds to activate the light.

Problem	Solution
One of the lights is not illuminating.	Try charging the light again for a few minutes, then unplugging and reconnecting the charging cable. This can help to reset the light.
Lights are not syncing properly.	Ensure you are pressing and holding the "ON" button on the remote for 2-3 seconds to sync all units simultaneously. A short click may only activate individual units.

Package Includes

4x LED Light



1x Remote Control



4x Hook and Loop Sticker



8x Rubber Band



1x User Manual



2x Charging Cable



Figure 9: Troubleshooting Guide. This image provides visual context for common issues and their solutions.

SPECIFICATIONS

Feature	Detail
Brand	Mcbazel

Feature	Detail
Model Number	MT-led-060062
Item Dimensions (L x W x H)	5.91 x 4.45 x 0.71 inches
Item Weight	67 Grams
Color	Multicolor (8 colors)
Light Source Type	LED
Voltage	5 Volts (DC)
Connectivity Technology	USB
Water Resistance Level	Waterproof
Includes Remote	Yes
Battery Capacity	110mAh rechargeable lithium battery
Fit Type	Universal Fit
Material Type	Composite

WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For warranty details or technical support, please contact Mcbazel customer service directly through their official website or the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question