

[Manuals.plus](#) /

› [Tribesigns](#) /

› Tribesigns 14-Tier Shoe Rack Instruction Manual

Tribesigns NY209

Tribesigns 14-Tier Shoe Rack Instruction Manual

Model: NY209

PRODUCT OVERVIEW

The Tribesigns 14-Tier Shoe Rack is a modern, tall shoe organizer designed to provide ample and flexible storage for various types of footwear and other items. Constructed from durable E1-grade MDF with a waterproof, scratch, and wear-resistant white paint finish, this freestanding unit is suitable for entryways, bedrooms, hallways, living rooms, or closets.

It features 23 storage shelves, offering space for slippers, high heels, sneakers, and boots, with additional upper space for decorative items or accessories. An anti-tip safety kit is included to ensure stability, making it safe for households with children and pets.



Figure 1: Fully assembled Tribesigns 14-Tier Shoe Rack.

IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always follow the assembly instructions provided in this manual.
- Assemble this product on a stable, level surface to ensure proper alignment and stability.
- Do not overload shelves beyond their recommended weight limit.
- Keep the product away from direct heat sources, such as radiators or fireplaces.
- Do not place excessively heavy objects on the top shelf to prevent tipping.
- Ensure the anti-tip safety kit is properly installed and secured to a wall, especially in homes with children or pets.
- Keep children and pets away from the product during assembly.
- Always unplug any electronic devices or accessories placed on the rack before cleaning or performing maintenance.



Figure 2: Anti-tip safety kit installation.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware are present and undamaged. Refer to the included assembly instructions for a detailed list of numbered parts.

- Wooden panels (various sizes for shelves and frame)
- Assembly hardware (screws, dowels, cam locks, cam bolts, etc.)
- Anti-tip safety kit
- Assembly instructions manual



Figure 3: All components laid out for assembly.

ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Each part is numbered for quick and easy identification. It is recommended to have a second person assist with assembly, especially during the final stages, due to the product's weight and size.

Step 1: Unpacking and Preparation

1. Carefully open the packaging and remove all components.
2. Lay out all wooden panels and hardware on a clean, soft surface (e.g., a blanket or the cardboard packaging) to prevent scratches.
3. Identify each part by its corresponding number as indicated in the assembly manual.

Your browser does not support the video tag.

Video 1: Unboxing and laying out components for the 14-Tier Wooden Shoe Rack.

Step 2: Assembling the Side Panels and Shelves

1. Attach the cam bolts and dowels to the designated holes on the side panels.
2. Carefully align and insert the shelves into the side panels, ensuring the cam locks engage properly. Turn the cam locks clockwise to secure the connection.
3. Repeat this process for all sections of the shoe rack, building it section by section.



Figure 4: Assembling the main structure.

Step 3: Connecting Sections and Finalizing

1. Once individual sections are complete, connect them using the provided connectors and hardware.
2. Ensure all connections are tight and secure.
3. Install the anti-tip safety kit by securing one end to the top rear of the shoe rack and the other end to a wall stud using appropriate wall anchors (not always included, check your specific hardware). This is crucial for stability.
4. Apply the included white stickers to cover any visible fasteners for a cleaner appearance.

Note on Assembly: Some users have reported that the instructions might lead to fasteners showing on the front if

followed exactly. Pay close attention to the orientation of panels to ensure the finished side faces outwards and fasteners are concealed where possible.

OPERATING INSTRUCTIONS

The Tribesigns 14-Tier Shoe Rack is designed for versatile storage and organization.

Maximizing Storage Capacity

- **Shoe Storage:** Utilize the 23 open cubbies to store up to 46 pairs of shoes, depending on shoe size and type. The varied shelf heights accommodate different footwear, from slippers and sneakers to high heels and boots.
- **Boot Storage:** The central, taller sections are specifically designed for boots, allowing them to stand upright without creasing.
- **Accessory Storage:** The top surface and some wider cubbies can be used for decorative items, storage boxes, bags, or other accessories, enhancing the rack's functionality as a display shelf.



Figure 5: Dedicated boot storage area.

Placement and Versatility

This freestanding shoe rack is versatile and can be placed in various locations:

- **Entryway/Hallway:** Ideal for organizing shoes near the entrance, keeping your home tidy.
- **Bedroom/Closet:** Provides extensive storage within a bedroom or walk-in closet, complementing existing furniture.
- **Living Room:** Its modern, minimalist design allows it to blend seamlessly as a decorative storage unit.

MAINTENANCE

To ensure the longevity and appearance of your Tribesigns 14-Tier Shoe Rack, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a damp cloth to remove dust and light dirt. For stubborn marks, use a mild, non-abrasive cleaner. Immediately wipe dry with a clean, dry cloth to prevent water damage.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or polishes that may damage the finish.
- **Spills:** Promptly clean up any spills to prevent staining or damage to the wood.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Rack is wobbly or unstable.	Loose connections; uneven assembly surface; anti-tip kit not installed.	Ensure all cam locks and screws are fully tightened. Assemble on a flat, level surface. Install the anti-tip safety kit securely to a wall.
Parts do not align correctly during assembly.	Incorrect orientation of panels; misidentified parts.	Double-check part numbers against the manual. Ensure panels are oriented correctly (e.g., finished edges facing outwards, pre-drilled holes for fasteners on the inside).
Fasteners (screws/cam locks) are visible on the front.	Panels assembled in incorrect orientation.	Disassemble the affected section and reassemble, ensuring the side with pre-drilled holes for cam locks/screws is facing inwards or towards the back. Use provided white stickers to cover any unavoidable visible fasteners.
Missing or damaged parts.	Packaging error or transit damage.	Contact Tribesigns customer service immediately with your purchase details and a list of missing/damaged parts.

SPECIFICATIONS

Feature	Detail
Brand	Tribesigns
Model Name	14-Tier Shoe Rack
Model Number	NY209
Product Dimensions	11.8"D x 47.2"W x 59"H
Item Weight	99.2 Pounds
Material	E1-grade MDF
Finish Type	Varnished (White)
Number of Shelves	25
Special Feature	Heavy Duty, Anti-tip safety kit included
Assembly Required	Yes
Installation Type	Freestanding
Recommended Uses	Shoes, decorative storage display shelf

