

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [VINGLI](#) /

> [VINGLI Wooden Patio Glider \(Model VL-G56000909\) Instruction Manual](#)

VINGLI VL-G56000909

VINGLI Wooden Patio Glider (Model VL-G56000909) Instruction Manual

INTRODUCTION

Thank you for choosing the VINGLI Wooden Patio Glider. This manual provides essential information for the safe assembly, proper operation, and effective maintenance of your new outdoor glider. Please read these instructions thoroughly before assembly and use, and retain them for future reference.

Important Safety Information

- Always assemble with two people to ensure safety and ease of construction.
- Do not exceed the maximum weight capacity of 800 lbs (approximately 363 kg).
- Protect the glider from extreme weather conditions when not in use to prolong its lifespan.
- Ensure all bolts and fasteners are securely tightened before each use.

SETUP AND ASSEMBLY

Assembly of the VINGLI Wooden Patio Glider is designed to be straightforward. Follow the step-by-step instructions provided in the packaging. It is recommended to have two people for installation, which typically takes approximately 45 minutes.

Assembly Steps Overview:

1. Unpack all components and verify against the parts list in your product packaging.
2. Assemble the base frame of the glider, ensuring all connections are secure.
3. Attach the seat and backrest sections to the assembled frame.
4. Install the armrests, which include integrated cup holders.
5. Connect the gliding mechanism components, ensuring smooth movement.
6. Tighten all bolts and fasteners using the provided tools. Double-check all connections for stability.



Figure 1: Product Dimensions Diagram. This image illustrates the overall dimensions of the glider, including its height (35.4 inches), width (48 inches), and depth (30.9 inches), along with seat depth (20 inches) and seat width (42.5 inches).

Dimensions



Load capacity
of 800lbs



weight 43.3LBS



Figure 2: Comfort Seating Experience. This image details the design features contributing to comfort, such as the round-edge armrests, ergonomically designed seat, and high backrest.

Video 1: Wooden Porch Glider Overview. This video provides a general overview of the VINGLI Wooden Patio Glider, showcasing its design and functionality in an outdoor setting.

OPERATING INSTRUCTIONS

The VINGLI Wooden Patio Glider is designed for smooth and gentle back-and-forth motion, providing a relaxing experience. Simply sit on the bench and use your feet to initiate and control the gliding movement.

- **Smooth Gliding:** The glider features a smooth rocking mechanism with durable stainless steel rocking arms for quiet and dependable performance.
- **Cup Holders:** Utilize the convenient cup holders integrated into the armrests to keep your beverages secure while relaxing.
- **Seating Capacity:** The generously widened seat is designed to comfortably accommodate two adults, supporting a combined weight of up to 800 lbs.

Comfort

Seating Experience



Round-edge Armrest



Ergonomic Design Seat



High Backrest

Figure 3: Smooth Rocking System. This image visually represents the gentle gliding motion of the bench, emphasizing its quiet operation.



Figure 4: Glider in Use. This image shows two individuals enjoying the glider, demonstrating the comfortable seating and the use of the cup holders.

MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your VINGLI Wooden Patio Glider.

- **Cleaning:** Wipe down the wooden surfaces regularly with a soft, damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly. Avoid harsh chemicals that may damage the wood finish.
- **Weather Protection:** While crafted from solid fir wood, it is advisable to protect the glider from prolonged exposure to extreme weather conditions (heavy rain, snow, intense sun) by using a furniture cover or storing it indoors during off-seasons.
- **Fastener Check:** Periodically inspect all bolts and screws to ensure they remain tight. Re-tighten as necessary to maintain structural integrity.
- **Wood Treatment:** To maintain the wood's appearance and protect it from the elements, consider applying a wood sealant or stain annually, especially if exposed to harsh weather.

SMOOTH AND GENTLE ROCKING SYSTEM

Glide Back and Forth



 No noise



Figure 5: Solid Wood Material. This image emphasizes the durable solid fir wood construction, which is designed to withstand various weather conditions.

TROUBLESHOOTING

If you encounter any issues with your VINGLI Wooden Patio Glider, refer to the following common solutions:

- **Squeaking during gliding:** Check the gliding mechanism for any loose bolts or obstructions. Apply a silicone-based lubricant to the moving parts if necessary.
- **Unstable or wobbly:** Ensure all assembly bolts are fully tightened. Verify that the glider is placed on a flat, even surface.
- **Difficulty in assembly:** Re-read the assembly instructions carefully. Ensure all parts are correctly oriented before tightening. Contact customer support if you are still experiencing difficulties.

SPECIFICATIONS

Feature	Detail
Brand	VINGLI

Feature	Detail
Model Name	glider-909
Item Model Number	VL-G56000909
Color	Teak
Material	Wood (Solid Fir Wood)
Product Dimensions	30.9"D x 48"W x 35.4"H (78.5 cm D x 121.9 cm W x 89.9 cm H)
Size	3.5 FT
Back Style	High Back
Maximum Weight Recommendation	800 Pounds (363 kg)
Item Weight	37.5 pounds (17 kg)
Indoor/Outdoor Usage	Outdoor
Included Components	Glider

WARRANTY AND SUPPORT

For specific warranty information or technical support, please refer to the documentation included with your purchase or contact VINGLI customer service directly. Keep your proof of purchase for any warranty claims.