

[Manuals.plus](#) /

> [Tajsoon](#) /

> Tajsoon 3 Bag Laundry Sorter Cart Instruction Manual - Model LCR03GYW

Tajsoon LCR03GYW

Tajsoon 3 Bag Laundry Sorter Cart Instruction Manual

MODEL: LCR03GYW

Introduction

Thank you for choosing the Tajsoon 3 Bag Laundry Sorter Cart. This manual provides detailed instructions for the assembly, operation, and maintenance of your new laundry sorter. Designed for efficiency and durability, this cart features a stable frame, large capacity removable bags, and heavy-duty lockable wheels to simplify your laundry routine.



Figure 1: Tajsoon 3 Bag Laundry Sorter Cart in use.

What's in the Box

Please verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Metal Frame Poles (various lengths and shapes, labeled A-G)
- 3 x Removable Laundry Bags (labeled H, I, J)
- 4 x Heavy-Duty Lockable Wheels (labeled L)
- Hooks for Bags (labeled K)
- Assembly Screws and Allen Key (labeled M, N)

TAJSOON



Figure 2: All parts included in the package.

Your browser does not support the video tag.

Video 1: Overview of the Tajsoon 3 Bag Laundry Sorter Cart, demonstrating its features and assembly process.

Setup and Assembly

Follow these steps to assemble your laundry sorter cart. Refer to the included diagrams for visual guidance.

1. **Step 1: Assemble the Base Frame.** Connect the designated metal poles (C, D, M) to form the rectangular base of the cart. Ensure all connections are secure.
2. **Step 2: Attach the Vertical Supports.** Secure the vertical poles (A, B) to the assembled base. These will form the side handles and support the upper bars.
3. **Step 3: Install Horizontal Bars.** Attach the remaining horizontal bars (E, F, G) between the vertical supports. These bars provide stability and support for the laundry bags.
4. **Step 4: Attach Wheels.** Screw the four lockable wheels (L) into the designated holes at the bottom of the base frame. Use the provided wrench to tighten them securely.
5. **Step 5: Hang Laundry Bags.** Attach the hooks (K) to the top edges of the laundry bags (H, I, J). Hang the bags onto the upper horizontal bars of the frame.

6. **Step 6: Final Tightening.** After installation, ensure all screws are tightened for maximum stability.



3 Labels Laundry Sorter Cart



Each bag holds 13 Gal

Holds up to **147**^L
A Total of

Figure 3: Diagram for connecting frame poles.




Figure 4: Diagram for attaching vertical supports and horizontal bars.

Operating Instructions

Using your Tajsoon Laundry Sorter Cart is straightforward:

- **Sorting Laundry:** Utilize the three separate bags to sort your laundry by color (e.g., darks, lights, colors) as you place items into the sorter. Each bag holds up to 13 gallons.
- **Mobility:** The cart is equipped with four 360° rolling wheels for easy movement between rooms.
- **Locking Wheels:** Two of the wheels are lockable. To secure the cart in place, press down on the lever located on the wheel. To unlock, lift the lever.
- **Removing Bags:** Each laundry bag can be individually removed from the frame using its metal handles. This allows for easy transport of sorted laundry to the washing machine.
- **Side Pockets:** Use the integrated side pockets for storing small laundry accessories like detergent pods, dryer sheets, or stain removers.

Thoughtful Design



- Easy to lift and carry



- Foamed handles



- Lockable casters



- 4 Side pockets

Figure 5: Removable laundry bags for easy transport.



Figure 6: Lockable casters for stability.

Features

- **Stable Construction:** The frame is made of cast iron with a metal lacquer finish, providing anti-rust properties and enhanced durability. An extra horizontal bar ensures a solid and stable structure.
- **Large Capacity:** Each heavy-duty bag can hold up to 13 gallons of clothes, totaling 39 gallons (147L) for the entire unit, optimizing laundry sorting efficiency.
- **Removable Bags:** Individual bags can be easily lifted out using their metal handles, simplifying the process of taking laundry to the washing machine.
- **Smooth Mobility:** Equipped with four 360° rotating wheels, two of which are lockable, allowing for effortless movement and secure positioning.
- **Comfortable Handles:** The cart features foam handles for a non-slip and comfortable grip during transport.
- **Convenient Storage:** Four side pockets are included for additional storage of small items.



Figure 7: Foam-padded handles for comfortable grip.

• Product Size

Unit: inch



Figure 8: Convenient side pockets for small items.

Specifications

Product Dimensions	28.62"L x 15.74"W x 32.68"H
Brand	Tajsoon
Color	Beige
Material	Iron, Polyester cloth
Style	Modern
Special Feature	Portable
Shape	Rectangular
Included Components	Wheel
Size	3 Bag

Number of Pieces	1
Capacity	39 Gallons (147L)
Recommended Uses	Sorting, storing, and transporting laundry
Room Type	Laundry Room
Mounting Type	Freestanding
Item Weight	4.4 Kilograms

Maintenance

To ensure the longevity and optimal performance of your laundry sorter cart, follow these maintenance guidelines:

- **Frame Cleaning:** Wipe the metal frame with a soft, damp cloth and mild detergent. Avoid abrasive cleaners that may damage the lacquer finish. Dry thoroughly to prevent rust.
- **Bag Cleaning:** The polyester cloth bags can be spot cleaned with a damp cloth and mild soap. For deeper cleaning, hand wash the bags in cold water and air dry. Do not machine wash or tumble dry to prevent shrinkage or damage.
- **Wheel Maintenance:** Periodically check the wheels for any accumulated lint or debris and remove them to ensure smooth rolling. If necessary, a small amount of silicone lubricant can be applied to the wheel axles.
- **Screw Tightness:** Regularly check all assembly screws and tighten them if they have become loose over time to maintain the cart's stability.

Troubleshooting

If you encounter any issues with your Tajsoon Laundry Sorter Cart, refer to the following common problems and solutions:

- **Cart is unstable or wobbly:**
 - Ensure all screws are securely tightened. Refer to the assembly instructions for correct placement and tightening.
 - Verify that all frame poles are fully inserted into their connectors.
- **Wheels are not rolling smoothly:**
 - Check for any hair, lint, or debris caught in the wheel casters and remove them.
 - Ensure the wheel locks are disengaged.
 - Apply a small amount of lubricant to the wheel axles if friction persists.
- **Laundry bags are sagging:**
 - Ensure the bags are correctly hooked onto the horizontal bars.
 - Avoid overloading the bags beyond their 13-gallon capacity.

Warranty and Support

For warranty information or further assistance, please contact Tajsoon customer support. Keep your

purchase receipt as proof of purchase. Our dedicated support team is available to help with any questions or concerns you may have regarding your product.

Contact Information: Please refer to the contact details provided on the product packaging or the official Tajsoon website.