Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

glaury J701

User Manual for glaury GPS Navigator

Model: J701

1. Introduction

This manual provides comprehensive instructions for the operation and maintenance of your glaury GPS Navigator, Model J701. Please read this manual carefully before using the device to ensure proper functionality and to maximize your navigation experience.

1.1 Package Contents

Upon opening the package, please verify that all the following items are included:

- glaury GPS Navigation Device
- Car Charger
- USB Cable
- Suction Cup Mount
- Back Bracket
- User Manual (this document)



Figure 1.1: Included components of the glaury GPS Navigator package.

2. Setup

2.1 Mounting the Device

The GPS navigator comes with a suction cup mount for easy installation on your vehicle's windshield or dashboard. Ensure the mounting surface is clean and dry before attachment.

1. Attach the back bracket to the rear of the GPS device until it clicks into place.
2. Connect the suction cup mount to the back bracket.
3. Press the suction cup firmly against the desired mounting surface (windshield or dashboard) and flip the lever to secure it.
4. Adjust the angle of the GPS device for optimal viewing without obstructing your driving view.



Figure 2.1: The GPS Navigator securely mounted in a vehicle.

2.2 Powering On and Charging

To power on your GPS navigator, connect it to your vehicle's cigarette lighter socket using the provided car charger. The device will automatically power on when connected. For initial use, ensure the device is fully charged or connected to power.

- Insert the small end of the USB cable into the GPS device's charging port.
- Insert the car charger into your vehicle's 12V power outlet (cigarette lighter socket).
- A small light on the car charger indicates a successful connection and charging status.

3. Operating Instructions

3.1 Basic Navigation

The glaury GPS Navigator provides intuitive turn-by-turn directions. After powering on, the device will acquire a GPS signal. You can then enter your destination using various methods:

- **Postcode Search:** Enter the destination's postcode.
- **Address Search:** Input the full street address.
- **Coordinates Search:** Enter specific latitude and longitude coordinates.
- **Favorite Locations:** Select from previously saved favorite destinations.

- **POI (Points of Interest) Search:** Find nearby gas stations, restaurants, hotels, etc.

Once a destination is set, the device will calculate the route and begin providing voice-guided directions.

3.2 Intelligent Route Planning

The device offers advanced route planning options to suit your preferences and vehicle type. You can select from four route options:

- **Fast:** Prioritizes the quickest route.
- **Green:** Suggests routes that are more fuel-efficient.
- **Short:** Calculates the shortest distance route.
- **Easy:** Avoids complex turns or difficult road conditions.

Additionally, you can customize the route based on your vehicle's specific dimensions and weight (e.g., length, height, width, weight) to avoid restricted roads. The system supports 7 vehicle types: Car, Truck, Bus, Taxi, Emergency, Bicycle, and Pedestrian.



Figure 3.2: Route planning options for various vehicle types.

3.3 Intelligent Voice Guidance and Alerts

The GPS navigator provides clear, real voice spoken turn-by-turn directions. It also includes intelligent alerts to enhance your driving safety and awareness:

- **Speed Camera Alerts:** Notifies you of upcoming speed cameras.
- **Sound Warning:** Provides audible warnings for various road conditions.
- **Street Names Broadcast:** Announces street names for clearer navigation.
- **Current Speed Display:** Shows your current driving speed.
- **Active Lane Assistant:** Guides you to the correct lane for upcoming turns or exits.
- **Red Light Warning:** Alerts you to upcoming red light cameras.
- **Estimated Arrival Time:** Displays the projected time of arrival at your destination.

The device also supports FM broadcast functionality, which allows you to transfer the GPS sound to your car's speakers

for improved clarity. This is not an FM radio function but a sound transmission feature.



Figure 3.3: Overview of voice guidance and alert features.

3.4 Map Updates

Your glaury GPS Navigator comes pre-installed with the latest 2025 maps for the United States, Canada, and Mexico. Lifetime free map updates are provided. To update your maps:

- **Via PC:** Connect the GPS device to a Windows PC using the provided USB cable. Follow the instructions provided by the manufacturer for the update software.
- **Via TF Card:** Download map updates to a TF (microSD) card and insert it into the device.

For maps of other regions (e.g., Europe), please contact glaury customer support for download instructions.



Figure 3.4: Methods for updating maps on your GPS Navigator.

4. Maintenance

To ensure the longevity and optimal performance of your glaury GPS Navigator, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the screen and exterior of the device. Avoid abrasive cleaners or solvents.
- **Temperature:** Do not expose the device to extreme temperatures (hot or cold) for extended periods, as this can damage the battery and internal components.
- **Storage:** When not in use, store the device in a cool, dry place away from direct sunlight.
- **Handling:** Handle the device with care. Avoid dropping it or subjecting it to strong impacts.

5. Troubleshooting

This section addresses common issues you might encounter with your GPS navigator. If you experience problems not

listed here, please contact customer support.

Problem	Possible Cause	Solution
Device does not power on.	Low battery; improper power connection.	Ensure the device is fully charged or connected to the car charger. Check if the car charger is properly inserted and the vehicle's power outlet is functional.
No GPS signal.	Obstructed view of the sky; device indoors.	Move the device to an open area with a clear view of the sky. Avoid using it indoors or in tunnels.
Voice guidance is too low or absent.	Volume settings; FM transmitter not configured.	Adjust the volume settings on the device. If using FM transmission, ensure it is correctly set up and your car radio is tuned to the correct frequency.
Screen is unresponsive.	Software glitch; device frozen.	Perform a soft reset by pressing and holding the power button until the device restarts. If the issue persists, contact support.

6. Specifications

Feature	Detail
Model Number	J701
Screen Size	7 Inches
Touch Screen Type	Capacitive
Connectivity Technology	USB
Map Type	North America (US, Canada, Mexico)
Vehicle Service Type Support	Bus, RV, Car, Truck, Bicycle, Taxi, Emergency, Pedestrian
Special Features	Touchscreen, Speed Camera Alerts, Voice Guidance, Lane Assistant, FM Transmitter
Item Weight	Approximately 2.2 pounds (1 kg)
Batteries	1 Lithium Polymer battery (included)

7. Warranty and Support

For any questions, technical assistance, or warranty claims regarding your glaury GPS Navigator, please refer to the contact information provided with your purchase or visit the official glaury website. Lifetime free map updates are provided, and support is available for assistance with these updates or any operational queries.
Common questions and operating procedures are detailed in this user manual. Please review it thoroughly. If further assistance is needed, do not hesitate to contact customer support.

© 2025 glaury. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I update the maps on my glaury J701 GPS Navigator?

The glaury J701 GPS Navigator offers lifetime free map updates. According to the manual, there are two primary methods to update your maps: Via PC: Connect the GPS device to a Windows PC using...

Read full answer

Open the live page

https://manuals.plus/asin/B0DLBDTFL7

More documents and user manuals: **https://manuals.plus/**