

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Alaga](#) /

› [Alaga Indoor Security Camera 3K User Manual](#)

Alaga B0DLBFVT55

Alaga Indoor Security Camera 3K User Manual

Model: B0DLBFVT55

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Alaga Indoor Security Camera 3K. Please read this manual thoroughly before using the product to ensure proper functionality and safety. The Alaga Indoor Security Camera 3K offers advanced features including 3K Ultra HD clarity, dual-band WiFi connectivity (2.4G and 5G), 360° pan and tilt functionality, AI-powered motion detection for humans and pets, advanced night vision, two-way audio, and compatibility with Alexa and Google Assistant.

PACKAGE CONTENTS

Before proceeding with installation, please verify that all items are present in the package:

- Alaga Indoor Security Camera 3K
- Power Adapter
- USB Cable
- Mounting Bracket
- Screws and Wall Plugs
- User Manual (this document)

SETUP GUIDE

1. Powering On the Camera

Connect the provided USB cable to the camera's power port and the other end to the power adapter. Plug the power adapter into a wall outlet. The camera will power on and initiate its self-test sequence.

2. App Installation and Account Creation

Download the official Alaga security camera application from your device's app store (iOS App Store or Google Play Store). Follow the on-screen instructions to create a new account or log in if you already have one.

3. Connecting to Wi-Fi

In the app, select "Add Device" and choose your camera model. Follow the in-app prompts to connect the camera to your Wi-Fi network. The camera supports both 2.4G and 5G Wi-Fi bands for flexible connectivity. Ensure your mobile device is connected to the same Wi-Fi network during the setup process.

4. Mounting the Camera (Optional)

The camera can be placed on a flat surface or mounted to a wall or ceiling. Use the provided mounting bracket, screws, and wall plugs for secure installation. Ensure the camera has a clear line of sight to the area you wish to monitor.



Image: The Alaga Indoor Security Camera 3K shown alongside a smartphone displaying its live view and control interface. This illustrates the camera's design and its integration with the mobile application for remote monitoring and control.

OPERATING INSTRUCTIONS

Live View and Pan/Tilt Control

Open the Alaga app and select your camera to access the live view. Use the on-screen joystick or swipe gestures to control the camera's 345° horizontal pan and 62° vertical tilt, allowing you to monitor every corner of your room.

See All Around with 360° Pan and Tilt



Image: An Alaga camera positioned in a living space, with arrows indicating its 360-degree pan and tilt capability, demonstrating its wide coverage area.

Motion Detection and Alerts

The camera features AI-powered motion detection. When motion, a person, or a pet is detected, the camera will send instant push notifications to your phone. You can customize detection zones and sensitivity settings within the app.

Ultra-Smooth 360° Viewing Experience

Focus shifts instantly to your selected area with Quick Focus Tap.




Image: A child playing on a couch, with a visual overlay indicating that the camera's AI tracking feature is actively following the subject, highlighting its ability to keep targets in view.

Night Vision

The camera automatically switches to advanced infrared night vision in low-light conditions, providing clear footage up to 30 feet. This ensures continuous monitoring even in complete darkness.

Advanced AI: Accurate Detection & Tracking

Instantly detects and tracks humans and pets.




Image: A smartphone screen displaying a black and white night vision feed from the Alaga camera, showing a dog and a person sleeping, with indicators for lens aperture, light increase, and clear face detection distance.

Two-Way Audio

Utilize the two-way audio feature to communicate with individuals near the camera. Tap the microphone icon in the app to speak, and the camera's built-in speaker will transmit your voice. You can also hear audio from the camera's environment.

Storage Options

The camera supports local storage via a Class 10 microSD card (up to 256GB, not included). Alternatively, you can subscribe to cloud storage services for encrypted footage backup, ensuring data safety even if the camera is compromised.

Voice Assistant Integration

Integrate your Alaga camera with Amazon Alexa or Google Assistant. Once linked, you can view live footage on compatible devices like Echo Show or Google Chromecast using simple voice commands.

Privacy Mode

Activate privacy mode through the app to temporarily disable recording and live view, ensuring your privacy when needed. The camera lens may physically retract or turn away in this mode.

Privacy at the Tap of a Button

Protect privacy easily with privacy mode and local storage.





Image: A hand interacting with a smartphone app, showing the option to toggle "Camera On" or "OFF" for privacy mode, with the Alaga camera in the background, illustrating how privacy can be activated with a tap.

MAINTENANCE

Cleaning the Camera

To maintain optimal image quality, gently wipe the camera lens and body with a soft, dry, lint-free cloth. Do not use liquid cleaners or abrasive materials, as they may damage the camera.

Firmware Updates

Periodically check the Alaga app for available firmware updates. Keeping your camera's firmware up-to-date ensures

access to the latest features, security enhancements, and performance improvements.

MicroSD Card Management

If using a microSD card for local storage, regularly back up important footage and format the card periodically to maintain performance and prevent data corruption. Refer to the app for microSD card management options.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera offline/Cannot connect to Wi-Fi	Incorrect Wi-Fi password; Camera too far from router; Router issues; Incorrect Wi-Fi band selected.	<ul style="list-style-type: none">◦ Verify Wi-Fi password.◦ Move camera closer to the router or use a Wi-Fi extender.◦ Restart your router and the camera.◦ Ensure you are connecting to a 2.4G or 5G network as supported.
Poor image quality	Dirty lens; Insufficient lighting; Network bandwidth issues.	<ul style="list-style-type: none">◦ Clean the camera lens with a soft cloth.◦ Ensure adequate lighting or verify night vision is active.◦ Check your internet speed and reduce other network usage.
Motion alerts not received	App notifications disabled; Motion detection sensitivity too low; Detection zone not configured.	<ul style="list-style-type: none">◦ Enable notifications for the Alaga app in your phone settings.◦ Adjust motion detection sensitivity in the app.◦ Configure detection zones to cover desired areas.
Two-way audio not working	Microphone/speaker permissions not granted; Volume too low; Network latency.	<ul style="list-style-type: none">◦ Grant microphone and speaker permissions to the app.◦ Increase volume settings in the app and on your phone.◦ Check network connection stability.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model	Alaga Indoor Security Camera 3K (B0DLBFVT55)
Resolution	3K Ultra HD (2880×1620)
Connectivity	2.4G & 5G Wi-Fi, Bluetooth
Pan/Tilt Range	345° Horizontal, 62° Vertical
Night Vision Range	Up to 30 feet (10 meters)
Audio	Two-Way Audio
Storage Options	MicroSD Card (up to 256GB, Class 10), Cloud Storage
AI Features	Human & Pet Motion Detection, Tracking
Compatibility	Amazon Alexa, Google Assistant
Indoor/Outdoor Usage	Indoor Only

WARRANTY INFORMATION

Alaga products are covered by a limited warranty from the date of purchase. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Alaga website. This warranty typically covers manufacturing defects and malfunctions under normal use.

CUSTOMER SUPPORT


If you encounter any issues or have questions regarding your Alaga Indoor Security Camera 3K, please contact our customer support team:

- **Email:** support@alaga.com
- **Website:** www.alaga.com/support
- **Phone:** Please refer to the contact information provided on the official Alaga website for regional support numbers.

When contacting support, please have your product model (B0DLBFVT55) and purchase date ready.



Related Documents - B0DLBFVT55

	<p>Alaga Home Security Wi-Fi Camera Quick Start Guide</p> <p>A quick start guide for the Alaga Home Security Wi-Fi Camera, covering setup, mounting, FAQs, and LED light status.</p>
---	--

<div><p>Alaga Home Security WiFi Camera S-CW2503C-H Model Statement</p><p>Statement from Mega Multimedia AI LLC regarding the Alaga Home Security WiFi Camera, Model S-CW2503C-H, confirming that test data for this model represents derivative models S-CW2503C, CW2503C, P50, and P50S due to identical circuitry and PCB layout.</p></div>	
<div><p>The Platinum Karaoke: New Songs Vol. 73 Catalog</p><p>A comprehensive catalog of new song releases for The Platinum Karaoke system, Volume 73. This document lists hundreds of songs, including popular hits and classic tracks, with their respective model numbers and artists. It features a diverse selection of music in both English and Filipino languages.</p></div>	