

**Manuals+**

[Q & A](#) | [Deep Search](#) | [Upload](#)

**LIORQUE TM027**

# LIORQUE 60 Minute Visual Timer User Manual

Model: TM027

## INTRODUCTION

---

The LIORQUE 60 Minute Visual Timer is designed to help individuals, both children and adults, manage time effectively. Its clear visual display and quiet operation make it ideal for various settings, including classrooms, offices, and homes. This manual provides detailed instructions for setting up, operating, and maintaining your visual timer.



Image: The LIORQUE 60 Minute Visual Timer in dark blue, showing the white dial with black numbers and a blue visual disk indicating remaining time.

## SAFETY INFORMATION

---

- Keep out of reach of small children to prevent choking hazards from small parts.
- Do not expose the timer to extreme temperatures or direct sunlight.
- Avoid dropping the timer or subjecting it to strong impacts.
- Do not attempt to disassemble or repair the timer yourself. Refer to qualified personnel for service.
- Dispose of batteries according to local regulations.

## PACKAGE CONTENTS

---

Please check the package to ensure all items are present:

- 1 x LIORQUE 60 Minute Visual Timer (Model TM027)
- 2 x AA Batteries (included)
- 1 x User Manual (this document)

## SETUP

---

### Battery Installation

1. Locate the battery compartment on the back of the timer.
2. Open the battery compartment cover.
3. Insert two AA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

# Battery Operated, No Ticking Sound



Image: The LIORQUE visual timer on a table with two AA batteries next to it, illustrating that batteries are included and the timer is battery-operated.

## Placement Options

The LIORQUE visual timer offers flexible placement options:

- **Magnetic Backing:** Attach the timer to any magnetic surface, such as a whiteboard or refrigerator.

- **Foldable Bracket:** Use the integrated foldable stand to place the timer on a desk, table, or shelf.
- **Wall Mounting Hole:** Hang the timer on a wall using a suitable hook or nail.

# 3 Types of Placement

# J

## Hook Hole



## Magnetic Back



$$\sum_{i=1}^n (x_i - \bar{x})^2 = \sum_{i=1}^n x_i^2 - n\bar{x}^2$$



## Stand



Image: A collage showing the three placement options: hanging via a hook hole, magnetic attachment to a blackboard, and standing on a tabletop using the foldable bracket.

## OPERATING INSTRUCTIONS

---

### Setting the Timer

To set the countdown time:

1. Turn the central dial **clockwise** to increase the time. The blue visual disk will expand to indicate the set duration.
2. Turn the central dial **counter-clockwise** to decrease the time.
3. The timer will begin counting down immediately once the dial is set.
4. **Note:** If the desired countdown time is less than 3 minutes, first turn the dial to 5 minutes, then turn it back to your desired shorter time.

# Easy to Use

- ↻ Turn clockwise to increase the time
- ↺ Turn counterclockwise to decrease the time



Turn off the alarm:  
Rotate clockwise a little, then reset to zero.

Image: The visual timer with text overlay indicating to turn clockwise to increase time and counter-clockwise to decrease time. A child is visible in the background, suggesting its use for learning.

## Adjusting Alarm Modes

The LIORQUE visual timer features three alarm modes: Sound, Light, and Vibration. You can select the mode that best suits your needs.

- **Sound Mode:** Offers three volume levels: Mute, Low, and High. Adjust the volume using the switch on the side/back of the timer.
- **Light Mode:** The timer will flash a light when the time expires.
- **Vibration Mode:** The timer will vibrate when the time expires.

All alarm types will last for 1 minute. To end the alarm early, refer to the 'Turning Off the Alarm' section.

## 3 Alarm Modes




Image: A collage illustrating the three alarm modes: Light Alarm (red light flashing), Vibration Alarm (vibration icon), and Audible Alarm (sound icon with Mute-Low-High options).

## Turning Off the Alarm

If you wish to stop the alarm before its 1-minute duration, gently rotate the dial clockwise a little, then reset it to zero. This action will disengage the alarm.

## FEATURES

---

- **Extra Large Visual Display:** The 7.5-inch screen provides a clear, at-a-glance view of remaining time, making it easy to understand for all ages.
- **Non-Ticking Operation:** Battery-powered design ensures silent operation, preventing distractions during focused tasks.
- **Multiple Alarm Options:** Choose between sound, light, or vibration alerts to suit different environments and personal preferences.
- **Flexible Placement:** Equipped with magnetic backing, a foldable stand, and a wall-mounting hole for versatile use.




Image: A graphic summarizing key features: Time Visible, 7.5" Large Screen, Easy to Operate, Battery-powered, No Ticking Sound, and Multiple Alarm Modes.

# 7.5 inch large screen, clear view - even from afar!




Image: The LIORQUE visual timer displayed with its dimensions, highlighting the 7.5-inch screen size for clear visibility from a distance.

## USAGE SCENARIOS

The LIORQUE visual timer is a versatile tool for various time management needs:

- **Classroom:** Helps students understand time limits for assignments, tests, or group activities.
- **Kitchen:** Perfect for cooking, baking, or any timed kitchen tasks.
- **Meetings:** Keeps discussions on track and ensures efficient use of time.
- **Yoga/Meditation:** Provides a visual cue for timed sessions without audible distractions.
- **Homework/Study:** Assists in focused work periods and breaks.
- **Chores/Tasks:** Motivates completion of household tasks within a set timeframe.

# Suitable for Several Occasions



Cooking



Classroom



Meeting

Yoga



Image: A graphic showing the visual timer in different settings: cooking, classroom, meeting, and yoga, demonstrating its versatility.



Image: A comparison showing children with improved focus and time management skills, illustrating the positive impact of using the visual timer.

## MAINTENANCE

- Clean the timer with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the timer to water or excessive moisture.
- If the timer will not be used for an extended period, remove the batteries to prevent leakage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Timer not starting/working	Batteries are dead or incorrectly inserted.	Replace batteries with new AA batteries, ensuring correct polarity.
Alarm not sounding/vibrating/lighting	Alarm mode is set to Mute or incorrect mode.	Check the alarm mode switch and volume settings.
Visual disk not moving smoothly	Internal mechanism obstruction or damage.	Ensure the timer is on a flat, stable surface. If problem persists, contact customer support.

## SPECIFICATIONS

**Brand:** LIORQUE

**Model Number:** TM027

**Color:** Dark Blue

**Product Dimensions:** 7.64"D x 7.8"W x 2"H

**Screen Size:** 7.5 Inches

**Item Weight:** 1.23 pounds

**Batteries:** 2 AA batteries (included)

**Maximum Time Setting:** 60 minutes




# WARRANTY AND SUPPORT

LORQUE products are manufactured with high-quality standards. For any questions, technical support, or warranty claims, please refer to the contact information provided with your purchase or visit the official LORQUE website. Please retain your proof of purchase for warranty purposes.



© 2025 LORQUE. All rights reserved.

## Related Documents

	<p><a href="#">Liorque Visual Timer Model TM027 User Guide</a></p> <p>Comprehensive guide for the Liorque Visual Timer (Model TM027). Learn about its features, alarm modes (sound, light, vibration), setting instructions, low battery indicators, and proper disposal. Contact support for assistance.</p>
	<p><a href="#">Liorque Kitchen Timer and Clock User Manual</a></p> <p>User manual for the Liorque Kitchen Timer and Clock, detailing its features, operation, and specifications. This digital timer is suitable for cooking, learning, and various other activities.</p>
	<p><a href="#">Liorque Projection Alarm Clock User Manual: Setup, Features, and Operation Guide</a></p> <p>Detailed user manual for the Liorque Projection Alarm Clock. Learn how to set time, alarms, date, use the FM radio, projection features, adjust brightness, and understand safety precautions and FCC compliance.</p>



**LIORQUE** Radiowa stacja pogodowa z czujnikiem zewnętrznym, cyfrowy termometr, higrometr, do użytku wewnątrz i na zewnątrz, radiowa stacja pogodowa z prognozą pogody, zasilana bateriami, wyświetlacz LCD.

Cena: 307,48 zł

**Opis**

LIORQUE Radiowa stacja pogodowa z czujnikiem zewnętrznym, cyfrowy termometr, higrometr, do użytku wewnątrz i na zewnątrz, radiowa stacja pogodowa z prognozą pogody, zasilana bateriami, wyświetlacz LCD.

**Ważne informacje**


LIORQUE Radiowa stacja pogodowa z czujnikiem zewnętrznym, cyfrowy termometr, higrometr, do użytku wewnątrz i na zewnątrz, radiowa stacja pogodowa z prognozą pogody, zasilana bateriami, wyświetlacz LCD.

[LIORQUE Radiowa Stacja Pogodowa z Czujnikiem Zewnętrznym: Termometr, Higrometr, Prognoza Pogody, Zasilana Bateriami](#)

Wielofunkcyjna radiowa stacja pogodowa LIORQUE z czujnikiem zewnętrznym do monitorowania temperatury, wilgotności i prognozy pogody wewnątrz i na zewnątrz. Wyposażona w 4,3-calowy ekran LCD, funkcje alarmu, drzemki i kalendarza. Łatwa w konfiguracji, zasilana bateriami.

Documents - LIORQUE – TM027

**LIORQUE Visueller Timer Modell: TM027 DE**




**Diagram**

- 1. Kнопf
- 2. LED-Anzeigeleuchte
- 3. Visuelles Zifferblatt
- 4. Windauffringeloch
- 5. 3 Aser der Alarmbausteile (im Tonmodus)
- 6. 3 Alarmmodi (Ton/Licht/Vibration)
- 7. Batteriefach
- 8. Halterung
- 9. Magnet

**Tipps vor der Anwendung**

1. Öffnen Sie vor dem Gebrauch bitte die Batterieabdeckung, entfernen Sie die Isolierfolie und prüfen Sie, ob die Batterie richtig eingelegt ist.
2. Bitte stellen Sie vor der Verwendung den gewünschten Alarmmodus ein.

**Alarmmodi**



**1. Tonmodus**

Im Tonmodus können Sie den Alarmton stummstellen – niedrige Lautstärke – hohe Lautstärke. Wenn der Countdown abgelaufen ist, ertönt der Alarmton.

**Hinweise:**  
Im Stummstellungsmodus erfolgt keine Meldung, wenn der Countdown endet. Die Einstellung der Alarmlautstärke ist nur im Tonmodus wirksam.

**2. Lichtmodus**

Im Lichtmodus blinkt der Timer rot, um Sie daran zu erinnern, wenn die Zeit abgelaufen ist.

**3. Vibrationsmodus**

Im Vibrationsmodus vibriert der Timer, um Sie daran zu erinnern, wenn die Zeit abgelaufen ist.

**Einstellung**

1. Drehen Sie den Knopf im Uhrzeigersinn auf die gewünschte Countdown-Zeit. Das grüne Licht erscheint, was bedeutet, dass der Timer zu arbeiten beginnt und das grüne Licht während des Countdowns langsam erloscht.
2. Wenn die gewünschte Countdownzeit weniger als 5 Minuten beträgt, drehen Sie den Knopf bitte zuerst auf 5 Minuten und dann auf die gewünschte Zeitskala.
3. Countdown-bleibt für 0:43 Minuten.
4. Der Countdown ist abgelaufen und alle Alarmmodi dauern 1 Minute. Wenn Sie den Alarm vorzeitig beenden möchten, sehen Sie sich bitte die Schritte zum Beenden des Alarms im folgenden Kapitel an.



**Erinnerung an niedrigen Batteriestand**

1. Wenn der Akku im Standby-Modus schwach ist, blinkt der Timer alle 2 Sekunden rot.
2. Wenn die Batterie schwach ist, funktioniert der Timer nicht richtig. Bitte ersetzen Sie die Batterie sofort.
3. Bitte verwenden Sie austauschbare 2x AA 1,5V-Batterien.

**24 Stunden Kundendienst**

Wenn Sie Fragen haben, kontaktieren Sie uns bitte unter [support@liorque.net](mailto:support@liorque.net)



Korrekte Entsorgung dieses Produkts  
Diese Kennzeichnung weist darauf hin, dass dieses Produkt in der gesamten EU nicht mit anderen Haushaltsabfällen entsorgt werden darf. Um mögliche Schäden für die Umwelt oder die menschliche Gesundheit durch unkontrollierte Abfallentsorgung zu vermeiden, recyclen Sie es verantwortungsbewusst, um die nachhaltige Wiederverwendung von Materialressourcen zu fördern. Um Ihr Altgerät zurückzugeben, nutzen Sie bitte die Rückgabe- und Sammelsysteme oder wenden Sie sich an den Händler, bei dem das Produkt gekauft wurde. Diese können das Produkt einem umweltgerechten Recycleen zuführen.

[LIORQUE Visual Timer Model TM027 User Guide](#)

Comprehensive guide for the LIORQUE Visual Timer (Model TM027). Learn about its features, alarm modes (sound, light, vibration), setting instructions, low battery indicators, and proper disposal. Contact support for assistance.

lang: score:14 filesize: 399.39 K page\_count: 1 document date: 2024-10-06