

[Manuals.plus](#) /

› [Yaheetech](#) /

› Yaheetech 3-Seater Sofa with USB Ports - Instruction Manual for Model YT-00142147

Yaheetech YT-00142147

Yaheetech 3-Seater Sofa with USB Ports - Instruction Manual

Model: YT-00142147

INTRODUCTION

Thank you for choosing the Yaheetech 3-Seater Sofa. This manual provides essential information for the safe assembly, operation, and maintenance of your new sofa. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The Yaheetech 3-Seater Sofa, featuring a modern design with dark gray fabric upholstery, positioned in a living room.

SAFETY INFORMATION

Please observe the following safety guidelines to ensure safe use of your sofa:

- All foam and upholstered surfaces meet flammability standards.
- Keep the sofa away from open flames or high heat sources to prevent fire hazards.
- Supervise children and pets to avoid entrapment risks or injury.
- Do not exceed the maximum weight capacity of 750 pounds (340 kg).
- Ensure all components are securely fastened before use.

PACKAGE CONTENTS

Your Yaheetech 3-Seater Sofa is shipped in two packages. Please verify that all components listed below are present before beginning assembly. Components are often stored within zippered compartments of the sofa base or armrests.



Image: An illustration detailing the sofa's dimensions and how components are distributed across two shipping packages, including parts hidden within the sofa structure.

Box 1 Contents:

- Backrest (left)
- Backrest (right)
- Base (left)
- Armrest (left)
- Back Pillow 1

Box 2 Contents:

- Hardware & Legs
- Base (right)
- Armrest (right)
- Seat Cushion 1, 2, 3
- Back Pillow 2, 3

Note: Hardware, legs, and some smaller components are typically found within zippered compartments located on the underside of the sofa bases or armrests. Please check these compartments thoroughly.

SETUP AND ASSEMBLY

Assembly is required for this sofa. It is recommended to have two people for easier and safer assembly. Please follow the included assembly instructions carefully. A general overview of the process is provided below:

1. **Unpack Components:** Carefully remove all parts from both packages. Lay them out on a clean, soft surface to prevent scratches. Identify all hardware and legs, usually found in zippered compartments.
2. **Attach Legs:** Securely attach the six sturdy plastic legs to the underside of the sofa bases using the provided hardware. Ensure they are tightened firmly.

3. **Connect Bases:** Join the left and right sofa bases together. Align the connecting brackets and secure them with the appropriate hardware.
4. **Attach Armrests:** Connect the armrests to the assembled sofa base. Ensure the USB cables are routed correctly if applicable.
5. **Install Backrests:** Slide or attach the backrest sections into their designated slots on the sofa frame.
6. **Place Cushions:** Position the seat cushions and back pillows onto the sofa.
7. **Final Check:** Verify that all connections are secure and the sofa is stable before use.

For detailed, step-by-step instructions, refer to the separate assembly guide included in your package.

OPERATING INSTRUCTIONS

Your Yaheetech 3-Seater Sofa is designed for comfort and convenience.

USB Charging Ports:

The sofa features integrated USB ports for convenient charging of your electronic devices. Locate the USB ports on the side of the armrest. Connect your device's charging cable to the port. Ensure the sofa is connected to a power source (if applicable, via an adapter or integrated power cord) for the USB ports to function.



Image: A detailed view of the sofa's armrest, highlighting the integrated USB charging ports and dual-side storage pockets, with a laptop and smartphone connected for charging.

Storage Pockets:

Each armrest includes dual-side storage pockets. These are ideal for keeping small items such as remote controls, magazines, books, or mobile phones within easy reach.

Comfort and Support:

The sofa is designed with well-stuffed backrests and armrests, along with 6-inch thick seat cushions and a sinuous wire spring system for optimal support and comfort.




Image: A person comfortably seated on the sofa, demonstrating the ergonomic design that supports the shoulder, lumbar, hip, and legs. The image also shows the 6-inch clearance beneath the sofa, allowing for robot vacuum access.

MAINTENANCE

Proper care will extend the life and appearance of your sofa.

Cleaning:

- **Regular Cleaning:** Vacuum the sofa regularly using an upholstery attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain. For stubborn stains, use a mild fabric cleaner specifically designed for polyester upholstery. Test the cleaner on an inconspicuous area first.
- **Removable Cushions:** The seat cushions and back cushions are removable. Check the care tag on the cushions for specific cleaning instructions.

General Care:

- Avoid direct sunlight exposure for prolonged periods to prevent fading of the fabric.

- Rotate and fluff cushions periodically to maintain their shape and even out wear.
- Keep sharp objects away from the fabric to prevent tears or snags.



Image: An illustration detailing the internal construction of the sofa, showcasing the durable and breathable polyester fabric, 28D high-density foam, sturdy wood frame, and metal sinuous spring support system.

TROUBLESHOOTING

If you encounter any issues with your sofa, refer to the following common problems and solutions:

- **Sofa feels unstable after assembly:**
Ensure all legs are securely tightened and all connecting brackets between sofa sections are firmly fastened. Re-check the assembly instructions to confirm all steps were followed correctly.
- **USB ports are not charging devices:**
Verify that the sofa's power cord (if applicable) is properly plugged into a functional wall outlet. Check the connection of the USB cable to both the sofa port and your device. Try a different USB cable or device to rule out cable/device issues.
- **Cushions appear flat or misshapen:**
Regularly fluff and rotate the seat and back cushions to help them retain their shape and even out

wear. This is normal for foam-filled cushions over time.

- **Squeaking noises:**

Check all bolted connections and tighten any loose hardware. Squeaking can sometimes occur from friction between components. If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Yaheetech
Model Number	YT-00142147
Product Dimensions (D x W x H)	32.5"D x 76"W x 34"H
Item Weight	92.6 Pounds
Weight Limit	750 Pounds
Seat Depth	21.7 inches
Seat Height	18 Inches
Furniture Wall Clearance	6 Inches
Upholstery Fabric Type	Polyester
Frame Material Type	Engineered Wood, Plastic
Seat Fill Material	Foam
Back Fill Material	Foam
Suspension Type	Sinuous Springs
Assembly Required	Yes
Included Components	Assembly Instructions, Accessory Kit, Sofa Cover

WARRANTY AND SUPPORT

Warranty Information:

This Yaheetech sofa comes with a limited warranty. For specific details regarding coverage and duration, please refer to the warranty card included with your product or visit the official Yaheetech website.

Customer Support:

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact Yaheetech customer support. You can typically find contact information on the packaging, in the assembly guide, or on the official Yaheetech website.

For online support, visit: [Yaheetech Store on Amazon](#)

