



[Manuals.plus](#) /

- › [Signature Design by Ashley](#) /
- › Signature Design by Ashley Drazmine Lift-Top Coffee Table (Model T734-20) User Manual

## Signature Design by Ashley T734-20

# Signature Design by Ashley Drazmine Lift-Top Coffee Table User Manual

Model: T734-20

## INTRODUCTION

---

This manual provides essential information for the safe and proper use, setup, operation, and maintenance of your Signature Design by Ashley Drazmine Lift-Top Coffee Table. Please read all instructions carefully before using the product and retain this manual for future reference.



*Image: Front view of the Drazmine Lift-Top Coffee Table. This image displays the table's overall design, including the dark brown base, light wood-tone top, and four visible drawers with silver knobs.*

## SAFETY INFORMATION

**WARNING: Failure to follow these safety instructions may result in injury or damage to the product.**

- Always anchor this furniture to the wall to prevent tipping. Use appropriate anchoring hardware (not included) suitable for your wall type.
- Keep fingers and other body parts away from the lift-top mechanism during operation to avoid pinching or crushing injuries.
- Do not exceed the weight limit of 113 pounds (approximately 51 kg) on the tabletop. Distribute weight evenly.
- Ensure the table is placed on a level surface to prevent instability.
- Do not allow children to climb on or play with the lift-top mechanism or drawers.

## SETUP

The Signature Design by Ashley Drazmine Lift-Top Coffee Table is designed for minimal assembly. It arrives ready for instant enjoyment in your home.

1. **Unpacking:** Carefully remove the coffee table from its packaging. Inspect for any shipping damage.
2. **Placement:** Position the coffee table in your desired location. It is recommended that two people move the table due to its weight (113 pounds).
3. **Leveling:** Ensure the table is stable on your floor. The table includes casters for mobility, but ensure it is stationary when in use.
4. **Wall Anchoring:** For safety, especially in homes with children, it is strongly recommended to anchor the table to a wall to prevent tipping. Refer to the safety information section for details.



*Image: The Drazmine Coffee Table positioned in a living room, demonstrating its intended use and scale within a home environment.*

## OPERATING THE LIFT-TOP MECHANISM AND DRAWERS

### Lift-Top Operation:

The coffee table features a spring-operated lift-top mechanism, allowing the tabletop to be raised to a more convenient height for various activities.

1. **To Raise:** Gently lift the front edge of the tabletop. The spring mechanism will assist in raising it smoothly. Continue lifting until it locks into the elevated position.
2. **To Lower:** Carefully disengage the locking mechanism (if present, or gently push down if it's a friction-based lift) and guide the tabletop back down to its original position. Ensure hands are clear of the mechanism.

ALSO AVAILABLE IN THIS COLLECTION



*Image: The coffee table with its lift-top mechanism fully extended, revealing internal storage compartments. Multiple drawers are also shown open, displaying their storage capacity.*

### **Drawer Operation:**

The table is equipped with four smooth-gliding drawers for convenient storage.

- **Opening:** Pull the drawer knob gently to slide the drawer open. The drawers are designed for smooth operation.
- **Closing:** Push the drawer firmly until it is fully closed and flush with the table's frame.
- **Storage:** Utilize the drawers for organizing small items, remote controls, or other living room essentials.



*Image: A close-up view of an open drawer, highlighting the smooth-gliding metal drawer slide mechanism.*

### **Caster Wheels:**

The table is fitted with caster wheels for easy repositioning. When moving the table, ensure the path is clear and lift slightly if crossing uneven surfaces to prevent damage to the casters or floor.



*Image: A detailed view of one of the caster wheels located at the base of the coffee table, designed for mobility.*

## MAINTENANCE AND CARE

---

Proper care will help maintain the appearance and longevity of your coffee table.

- **Cleaning:** For general cleaning, wipe surfaces with a damp cloth. Follow immediately by wiping with a dry cloth to prevent moisture damage.
- **Spills:** Blot spills immediately with a clean, dry cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Protection:** Use coasters under beverages and placemats under hot items to protect the tabletop from heat and moisture rings.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Moving:** When moving the table, lift it rather than dragging it to prevent damage to the legs, casters, and floor.

## TROUBLESHOOTING

---

This section addresses common issues you might encounter with your coffee table.

- **Table Wobbles:** Ensure the table is on a level surface. If wobbling persists, check if any casters or legs are uneven. Adjust placement as needed.
- **Lift-Top Mechanism Sticking:** If the lift-top mechanism feels stiff, ensure no objects are obstructing its movement. Avoid forcing the mechanism. Light lubrication (e.g., silicone spray) on moving parts may help, but consult the manufacturer if issues persist.
- **Drawers Not Sliding Smoothly:** Check for any obstructions inside the drawer or along the slides. Ensure the drawer is properly aligned on its tracks.
- **Scratches or Dents:** Minor scratches can sometimes be touched up with furniture repair markers or waxes that match the wood finish. For significant damage, professional repair may be necessary.

## SPECIFICATIONS



**WIDTH:46"**

**DEPTH:26"**

**HEIGHT:19.5"**

Lift top extended height: 27.5"

Center drawer interior (2):

17" W x 15.38" D x 5.63" H

Lift top extended depth: 34.63"

Side drawer interior (2):

17.13" W x 9.13" D x 2.25" H

*Image: A diagram illustrating the key dimensions of the Drazmine Coffee Table, including width, depth, and height, as well as extended lift-top dimensions and drawer interior measurements.*

| Feature    | Detail                         |
|------------|--------------------------------|
| Brand      | Signature Design by Ashley     |
| Model Name | Drazmine Lift-Top Coffee Table |

| Feature                               | Detail                                |
|---------------------------------------|---------------------------------------|
| Model Number                          | T734-20                               |
| Product Dimensions (D x W x H)        | 26"D x 46"W x 19.5"H                  |
| Lift Top Extended Height              | 27.5"                                 |
| Lift Top Extended Depth               | 34.63"                                |
| Item Weight                           | 113 Pounds                            |
| Material Type                         | Engineered Wood, Metal, Wood (Acacia) |
| Color                                 | Dark Brown & Light Brown              |
| Number of Drawers                     | 4                                     |
| Casters                               | Yes, for mobility                     |
| Assembly Required                     | No (Ready for instant enjoyment)      |
| Recommended People for Assembly/Setup | 2 (for moving/placement)              |

## WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to purchase replacement parts, please contact Signature Design by Ashley customer service directly. Refer to the official Signature Design by Ashley website or your purchase documentation for contact details.

**Manufacturer:** Ashley Furniture Industries

**UPC:** 024052902921

© 2023 Signature Design by Ashley. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.