

Playmobil 71762

Playmobil Asian Garden with Pandas (Model 71762) Instruction Manual

INTRODUCTION

Welcome to the Playmobil Asian Garden with Pandas playset, model 71762. This instruction manual provides detailed guidance for the assembly, proper use, and maintenance of your new toy. The set is designed for children aged 4 years and older, offering an engaging play experience with an Asian-themed pavilion, panda figures, and various accessories.

Familiarize yourself with the contents and instructions to ensure a safe and enjoyable play experience.

SAFETY INFORMATION

Please read all safety warnings carefully before use.

- **Warning:** Not suitable for children under 3 years due to small parts. Choking hazard.
- To be used under adult supervision.
- Keep packaging materials away from children to avoid suffocation risks.

PACKAGE CONTENTS

Before beginning assembly, please verify that all components listed below and shown in the diagram are present in your package. The set contains 46 pieces.




Figure 1: Overview of all included components for the Playmobil Asian Garden with Pandas set.

The diagram illustrates the various figures, animals (pandas), pavilion parts, trees, water features, and small accessories like food items, fans, and umbrellas. Refer to this image to ensure no parts are missing before assembly.

SETUP AND ASSEMBLY

Assembly of the Playmobil Asian Garden with Pandas set is straightforward. Adult assistance is recommended, especially for younger children, to ensure correct part placement and secure connections.

1. Unpack all components and lay them out on a clean, flat surface. Refer to Figure 1 for a complete list of parts.
2. Begin by assembling the main pavilion structure. Connect the base plate to the wall sections, then attach the roof.
3. Assemble the decorative elements such as the cherry blossom tree and the bamboo stalks.
4. Place the koi pond and other landscape features as desired within the garden area.
5. Position the figures, pandas, and small accessories to complete the scene.
6. Ensure all connections are firm and stable before play.



Figure 2: The Playmobil Asian Garden with Pandas playset after complete assembly.

Once assembled, the playset provides a detailed and interactive environment for imaginative storytelling.

OPERATING INSTRUCTIONS (PLAY SCENARIOS)

The Playmobil Asian Garden with Pandas set encourages creative play. Here are some suggested play scenarios:

- **Panda Feeding:** Use the provided apples, seeds, or bamboo pieces to feed the panda figures near the koi pool.
- **Tea Ceremony:** Arrange the figures at the pavilion table with the teacups and teapot for a traditional tea ceremony.
- **Garden Exploration:** Have the figures explore the garden, interact with the pandas, or relax under the umbrella.



Figure 3: Figures enjoying the garden with the pandas.



Figure 4: A tea ceremony taking place inside the Asian Pavilion.

Encourage children to create their own stories and adventures within the Asian Garden setting.

MAINTENANCE AND CARE

To ensure the longevity and hygiene of your Playmobil playset, follow these care instructions:

- **Cleaning:** Clean parts (without labels) under running water. Use mild soap if necessary.
- **Avoid Chemicals:** Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the plastic.
- **Drying:** Allow all parts to air dry completely before storing or reassembling.
- **Storage:** Store the playset in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.

TROUBLESHOOTING

If you encounter any issues with your Playmobil Asian Garden with Pandas set, please refer to these common solutions:

- **Missing Parts:** If you believe parts are missing, carefully re-check the packaging and compare with Figure 1 (Package Contents). Contact Playmobil customer support if parts are genuinely missing.
- **Difficulty Assembling:** Ensure you are following the assembly steps correctly. Apply gentle, even pressure when connecting parts. Do not force pieces together.
- **Damaged Parts:** If any part is damaged upon arrival, do not attempt to assemble or use the set. Contact Playmobil customer support for assistance.

SPECIFICATIONS

Brand	Playmobil
Model Number	71762
Theme	Natural/Asia
Material Type	Plastic
Recommended Age	4 to 10 years
Number of Pieces	46
Item Dimensions (L x W x H)	11.18 x 7.36 x 3.66 inches
Item Weight	0.53 Kilograms
Assembly Required	Yes, user assembly required (no special tools)

WARRANTY AND SUPPORT

Playmobil products are manufactured to high-quality standards. For information regarding warranty, missing parts, or any other support needs, please contact Playmobil customer service directly.

You can find contact details and further information on the official Playmobil website: www.playmobil.com

Please have your model number (71762) ready when contacting support.