

[Manuals.plus](#) /

› [Tokidos](#) /

› Tokidos PlayCubes Bundle - Early Learners Bundle (3-5) User Manual

Tokidos T001

Tokidos PlayCubes Bundle - Early Learners Bundle (3-5) User Manual

Model: T001

INTRODUCTION

The Tokidos PlayCubes system is an innovative screen-free edutainment solution designed for children aged 3 to 8. This bundle, specifically the Early Learners Bundle, focuses on developing essential skills in math, cognitive growth, language, arts, emotional intelligence, and mindfulness through interactive play. It includes one set of Tokidos PlayCubes, a convenient carry box, and three interactive PlayCards tailored for children aged 3-5.

Key features of the Tokidos PlayCubes system include:

- **Bundle Contents:** 1 set of Tokidos PlayCubes with a carry box and 3 interactive PlayCards, each designed to support children's developmental needs.
- **Engaging, Screen-Free Play:** Promotes healthy, imaginative play, nurturing creativity and enhancing focus without screen distractions.
- **Comprehensive Skill Development:** Cultivates skills in math, cognitive abilities, language, arts, emotional intelligence, and mindfulness for holistic growth.
- **Durable & Safe:** Constructed from high-quality materials, ensuring safety and durability for extended play.
- **Batteries Included:** Each PlayCube features a long-lasting rechargeable battery, providing up to 6 hours of play.



Image: The Tokidos PlayCubes Early Learners Bundle, showcasing the clear carry box, the five light blue PlayCubes, and the three included PlayCards: "Discover Animal Sounds", "Alphabet Smash", and "Math Alchemist".

Safety Information

WARNING: CHOKING HAZARD - SMALL PARTS NOT SUITABLE FOR CHILDREN UNDER 3 YEARS. DO NOT PLAY SOUNDS CLOSE TO YOUR EAR! THIS PRODUCT PRODUCES FLASHES OF LIGHT THAT MAY TRIGGER EPILEPSY IN SENSITIZED INDIVIDUALS. THIS PRODUCT CONTAINS 5 NON-REMOVABLE LI-ION RECHARGEABLE BATTERIES (7.4WH, 3.7V, 2000MAH). ONLY USE THE PROVIDED CHARGING STATION TO CHARGE THE CUBES. ALWAYS CHARGE BY PLUGGING CASE WITH THE PROVIDED CHARGING CABLE INTO THE WALL SOCKET USING A CHARGING ADAPTOR. DO NOT EXPOSE THE PRODUCT TO FIRE, HEAT SOURCES, OR DIRECT SUNLIGHT FOR PROLONGED PERIODS. AVOID PUNCTURING, CRUSHING, OR DISASSEMBLING THE PRODUCT. DO NOT LEAVE THE PRODUCT UNATTENDED WHILE CHARGING. DISCONNECT THE CHARGING STATION FROM THE POWER SOURCE ONCE CHARGING IS COMPLETE. ENSURE THE CHARGING STATION IS PLACED ON A FLAT, STABLE SURFACE AWAY FROM FLAMMABLE MATERIALS. ADULT SUPERVISION IS RECOMMENDED DURING USE. CAUTION: IMPROPER USE OF THE PRODUCT CAN RESULT IN FIRE, EXPLOSION, OR OTHER HAZARDS. PLEASE READ AND FOLLOW ALL SAFETY INSTRUCTIONS CAREFULLY. IMPORTANT: REGULARLY INSPECT THE PRODUCT AND CHARGING STATION FOR ANY DAMAGE. DO NOT USE THE PRODUCT IF IT APPEARS DAMAGED OR IF THE BATTERIES ARE LEAKING. DISPOSAL: FOLLOW LOCAL REGULATIONS FOR THE DISPOSAL OF ELECTRONIC DEVICES AND BATTERIES. DO NOT DISPOSE OF IN FIRE OR TRASH.

SETUP

1. **Unboxing:** Carefully remove all components from the packaging. The bundle includes the Tokidos PlayCubes, a carry box, three interactive PlayCards, and a charging cable.
2. **Initial Charge:** Although the PlayCubes come with pre-installed rechargeable batteries, it is recommended to fully charge them before first use.
 - Place the PlayCubes into their designated slots within the carry box.
 - Connect the provided charging cable to the carry box.
 - Plug the charging cable into a wall socket using a suitable charging adapter (not included, typically a standard USB wall adapter).
 - Ensure the charging station is on a flat, stable surface away from flammable materials.
 - The cubes will indicate charging status (e.g., a light indicator). Disconnect once fully charged.
3. **Familiarization:** Review the PlayCards to understand the different games and their objectives.

OPERATING INSTRUCTIONS

The Tokidos PlayCubes are designed for intuitive interaction. Each PlayCube is equipped with sensors and a display to facilitate engaging gameplay with the PlayCards.

Using the PlayCubes and PlayCards:

1. **Powering On:** The PlayCubes typically power on automatically when removed from the charging station or when a PlayCard is inserted.
2. **Inserting PlayCards:** Each PlayCard corresponds to a specific game. Gently slide a PlayCard into the designated slot on a PlayCube. The cube will recognize the card and initiate the game.



Image: A hand demonstrating how to insert one of the interactive PlayCards into the slot on a Tokidos PlayCube.

3. **Interacting with Cubes:** Depending on the game, you will interact with the cubes by tapping, shaking, or arranging them. The cubes will provide audio and visual feedback.



Image: A young child engaging with several Tokidos PlayCubes spread out on a dark table, demonstrating active play.



Image: A close-up view of a child's hands interacting with the glowing surfaces of the Tokidos PlayCubes, showing the illuminated displays.

4. **Game Progression:** Follow the audio prompts and visual cues from the PlayCubes to progress through the games.
5. **Powering Off:** The PlayCubes will typically enter a low-power state or power off automatically after a period of inactivity or when returned to the charging station.

Included Interactive Games (Early Learners Bundle):




Image: A visual representation of the three interactive PlayCards included in the Early Learners Bundle, highlighting their titles and themes.

- **Discover Animal Sounds:**

Explore various animal sounds and learn fascinating facts about animals. This game is designed to enhance memory and encourage scientific inquiry in young learners.

- **Alphabet Smash:**

Boost phonemic awareness by linking words with images and their starting letters. This game serves as an excellent first step towards reading, building foundational literacy skills.

- **Math Alchemist:**

A math game that helps children learn addition through playful potion-making. Players combine ingredients by quantity rather than numbers, making arithmetic engaging and intuitive.

MAINTENANCE

- **Cleaning:** To clean the PlayCubes and carry box, gently wipe them with a soft, damp cloth. Do not use harsh chemicals, abrasive cleaners, or immerse the units in water. Ensure the charging ports and card slots are free from debris.
- **Storage:** Store the Tokidos PlayCubes and PlayCards in their provided carry box when not in use. Keep them in a cool, dry place, away from direct sunlight and extreme temperatures, to prolong battery life and product integrity.
- **Battery Care:** The PlayCubes contain non-removable Li-Ion rechargeable batteries. To maintain battery health, avoid fully discharging the batteries frequently. Recharge them regularly, and do not leave them unattended while charging. Always use the provided charging station and cable.
- **Inspection:** Periodically inspect the PlayCubes, PlayCards, and charging station for any signs of damage, such as cracks, frayed cables, or loose parts. Discontinue use immediately if any damage is observed and contact support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
PlayCubes not turning on.	Low or depleted battery.	Place the PlayCubes in the charging station and ensure it is connected to power. Allow sufficient time for charging.
PlayCubes not responding to PlayCards.	PlayCard not inserted correctly or dirty slot/card.	Ensure the PlayCard is fully and correctly inserted into the cube's slot. Gently clean the card and slot if necessary.
Audio is distorted or too low.	Speaker obstruction or low battery.	Check the speaker area on the bottom of the cube for any obstructions. Ensure the cube is adequately charged. WARNING: Do not play sounds close to your ear.  <i>Image: The underside of a Tokidos PlayCube, clearly showing the speaker grill and other components.</i>
Lights are flickering or not displaying correctly.	Low battery or internal issue.	Charge the PlayCubes fully. If the issue persists, contact Tokidos customer support. WARNING: This product produces flashes of light that may trigger epilepsy in sensitized individuals.
Charging station not charging cubes.	Cable or adapter issue, or improper connection.	Ensure the charging cable is securely connected to both the carry box and the wall adapter/socket. Try a different wall socket or adapter. Inspect the cable for damage.

SPECIFICATIONS

Feature	Detail
Model Number	T001

Feature	Detail
Educational Objective(s)	Reading, Math, Cognitive Abilities, Language, Arts, Emotional Intelligence, Mindfulness
Assembly Required	No
Batteries Required	Yes (Included)
Battery Type	Lithium-Ion (5 Nonstandard Battery batteries included)
Material Type(s)	Plastic
Colour	Blue
Product Dimensions (LxWxH)	22.5 x 33.02 x 13.97 cm
Item Weight	2.39 kg
Manufacturer Recommended Age	36 months - 8 years
Included Components	Carry Box, 3 PlayCards, Charging cable

WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the documentation provided at the time of purchase or visit the official Tokidos website. Warranty terms and conditions may vary by region and retailer.

Should you require technical assistance, have questions about product functionality, or need to report an issue, please contact Tokidos customer support through their official website or the contact information provided with your purchase. Always provide your product model number (T001) and a detailed description of the issue when seeking support.