

[Manuals.plus](#) /

› [Onn](#) /

› Onn Surf Tablet Gen 3 User Manual

Onn RM

Onn Surf Tablet Gen 3 User Manual

Model: RM

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your Onn Surf Tablet Gen 3. Please read it thoroughly to ensure proper use and to maximize the lifespan of your device.



Image: Front and back view of the Onn Surf Tablet Gen 3 in charcoal color. The front displays the home screen with various app icons, while the back shows the "onn." logo and the rear camera.

WHAT'S IN THE BOX

Upon unboxing your Onn Surf Tablet Gen 3, ensure all the following items are present:

- (1) Onn Surf Tablet Gen 3 (7-inch, 32GB, 2022 Model) - Charcoal
- (1) AC adapter
- (1) USB-C charging cable (3.2 ft / 1 m)
- (1) Quick Start Guide



Image: The yellow retail box for the Onn Surf Tablet Gen 3, showing the tablet's image and key features.

SETUP

1. Charging the Tablet

Before first use, fully charge your tablet. Connect the USB-C charging cable to the tablet's USB-C port and the AC adapter. Plug the AC adapter into a wall outlet. The battery indicator on the screen will show charging progress.

2. Initial Power On and Setup

1. Press and hold the power button (located on the side) until the Onn logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. Review and accept the terms and conditions to complete the initial setup.



Image: A close-up view of the side of the Onn Surf Tablet Gen 3, highlighting the power button, volume buttons, and the USB-C charging port.

OPERATING THE TABLET

Navigation

The Onn Surf Tablet Gen 3 runs on Android 12 (Go edition). Navigate using touch gestures:

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through screens or lists.
- **Pinch-to-zoom:** Enlarge or shrink content on the screen.

Cameras

The tablet features a 2 MP front-facing camera and a 2 MP rear-facing camera. Open the "Camera Go" app to take photos or record videos.

Storage Expansion

The tablet comes with 32 GB of internal storage. You can expand this storage using a microSD card (not included) via the dedicated microSD slot.

Battery Life

The tablet offers up to 10 hours of battery life for various activities such as gaming, web browsing, watching videos, and

listening to music. Battery life may vary based on usage and settings.




Image: The Onn Surf Tablet Gen 3 screen displaying the Google Kids Space interface, showing various educational and entertainment content for children.

MAINTENANCE

Cleaning

To clean your tablet, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials, as these can damage the screen or casing.

Storage

When not in use for extended periods, store the tablet in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (around 50%) before long-term storage to preserve battery health.

Software Updates

Periodically check for system updates to ensure your tablet has the latest features and security patches. Go to **Settings > System > System update** to check for and install available updates.

TROUBLESHOOTING

If you encounter issues with your Onn Surf Tablet Gen 3, refer to the following common solutions:

Problem	Solution
Tablet is unresponsive or frozen.	Press and hold the power button for about 10-15 seconds to force a restart.

Problem	Solution
Battery drains quickly.	Reduce screen brightness, close unused apps, disable Wi-Fi/Bluetooth when not in use, and check for background app activity in settings.
Cannot connect to Wi-Fi.	Ensure Wi-Fi is enabled, restart your router, or forget the network and reconnect.
Apps are running slowly.	Clear app caches (Settings > Apps > [App Name] > Storage > Clear cache), free up storage space, or restart the tablet.
Screen sensitivity issues.	Ensure the screen is clean and dry. If issues persist, a factory reset might be necessary (backup data first).

SPECIFICATIONS

Feature	Detail
Model Name	Onn 7" 2022 Model
Item Model Number	RM
Operating System	Android 12 (Go edition)
Screen Size	7 Inches
Screen Resolution	1024 x 600 Pixels
Processor	2.0 GHz Quad-core (MediaTek)
RAM	2 GB
Internal Storage	32 GB
Expandable Storage	microSD slot
Front Camera	2 MP
Rear Camera	2 MP
Wireless Type	802.11g
Average Battery Life	Up to 10 Hours
Color	Charcoal
Item Weight	1 pounds
Product Dimensions (LxWxH)	7.42 x 4.51 x 1 inches

WARRANTY AND SUPPORT

Return Policy

As a renewed product, this Onn Surf Tablet Gen 3 is covered by a 90-day refund/replacement return policy from the seller, Prime Mobility. Please refer to your purchase documentation for specific details and instructions on initiating a return or

replacement.

Protection Plans

Optional protection plans may be available for purchase to extend coverage beyond the standard return policy. For details on available plans, please refer to the product listing or contact the seller.

Customer Support

For technical assistance or further inquiries, please contact the seller, Prime Mobility, through the Amazon platform. You can typically find seller contact information in your order history.

© 2025 Onn. All rights reserved. Information subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question