

BesLowe D05088P

BesLowe Outdoor Pendant Light D05088P Instruction Manual

1. INTRODUCTION

Thank you for choosing the BesLowe Outdoor Pendant Light, Model D05088P. This modern hanging lantern is designed for both indoor and outdoor use, providing reliable illumination for porches, patios, entryways, and other spaces. Crafted from durable metal and clear glass, it features a weather-resistant design and adjustable hanging height for versatile installation. Please read this manual thoroughly before installation and operation to ensure safe and proper use.



Image 1.1: BesLowe Outdoor Pendant Light, Model D05088P, showcasing its sleek black finish and clear glass panels.

2. SAFETY INFORMATION

- **WARNING:** Risk of electric shock. Disconnect power at the fuse or circuit breaker before installation or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- Do not install this fixture in areas where it may be submerged in water.
- Ensure the fixture is securely mounted to a structural element capable of supporting its weight.
- Use only bulbs of the specified type and wattage to avoid overheating or damage.
- Do not handle the light fixture or attempt bulb replacement while power is connected or if the fixture is wet.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- 1 x BesLowe Outdoor Pendant Light Fixture
- Mounting Hardware (screws, wire nuts, mounting plate, chain)

4. SPECIFICATIONS

Feature	Specification
Brand	BesLowe
Model Number	D05088P
Color	Black
Material	Metal, Glass
Style	Modern
Light Fixture Form	Pendant
Indoor/Outdoor Usage	Indoor, Outdoor
Power Source	Hard-wired
Voltage	120 volts
Bulb Base	E26
Max Wattage	100 watts
Water Resistance Level	Waterproof
Mounting Type	Ceiling Mount
Item Dimensions (L x W x H)	5.38"L x 5.38"W x 66.5"H (Max)

5. INSTALLATION

This pendant light fixture comes pre-assembled with all necessary mounting accessories for a straightforward setup. Always ensure power is disconnected at the circuit breaker before beginning installation.

5.1. Adjusting Hanging Height

The fixture includes two 24-inch chains, allowing you to customize the hanging height. You can adjust the chain length by removing links to achieve your desired suspension. The durable metal chain is adaptable for both flat and sloped ceilings.

Easily Customize the Hanging Height



Image 5.1: Illustration of adjustable hanging height with chain and screw lock buckle.



Image 5.2: Dimensions and compatibility with various ceiling types.

5.2. Mounting the Fixture

1. **Prepare Wiring:** Carefully thread the electrical wires through the chain and canopy.
2. **Attach Mounting Plate:** Secure the sturdy mounting plate to your ceiling junction box using the provided screws.
3. **Make Electrical Connections:** Connect the fixture's wires to your household wiring according to local electrical codes. Typically, black to black (live), white to white (neutral), and bare copper/green to bare copper/green (ground). Use wire nuts to secure connections.
4. **Secure Canopy:** Tuck the wires into the junction box and push the canopy up against the ceiling, securing it with the provided hardware.
5. **Install Bulb:** Insert an E26 base bulb (not included) into the socket. The open-bottom design allows for easy bulb replacement.



Image 5.3: Key structural features for installation and maintenance.

6. OPERATION

Once installed and wired correctly, the BesLowe Outdoor Pendant Light operates via a standard wall switch (not included). Ensure the correct bulb type is installed for optimal performance.

6.1. Bulb Requirements

- **Bulb Base:** E26 (Standard Medium Base)
- **Maximum Wattage:** 100W
- **Compatible Bulb Types:** LED, CFL, Incandescent, Halogen, Flame, RGB bulbs.



Image 6.1: Compatible E26 base bulb types (bulbs not included).

7. MAINTENANCE

7.1. Cleaning

To clean the fixture, ensure power is disconnected. Wipe the metal frame with a soft, damp cloth. For the glass panels, use a glass cleaner if necessary, applying it to the cloth first, not directly to the fixture. Avoid abrasive cleaners or solvents that could damage the finish.

7.2. Bulb Replacement

The open-bottom design allows for easy bulb replacement. Ensure power is off and the bulb has cooled before attempting to remove or install a new bulb. Screw in the new E26 base bulb firmly but gently.

8. TROUBLESHOOTING

- Light does not turn on:

- Check if the power is on at the circuit breaker.
- Ensure the bulb is correctly installed and not burnt out.
- Verify all wire connections are secure.

- **Light flickers:**

- Ensure the bulb is screwed in tightly.
- Check for loose wire connections.
- Try a different bulb to rule out a faulty bulb.

- **Water inside fixture:**

- While the fixture is waterproof, extreme weather conditions or improper installation can sometimes lead to moisture. Disconnect power, allow to dry, and inspect for any gaps in sealing or mounting.

9. WARRANTY INFORMATION

This BesLowe Outdoor Pendant Light (Model D05088P) is covered by a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. It does not cover damage caused by improper installation, misuse, accidents, or unauthorized modifications. Please retain your proof of purchase for warranty claims.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to make a warranty claim, please contact BesLowe customer support through the retailer's platform or the official BesLowe website. Please have your model number (D05088P) and proof of purchase ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question