

Monster Monster N-Lite 208 (MH22211)

Monster N-Lite 208 Wireless Earbuds User Manual

Brand: **Monster** | Model: **N-Lite 208 (MH22211)**

1. INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your Monster N-Lite 208 Wireless Earbuds. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your product package:

- 1 x Pair of Monster N-Lite 208 Wireless Earbuds
- 1 x Charging Case
- 1 x USB-C Charging Cable
- 1 x Quick Start Guide
- 1 x Warning Card



Image: The package contents including the earbuds, charging case, USB-C cable, and documentation.

3. PRODUCT OVERVIEW

3.1 Earbuds and Charging Case

The Monster N-Lite 208 Wireless Earbuds feature a sleek design with a compact charging case for portability and extended battery life. Each earbud is equipped with a touch control area for easy operation.



Image: The Monster N-Lite 208 Wireless Earbuds, one removed from the open charging case, showcasing their design.

3.2 Sound Technology

These earbuds incorporate 13mm dynamic drivers designed to deliver a powerful and wide sound range, providing clear and balanced audio for an immersive listening experience.



Image: An exploded diagram illustrating the internal components of the earbud's 13mm dynamic driver, highlighting its construction for sound quality.

4. SETUP

4.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging port on the case and to a compatible USB power source. The charging case features a Type-C fast charging function.

- **Charging Time:** Approximately 1.5 hours for a full charge.
- **Earbud Playtime (Single Charge):** Up to 5 hours.
- **Total Playtime (with Charging Case):** Up to 30 hours.

Smart Touch Control



Image: The Monster N-Lite 208 charging case connected to a USB-C cable, illustrating the 30-hour total playtime and 1.5-hour charging duration.

4.2 Bluetooth Pairing

The earbuds utilize advanced Bluetooth 5.4 technology for a stable and low-latency connection.

1. Ensure the earbuds are charged.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for available Bluetooth devices and select "Monster N-Lite 208" from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

Bluetooth 5.4 Stable Connection



Strong
Signal



One Step
Pairing



Wide
Compatibility



Image: A smartphone displaying a successful Bluetooth 5.4 connection to the Monster N-Lite 208 earbuds, indicating strong signal and wide compatibility.

5. OPERATING INSTRUCTIONS

The Monster N-Lite 208 earbuds feature intuitive touch controls on each earbud. The touch control area is typically located on the outer surface of the earbud stem.

30 Hours Playing Time




Image: A diagram illustrating the various touch control functions on the Monster N-Lite 208 earbud, including volume, track control, call management, and voice assistant activation.

5.1 Music Control

- **Play/Pause:** Double-tap the touch control area on either the Left (L) or Right (R) earbud.
- **Next Track:** Triple-tap the touch control area on the Right (R) earbud.
- **Previous Track:** Triple-tap the touch control area on the Left (L) earbud.
- **Volume Up:** Slide up on the touch control area of either earbud.
- **Volume Down:** Slide down on the touch control area of either earbud.

5.2 Call Control

- **Answer Call:** Double-tap the touch control area on either earbud.
- **Hang Up Call:** Press and hold the touch control area on either earbud for 2 seconds.

5.3 Voice Assistant

- **Activate Voice Assistant:** Press and hold the touch control area on either earbud for 2 seconds (when not on a call).



Image: A person smiling while using the Monster N-Lite 208 earbuds to make a phone call, emphasizing the clear call feature.

6. WEARING INSTRUCTIONS

For optimal sound quality and comfort, ensure the earbuds are worn correctly.

1. Identify the Left (L) and Right (R) earbuds.
2. Gently insert each earbud into the corresponding ear canal.
3. Adjust the earbud until it fits snugly and comfortably in your ear, with the stem pointing downwards.



Image: A visual guide demonstrating the correct steps to wear the Bluetooth headphones for a secure and comfortable fit, alongside a person wearing them correctly.

7. MAINTENANCE

7.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Avoid getting moisture in any openings.

7.2 Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

8. TROUBLESHOOTING

If you encounter any issues with your Monster N-Lite 208 Wireless Earbuds, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing	• Ensure earbuds are charged. • Place earbuds back in the case, close, then reopen to re-enter pairing mode. • Turn off and on Bluetooth on your device. • Forget/delete "Monster N-Lite 208" from your device's Bluetooth list and try pairing again.
No sound from one earbud	• Ensure both earbuds are charged. • Try placing both earbuds back in the case and taking them out again. • Reset the earbuds (refer to Quick Start Guide for specific reset instructions if available).

Problem	Possible Solution
Charging case not charging	• Check the USB-C cable and power adapter for damage. • Ensure the cable is securely connected to both the case and the power source. • Try a different USB-C cable or power adapter.
Touch controls unresponsive	• Ensure your fingers are clean and dry. • Try restarting the earbuds by placing them in the case and taking them out.

9. SPECIFICATIONS

Feature	Specification
Model Name	Monster N-Lite 208
Item Model Number	MH22211
Wireless Communication Technology	Bluetooth 5.4
Audio Driver Size	13 Millimeters
Control Method	Touch
Charging Time	1.5 Hours
Playtime (Earbuds)	Up to 5 Hours
Total Playtime (with Case)	Up to 30 Hours
Power Source	Battery Powered
Connector Type	USB-C
Color	Dark Black
Item Weight	0.176 ounces (earbuds)
Compatible Devices	Smartphones, Laptops, Tablets, Bluetooth-enabled Devices

10. SAFETY INFORMATION

- **Hearing Protection:** Avoid listening at high volume levels for extended periods to prevent hearing damage.
- **Driving Safety:** Do not use earbuds while driving or cycling in situations where the inability to hear ambient sounds could pose a danger.
- **Water and Moisture:** Keep the earbuds and charging case away from water and excessive moisture.
- **Disposal:** Dispose of the product and batteries responsibly according to local regulations. Do not dispose of with household waste.

11. WARRANTY AND SUPPORT

Monster products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included in your package or visit the official Monster website. For technical support or customer service inquiries, please contact Monster customer support through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question