

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [E-YOOSO](#) /

› [E-YOOSO A68 Red Axis Low Profile Mechanical Keyboard User Manual](#)

E-YOOSO A68

E-YOOSO A68 Red Axis Low Profile Mechanical Keyboard User Manual

Model: A68

INTRODUCTION

Thank you for choosing the E-YOOSO A68 Red Axis Low Profile Mechanical Keyboard. This manual provides detailed instructions to help you set up, operate, and maintain your new keyboard. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Image: The E-YOOSO A68 Red Axis Low Profile Mechanical Keyboard, a compact and ergonomic design.

PACKAGE CONTENTS

Please check the package for the following items:

- E-YOOSO A68 Mechanical Keyboard
- USB-C Cable
- Keycap & Switch Puller
- Spare Switches (Red Axis)
- 2.4G Wireless Receiver
- User Manual

Note: Contents may vary slightly based on region or specific product bundle.

SETUP

Physical Setup

Place the keyboard on a stable, flat surface. The E-YOOSO A68 features 2-level adjustable kickstands on

the underside, allowing you to customize the typing angle for ergonomic comfort. Simply flip out the desired kickstand level to adjust.

Your browser does not support the video tag.

Video: Demonstrates the 2-level kickstand adjustment and the detachable USB-C cable connection on an E-YOOSO 82-key keyboard, which is similar in design to the A68 model.

Connectivity

The E-YOOSO A68 supports multiple connection modes:

- **Wired Mode:** Connect the keyboard to your computer using the provided USB-C cable. The keyboard will be automatically recognized.
- **2.4G Wireless Mode:** Locate the 2.4G wireless receiver (dongle) in the package. Plug the receiver into an available USB port on your computer. Switch the keyboard's connectivity toggle to "2.4G" mode. The keyboard should connect automatically.
- **Bluetooth Mode:** Switch the keyboard's connectivity toggle to "BT" mode. On your device (computer, tablet, smartphone), search for Bluetooth devices and select "E-YOOSO A68" to pair.

The keyboard features a convenient switch on the back to easily toggle between 2.4G wireless, OFF, and Bluetooth modes.

OPERATING INSTRUCTIONS

RGB Lighting Modes

The E-YOOSO A68 keyboard offers a vibrant RGB backlight with multiple preset lighting modes and effects. You can customize your typing experience with 16.8 million RGB colors and various dynamic lighting effects.

- **Change RGB Backlight:** Press the dedicated knob on the top right of the keyboard to cycle through different RGB lighting modes.
- **Adjust Backlight Effects:** Use the combination of **FN + INS** to change the RGB backlight color and **FN + DEL** to cycle through 16 different backlight effects.

Your browser does not support the video tag.

Video: Showcases the E-YOOSO mechanical keyboard's RGB lighting modes, including various preset patterns and color changes. It also demonstrates the anti-ghosting and N-key rollover features, hot-swappable switches, and water resistance.

Key Functions and Features

- **Anti-ghosting & N-Key Rollover:** The keyboard supports anti-ghosting for all 81 keys and N-key rollover, ensuring every keystroke is registered accurately, even during intense gaming sessions.
- **Volume Control Knob:** The multi-function knob on the top right can be used for volume control. Long press the knob for 3 seconds to switch between RGB backlight control and volume control functions.
- **Ergonomic Keycaps:** The ergonomically stepped keycaps are designed to fit your hands easily, reducing fatigue during prolonged use.

Hot-Swappable Switches

The E-YOOSO A68 features hot-swappable Outemu switches, allowing you to easily change switches without soldering. This provides flexibility to customize your typing feel. The PCB supports both 3-pin and 5-pin switches.

To replace a switch:

1. Use the keycap puller to gently remove the keycap.

2. Use the switch puller to carefully remove the switch from the PCB.
3. Align the pins of the new switch with the holes on the PCB and press firmly until it clicks into place.
4. Reattach the keycap.

Water Resistance

The keyboard is designed to be water-resistant, meaning accidental spills do not necessarily end your game or work session. However, it is always recommended to clean up spills immediately and avoid submerging the keyboard in water.

Sound Test

The E-YOOSO A68 is engineered for a satisfying typing sound, featuring 4 layers of sound-absorbing foams to enhance acoustics and provide a pleasant typing experience. The Red Axis switches offer a smooth and linear keystroke.

MAINTENANCE

Cleaning

To keep your keyboard in optimal condition:

- Regularly dust the keyboard using compressed air or a soft brush.
- For deeper cleaning, remove keycaps using the provided keycap puller and wipe them with a damp cloth.
- Clean the keyboard plate with a slightly damp cloth, ensuring no moisture enters the switches or electronics.
- Ensure the keyboard is completely dry before reattaching keycaps and using it.

Switch Replacement

As detailed in the "Hot-Swappable Switches" section, you can replace individual switches if they become faulty or if you wish to change the typing feel. Use the provided switch puller for safe removal and installation.

TROUBLESHOOTING

If you encounter any issues with your E-YOOSO A68 keyboard, please refer to the following common solutions:

- **Keyboard not responding:**
 - Ensure the USB cable is securely connected or the wireless receiver is properly plugged in.
 - Check the connectivity switch on the back of the keyboard to ensure it's in the correct mode (Wired, 2.4G, or BT).
 - For wireless modes, ensure the keyboard battery is charged.
 - Try connecting to a different USB port or device.
- **RGB backlight not working/incorrect:**
 - Press the knob or use FN+INS/FN+DEL combinations to cycle through lighting modes and effects.
 - Ensure the keyboard is not in a low-power mode if using wireless connectivity.

- **Keys not registering:**

- Check if the keycap or switch is properly seated. If not, remove and re-install.
- If a specific switch is faulty, replace it with a spare switch.

If the issue persists, please contact E-YOOSO customer support for further assistance.

SPECIFICATIONS

Model	A68
Switch Type	Red Axis (Low Profile, Hot-Swappable Outemu)
Keycaps	Double-shot Injection Molded PBT Keycaps
Layout	81-Key (Compact)
Connectivity	Wired (USB-C), 2.4G Wireless, Bluetooth
Backlight	RGB (16.8 Million Colors, 16 Effects)
Construction	Top Grade Metal and ABS
Features	Anti-ghosting, N-Key Rollover, Water Resistant, Adjustable Kickstands, Volume/RGB Knob, Sound-absorbing Foams

WARRANTY AND SUPPORT

E-YOOSO products come with a standard manufacturer's warranty. Please refer to the warranty card included in your package or visit the official E-YOOSO website for detailed warranty terms and conditions. For technical support, product inquiries, or warranty claims, please contact E-YOOSO customer service through their official website or the contact information provided in your product documentation.