



Manuals.plus /

- › OKD /
- › OKD 75 Inch Electric Fireplace TV Stand Instruction Manual

## OKD VSC75FP36P

# OKD 75 Inch Electric Fireplace TV Stand Instruction Manual

Model: VSC75FP36P

## INTRODUCTION

Thank you for purchasing the OKD 75 Inch Electric Fireplace TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read all instructions carefully before beginning assembly or use, and retain this manual for future reference.

## IMPORTANT SAFETY INFORMATION

**WARNING:** Failure to follow these safety guidelines may result in fire, electric shock, or injury.

- Always follow assembly instructions carefully.
- Do not exceed the weight limit of 300 lbs for the TV stand.
- Keep children and pets away from the fireplace area during operation.
- Never leave the fireplace unattended while in use.
- Always turn off the fireplace before leaving the room or going to sleep.
- Do not block the ventilation openings of the fireplace.
- Keep flammable materials at least 3 feet (0.9 meters) away from the fireplace.
- Ensure the power cord is not pinched or routed under the unit.
- This electric fireplace is equipped with overheat protection. If it overheats, it will automatically shut off.
- The product is ETL/FCC certified for safety.

## PRODUCT OVERVIEW

The OKD 75 Inch Electric Fireplace TV Stand is designed to accommodate TVs up to 85 inches, offering both functional storage and a realistic 3D flame electric fireplace. Its construction features high-quality engineered wood with a distressed finish.

### Key Features:

- **Dimensions:** 75" (W) x 17" (D) x 32" (H).
- **TV Compatibility:** Supports TVs up to 85 inches.

- **Storage:** Features an open highboy section, two widened drawers, and two storage cabinets with adjustable shelves. Includes a cable management hole.
- **Electric Fireplace:** 36-inch 3-sided glass display with 3D flame effect.
- **Heating:** 5118 BTUs, suitable for spaces up to 400 sq. ft. Temperature range 64°F to 82°F.
- **Flame Settings:** 3 flame colors, 5-speed flame adjustment, and adjustable brightness. Flame and heat can be controlled separately.
- **Controls:** Touch screen panel on the fireplace and a remote control (effective up to 19 feet).
- **Timer Function:** 1-9 hour timer to reduce energy consumption.
- **Durability:** Double top panels and a 4-inch thickened base, supporting up to 300 lbs.
- **Quality Components:** High-quality mute slide rails for drawers and cushioned anti-pinch hinges for cabinet doors.

## Product Dimensions and Features Visuals

# PRODUCT DIMENSIONS



Figure 1: Overall dimensions of the TV stand (75" W x 17" D x 32" H) and TV size compatibility.

# 75" 3D ELECTRIC FIREPLACE TV STAND



Distressed Finish Desktop



Realistic 3D Flame Fireplace



Smooth Widened Drawer



Spacious Storage Cabinet

Figure 2: Detailed view of the TV stand's features, including the distressed finish, realistic 3D flame, smooth widened drawers, and spacious storage cabinets.



Figure 3: Close-up of the distressed finish on the tabletop.



**Figure 4:** View of a smooth widened drawer with its metal slide rails.



**Figure 5:** Interior view of a spacious storage cabinet with adjustable shelving.

## ASSEMBLY INSTRUCTIONS

The OKD 75 Inch Electric Fireplace TV Stand requires assembly. It is shipped in two separate packages, which may not arrive simultaneously. Please ensure you have both packages before beginning assembly.

### Before You Begin:

- **Check Contents:** Verify all parts are present and undamaged by comparing them with the included parts list.
- **Tools Required:** Gather necessary tools as specified in the assembly manual (typically a screwdriver and hammer).
- **Clear Workspace:** Assemble the unit on a soft, clean surface to prevent scratches.
- **Assistance:** Assembly may be easier with two people.

### General Assembly Steps:

1. Follow the step-by-step instructions provided in the separate assembly manual. All parts are labeled for easy identification.
2. Carefully attach the main frame components using the provided hardware.

3. Install the drawers and ensure smooth operation of the slide rails.
4. Mount the cabinet doors, adjusting hinges for proper alignment and the anti-pinch function.
5. Insert the electric fireplace unit into the designated opening.
6. Ensure all connections are secure and the unit is stable before placing a TV or other items on it.



Figure 6: The assembled TV stand in a living room environment.

## OPERATING THE ELECTRIC FIREPLACE

The integrated 36-inch electric fireplace offers both aesthetic flame effects and supplemental heating. It can be controlled via the touch screen panel on the unit or the included remote control.

### Controls:

- **Power Button:** Turns the fireplace on or off.
- **Heat Button:** Activates or deactivates the heating function. Adjust temperature between 64°F and 82°F.
- **Flame Color Button:** Cycles through 3 elegant flame colors.

- **Flame Speed Button:** Adjusts the flame speed with 5 settings (P1-P5).
- **Brightness Button:** Adjusts the brightness of the flame effect.
- **Timer Button:** Sets an automatic shut-off timer from 1 to 9 hours.

### Using the Remote Control:

The remote control allows convenient operation from up to 19 feet away. Ensure there are no obstructions between the remote and the fireplace sensor. The buttons on the remote correspond to the functions on the fireplace's touch screen panel.

## 36" 3D FIREPLACE INSERT



**Power**



**Heat**  
5118 BTUS



**Flame**  
3 colors flame effect



**Timer**  
1-9 hours



**Brightness**  
L1-L5 flame rightness



**Speed**  
P1-P5 flame speed







**Control Panel**

The remote control has an effective range of up to 19 ft..

Figure 7: Electric fireplace control panel and remote control for adjusting settings.

- ☑ 36" Full View Fireplace
- ☑ Realistic 3D Flame & Heating



Figure 8: Example of the blue flame effect within the 3-sided glass display.

### Official Product Video:

Your browser does not support the video tag.

Video 1: Demonstrates the features and functionality of the OKD 75 Inch 3-Sided Electric Fireplace TV Stand, including flame effects, storage, and overall design.

## CARE AND MAINTENANCE

### TV Stand Care:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Placement:** Avoid placing the unit in direct sunlight or near heat sources to prevent warping or fading.
- **Weight Distribution:** Distribute weight evenly across the top surface and shelves to maintain stability.

## Electric Fireplace Care:

- **Cleaning:** Ensure the fireplace is turned off and unplugged before cleaning. Wipe the exterior with a soft, damp cloth. Do not spray water directly onto the unit.
- **Ventilation:** Periodically check that the air intake and exhaust vents are clear of dust and debris to ensure proper airflow and prevent overheating.
- **Light Bulbs:** The LED flame effect system is designed for long life (50,000 hours) and typically does not require bulb replacement.

## TROUBLESHOOTING

If you encounter issues with your OKD Electric Fireplace TV Stand, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord loose, circuit breaker tripped, unit overheated.	Ensure the unit is plugged into a working outlet. Check the power cord connection. Reset the circuit breaker. Allow the unit to cool down if it has overheated.
No heat output.	Heat function not activated, thermostat set too low, air vents blocked.	Press the heat button on the control panel or remote. Increase the temperature setting. Clear any obstructions from the air intake/exhaust vents.
Flame effect not working.	Flame effect not activated, internal issue.	Ensure the fireplace is powered on and the flame effect is activated. If the issue persists, contact customer support.
Remote control not working.	Dead batteries, remote out of range, obstruction, sensor blocked.	Replace batteries. Ensure you are within 19 feet of the unit and pointing the remote directly at the sensor. Remove any obstructions.
Unit is unstable after assembly.	Loose connections, uneven floor.	Re-tighten all screws and connections. Ensure the unit is placed on a flat, level surface.

If the problem persists after trying these solutions, please contact OKD Customer Support for further assistance.

## SPECIFICATIONS

Feature	Detail
Brand	OKD
Model Name	Fireplace TV Stand
Item Model Number	VSC75FP36P
Material	Engineered Wood
Color	Dark Rustic Oak
Style	Modern and Farmhouse
Product Dimensions	75 x 15.5 x 32 inches (W x D x H)
Item Weight	211 pounds
Max TV Size Supported	Up to 85 inches
Fireplace Size	36 inches (3-sided glass display)
Heat Output	5118 BTUs
Heating Area	Up to 400 sq. ft.
Temperature Range	64°F to 82°F
Flame Lifespan	50,000 hours
Safety Certifications	ETL/FCC
Max Weight Capacity	300 lbs

## CUSTOMER SUPPORT

For any questions, missing parts, or assistance with assembly or operation, please contact OKD Customer Support. Our team is dedicated to providing prompt and helpful service.

- **Assembly Instructions:** Simple and clear instructions with labeled parts are included with your product. If you require a digital copy or further clarification, please reach out.
- **Shipping:** Please note that the product is shipped in two packages and they may arrive separately.
- **Contact Information:** Refer to the contact details provided in your product packaging or visit the official OKD website for support options.