

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KINMATES](#) /

› [KINMATES TikTok Scrolling Ring & Page Turner \(Model T01\) - Instruction Manual](#)

KINMATES T01

KINMATES TikTok Scrolling Ring & Page Turner (Model T01) - Instruction Manual

Model: T01 | Brand: KINMATES

INTRODUCTION

This manual provides detailed instructions for the KINMATES TikTok Scrolling Ring and Page Turner, Model T01. This device offers hands-free control for various applications, including social media scrolling, e-book page turning, and remote camera operation. Please read this manual thoroughly before using your device.

PRODUCT OVERVIEW

The KINMATES T01 is a compact, wearable Bluetooth remote designed to enhance your digital experience. Its ergonomic ring design ensures comfortable use for extended periods.

- Hands-Free Scrolling:** Effortlessly navigate TikTok and other video apps.
- E-Book Page Turning:** Conveniently turn pages in compatible e-reading applications on iPads and Android tablets.
- Remote Camera Control:** Capture photos and videos remotely.
- Rechargeable:** Long-lasting battery with quick recharging.
- Portable Design:** Lightweight and comfortable for on-the-go use.

TikTok Scrolling Ring

A fun and convenient tool that makes scrolling through TikTok videos much easier, a must-have for avid TikTok users.



Image: The KINMATES TikTok Scrolling Ring, showing its compact size and accompanying charging case. The ring features a scroll wheel and a button.

WHAT'S IN THE BOX

- KINMATES TikTok Scrolling Ring (Model T01)
- Charging Case
- USB-C Charging Cable
- User Manual

SETUP

1. Charging the Device

Before first use, fully charge the scrolling ring. Place the ring into its charging case and connect the USB-C cable to a power source. The indicator light on the case will show charging status.

Roller Design

Unlike traditional buttons, the roller design offers smoother, more convenient scrolling, making transitions between videos effortless and comfortable.



VS



Image: Illustration showing the KINMATES Scrolling Ring in its charging case, connected via USB-C cable, with battery indicators. The text highlights fast charging and ultra-long battery life.

2. Bluetooth Pairing

1. Ensure your device (smartphone or tablet) has Bluetooth enabled.
2. Take the scrolling ring out of its charging case. It will automatically enter pairing mode.
3. On your device, go to Bluetooth settings and select "T01" or a similar name to connect.
4. For iOS devices, ensure AssistiveTouch is enabled for full functionality:
 - Go to **Settings > Accessibility > Touch > AssistiveTouch**.
 - Toggle **AssistiveTouch** to ON.

Bluetooth Connection



Image: A smartphone screen displaying Bluetooth settings with the KINMATES T01 device listed as connected, alongside the scrolling ring and its charging case.

Easy to hold with Ring Design

Ergonomic design ensures comfort and ease of use, perfect for extended reading sessions or TikTok time



Image: Screenshots illustrating the steps to enable AssistiveTouch on iOS devices: Settings > Accessibility > Touch > AssistiveTouch.

3. Mode Switching

The KINMATES T01 supports different operating modes. If your device is not responding as expected, you may need to switch modes. Long-press the up and down buttons simultaneously until the indicator light flashes purple three times. This action cycles through available modes.

Your browser does not support the video tag.

Video: A setup guide for the KINMATES T01 Scrolling Ring, demonstrating how to pair the device and switch between different operating modes for optimal functionality.

OPERATING INSTRUCTIONS

The KINMATES T01 features a roller design for intuitive control. Wear the ring comfortably on your finger.



Image: A close-up view of the KINMATES Scrolling Ring, highlighting its ergonomic ring design and the scroll wheel for easy operation.

1. TikTok and Short Video Scrolling

- **Scroll Up/Down:** Use the scroll wheel to move through videos.
- **Like/Interact:** Press the main button (often a double-tap or single press depending on app settings) to like videos or interact with posts.
- **Volume Control:** Use the side button for adjusting media volume.



Image: A person relaxing while using the KINMATES Scrolling Ring to navigate TikTok videos on a smartphone, demonstrating hands-free operation.

2. E-Book Page Turning

The ring functions as a page turner for compatible e-book applications on iPad and Android tablets. **Note: Not suitable for Kindle devices (e.g., Paperwhite, Oasis, Scribe).**

- **Turn Page Forward/Backward:** Use the scroll wheel to navigate through pages.
- **Mute Function:** The mute button ensures quiet operation, ideal for reading without disturbing others.

Page Turner for iPad & Android Tablet Ebook Reading

Effortlessly turn pages with a simple button scroll, significantly enhancing your reading experience.



Image: A person comfortably reading an e-book on a tablet, using the KINMATES Scrolling Ring for hands-free page turning.

3. Remote Camera Control

Use the ring to remotely trigger your device's camera for photos and videos.

- **Take Photo:** Press the main button once.
- **Start/Stop Video Recording:** Press and hold the main button (functionality may vary by app).

Page Turner for iPad & Android Tablet Ebook Reading

Tips: not for Kindle devices like Paperwhite, Oasis, and Scribe...



Image: A family on a beach taking a group photo using the KINMATES Scrolling Ring as a remote camera control, illustrating its use for selfies and group shots.

MAINTENANCE

1. Charging

The ring and its charging case are equipped with rechargeable batteries. The charging box can fully charge the ring approximately 5 times. Once fully charged, the ring can operate for up to 12 hours.

- Connect the provided USB-C cable to the charging case and a compatible power adapter.
- Ensure the ring is properly seated in the charging case for optimal charging.

2. Cleaning and Care

- Wipe the device with a soft, dry cloth.
- Avoid exposing the device to extreme temperatures, moisture, or harsh chemicals.
- Store the device in its charging case when not in use to protect it and keep it charged.

TROUBLESHOOTING

Problem	Solution
Device does not turn on or respond.	Ensure the device is charged. Place it in the charging case and connect to power.
Unable to pair via Bluetooth.	<ul style="list-style-type: none">• Ensure Bluetooth is enabled on your phone/tablet.• Restart the scrolling ring and your device.• Forget the device in your Bluetooth settings and try pairing again.
Scrolling or button functions not working on iOS.	Verify that AssistiveTouch is enabled in your iOS Accessibility settings (Settings > Accessibility > Touch > AssistiveTouch).
Device performs unexpected actions (e.g., makes calls).	The device might be in an incorrect mode. Long-press the up and down buttons simultaneously until the indicator light flashes purple three times to switch modes.

Problem	Solution
Page turning not working on Kindle.	The KINMATES T01 is not compatible with Kindle devices. It works with e-book apps on iPads and Android tablets.

SPECIFICATIONS

Model Number	T01
Brand	KINMATES
Connectivity	Bluetooth
Compatible Devices	Smartphones, Tablets (iOS 14.8 or later for iPhone/iPad)
Special Features	TikTok Scrolling, E-book Page Turning, Remote Camera Control
Item Weight	3.52 ounces
Power Source	Rechargeable Battery (USB-C)
Battery Life (Ring)	Up to 12 hours on a single charge
Charging Case Capacity	Provides up to 5 full charges for the ring

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official KINMATES website. Keep your purchase receipt for warranty claims.