Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM VSC8DRSC-ABW

T4TREAM Farmhouse 8 Drawers Dresser User Manual

Model: VSC8DRSC-ABW

1. Introduction

This manual provides essential information for the assembly, safe use, and maintenance of your T4TREAM Farmhouse 8 Drawers Dresser. Designed with a blend of retro aesthetics and natural wood textures, this dresser offers significant storage capacity and a vintage design suitable for various interior styles. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Figure 1.1: The T4TREAM Farmhouse 8 Drawers Dresser in a room setting, showcasing its distressed white finish and eight drawers with antique-style handles.

2. Safety Information

Your safety is paramount. Please adhere to the following guidelines:

- **Anti-Toppling Device:** This dresser is equipped with an anti-toppling device. It is crucial to install this device securely to a wall to prevent accidental tipping, especially in households with children or pets. Failure to install this device can result in serious injury or death.
- **Weight Capacity:** Do not overload drawers or the top surface. Refer to the specifications section for weight limits.
- **Assembly:** Assembly requires two people for safety and ease. Follow all instructions carefully.
- **Placement:** Place the dresser on a level, stable surface.
- **Children:** Do not allow children to climb on or play with the dresser or its drawers.



Figure 2.1: Illustration detailing the dresser's dimensions (54"W x 15.5"D x 31.2"H) and the importance of installing the anti-toppling device to ensure stability and prevent tipping.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. The package typically includes:

- All necessary wood panels (top, sides, back, drawer fronts, drawer sides, drawer bottoms).
- Eight (8) drawer handles and corresponding screws.
- Drawer slides and mounting hardware.
- Cam locks, dowels, screws, and other fasteners.
- Anti-toppling device with wall anchors and screws.
- Assembly instructions manual.
- Small wrench or hex key (if required for specific fasteners).

If any parts are missing or damaged, please contact customer support immediately.

4. Setup and Assembly

Assembly of the T4TREAM Farmhouse 8 Drawers Dresser requires patience and careful attention to the provided instructions. It is strongly recommended that **two adults** perform the assembly to ensure safety and efficiency.

4.1 Preparation

- Clear a spacious, clean, and well-lit area for assembly.
- Lay out all parts on a soft, protective surface (e.g., a blanket or cardboard) to prevent scratches.
- Identify all parts using the labels and the parts list in the separate assembly guide.
- Gather necessary tools: Phillips head screwdriver, hammer, and possibly a power drill (use with caution and appropriate settings).

4.2 Assembly Steps

1. Begin by assembling the main frame of the dresser according to the step-by-step instructions provided in the separate assembly manual. Ensure all cam locks and screws are tightened securely.
2. Attach the drawer slides to the dresser frame, paying close attention to their orientation (left/right, top/bottom).
3. Assemble each of the eight drawers. This typically involves attaching the front, back, and side panels to the drawer bottom, then installing the drawer slides.
4. Install the decorative handles onto each drawer front.
5. Carefully insert the assembled drawers into the dresser frame, ensuring they slide smoothly.
6. **Install the Anti-Toppling Device:** Securely attach the anti-toppling device to the back of the dresser and then to a wall stud using the provided hardware. This step is critical for safety.

Refer to the detailed graphical instructions in your assembly guide for precise steps and diagrams.

5. Operating (Usage)

The T4TREAM Farmhouse 8 Drawers Dresser is designed for organized storage in bedrooms and living rooms.

5.1 Drawer Usage

- Each of the eight drawers is designed to hold clothing, linens, or other personal items.
- To open a drawer, gently pull the handle. To close, push firmly until it is fully seated.
- Avoid forcing drawers open or closed, as this can damage the slides or the drawer structure.
- Distribute weight evenly within drawers to prevent strain on the slides.



Figure 5.1: Two open drawers of the dresser, illustrating the storage capacity for folded clothing and textiles.

5.2 Top Surface Usage

- The spacious tabletop can be used to display decorative items such as lamps, framed photos, or small plants.
- Ensure items placed on the top surface are stable and do not exceed the recommended weight capacity.
- Avoid placing hot items directly on the surface without protective coasters.



Figure 5.2: The dresser positioned in a bedroom, with a television and various decorative items placed on its top surface, demonstrating its functional use.



Figure 5.3: An overhead perspective of the dresser's top surface, highlighting its distressed finish and the space available for displaying personal items.

6. Maintenance

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Humidity:** Maintain a stable humidity level in the room to prevent wood from warping or cracking.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.

7. Troubleshooting

If you encounter issues with your dresser, refer to the following common problems and solutions:

- **Drawers do not close smoothly or are misaligned:**
  - Check that the drawer slides are correctly installed and aligned on both the drawer and the dresser frame.
  - Ensure all screws securing the slides are tight.
  - Verify that the drawer bottom is properly seated and not warped.
  - Confirm that the dresser frame itself is level and square.
- **Dresser feels wobbly or unstable:**
  - Ensure all assembly fasteners (cam locks, screws) are fully tightened.
  - Verify that the dresser is placed on a flat, level surface.
  - Confirm that the anti-toppling device is securely installed to both the dresser and a wall stud.
- **Missing or damaged parts:**
  - Carefully re-check all packaging materials.
  - Contact T4TREAM customer support with your model number and a description of the missing/damaged part.

8. Specifications

Feature	Detail
Brand	T4TREAM
Model Name	VSC8DRSC-ABW
Product Dimensions	15.5"D x 54"W x 31.2"H
Color	Distressed White
Room Type	Bedroom, Living Room
Number of Drawers	8
Drawer Depth	4 inches (internal)
Item Weight	125 Pounds
Assembly Required	Yes (Two-person recommended)
Material	FSC-Certified Wood Materials

9. Warranty Information

Specific warranty details for the T4TREAM Farmhouse 8 Drawers Dresser are not provided in the available product information. For warranty inquiries, please contact T4TREAM customer support directly.

10. Customer Support

For further assistance, questions, or to report missing/damaged parts, please contact T4TREAM customer support. You can often find contact information on the brand's official website or through the retailer where the product was purchased.
Visit the official T4TREAM Store for more information: T4TREAM Furniture Store

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DLLCH9C4

More documents and user manuals: **https://manuals.plus/**