

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Care Bears](#) /

› [Care Bears Wireless Speaker - Grumpy Bear \(Model: CBSPKGRB101-MFN\) Instruction Manual](#)

Care Bears CBSPKGRB101-MFN

Care Bears Wireless Speaker - Grumpy Bear (Model: CBSPKGRB101-MFN) Instruction Manual

Your guide to setting up and using your portable Bluetooth speaker.

INTRODUCTION

This manual provides comprehensive instructions for the Care Bears Wireless Speaker, featuring the Grumpy Bear design (Model: CBSPKGRB101-MFN). This compact and portable Bluetooth speaker is designed for audio playback from compatible devices. It includes a rechargeable battery for on-the-go use and Bluetooth 5.2 for stable wireless connectivity.

Key features include:

- **Rechargeable & Portable:** Equipped with a 300 mAh battery, offering up to 4 hours of playtime and a 2-hour recharge time.
- **Grumpy Bear Design:** A unique design for visual appeal.
- **High-Quality Sound:** Features a 3W speaker driver for clear audio.
- **Bluetooth 5.2 Connectivity:** Provides stable wireless streaming up to 33 feet.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Care Bears Wireless Speaker (Grumpy Bear)
- USB Power Cable
- User Manual (this document)



Image: Packaging of the Grumpy Bear Wireless Speaker, highlighting its features and design.

SETUP

1. Charging the Speaker

1. Locate the charging port on the speaker.
2. Connect the provided USB power cable to the speaker's charging port.
3. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate. A full charge takes approximately 2 hours.
5. Once fully charged, the indicator light may change color or turn off. Disconnect the speaker from the power source.

Note: Ensure the speaker is fully charged before first use for optimal battery life.

2. Powering On/Off

- To power on, press and hold the power button (location may vary, typically on the back or bottom) for a few seconds until an indicator light illuminates and/or an audible tone is heard.
- To power off, press and hold the power button again for a few seconds until the indicator light turns off and/or an audible tone is heard.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and within 33 feet (10 meters) of your Bluetooth-enabled device.
2. The speaker will automatically enter pairing mode, indicated by a flashing LED light (e.g., blue).
3. On your device (smartphone, tablet, computer), go to the Bluetooth settings.
4. Search for available devices. The speaker should appear as "Care Bears Speaker" or similar.
5. Select the speaker from the list to initiate pairing.
6. Once successfully paired, the speaker will emit an audible confirmation, and the LED indicator light will typically become solid.

Note: If prompted for a password, enter "0000". The speaker will automatically reconnect to the last paired device when powered on, if that device's Bluetooth is active and within range.



Image: The Grumpy Bear Wireless Speaker, ready for use.

OPERATING INSTRUCTIONS

1. Playing Audio

- After successful Bluetooth pairing, open your preferred audio application on your connected device.
- Start playing music or other audio content. The sound will be routed through the Care Bears Wireless

Speaker.

2. Volume Control

- Volume is primarily controlled via your connected Bluetooth device. Adjust the volume on your smartphone, tablet, or computer.
- The speaker itself may have touch controls for volume adjustment (refer to specific product markings if present).

3. Call Handling (if applicable)

If the speaker supports hands-free calling (check product specifications), you may be able to:

- **Answer/End Call:** Press the multi-function button (often the power button or a dedicated call button) once.
- **Reject Call:** Press and hold the multi-function button for 2 seconds.



Image: The Grumpy Bear Wireless Speaker in a typical usage environment.

MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners, alcohol, or chemical solvents.

- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, fully charge the speaker at least once every three months if not in regular use. Avoid fully discharging the battery frequently.
- **Water Exposure:** This speaker is not waterproof. Avoid exposure to water or excessive moisture.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB cable and allow it to charge for at least 15 minutes before attempting to power on again.
No sound from the speaker.	<ul style="list-style-type: none"> • Check if the speaker is properly paired with your device. • Increase the volume on both the speaker and your connected device. • Ensure the audio source on your device is playing. • Try unpairing and re-pairing the speaker with your device.
Bluetooth pairing fails.	<ul style="list-style-type: none"> • Ensure the speaker is in pairing mode (flashing LED). • Make sure Bluetooth is enabled on your device. • Move the speaker closer to your device (within 33 feet). • Turn off other Bluetooth devices nearby to avoid interference. • Restart both the speaker and your Bluetooth device.
Poor audio quality or intermittent connection.	<ul style="list-style-type: none"> • Ensure there are no obstructions between the speaker and your device. • Move away from sources of interference (e.g., Wi-Fi routers, microwaves). • Ensure the speaker is fully charged. • Try moving your device closer to the speaker.

SPECIFICATIONS

Model Name	Care Bears Wireless Speaker - Grumpy Bear
Model Number	CBSPKGRB101-MFN
Brand	Care Bears
Connectivity Technology	Bluetooth 5.2
Bluetooth Range	Up to 33 feet (10 meters)
Speaker Output Power	3W
Audio Output Mode	Stereo
Battery Capacity	300 mAh

Playtime	Up to 4 hours
Recharge Time	Approximately 2 hours
Control Method	Touch
Product Dimensions	4.5"D x 5"W x 6"H
Item Weight	13.9 ounces
Material	Plastic
Manufacturer	Southern Telecom
UPC	680079024796

Note: Specifications are subject to change without notice.

WARRANTY INFORMATION

This product comes with a **Limited Warranty**. The specific terms and duration of the warranty are provided by the manufacturer, Southern Telecom. Please retain your proof of purchase for any warranty claims. The warranty typically covers manufacturing defects and malfunctions under normal use. It generally does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact the manufacturer:

Manufacturer: Southern Telecom

Please refer to the contact information provided on the product packaging or the manufacturer's official website for the most current support details.