Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jazwares HKT0868

Hello Kitty and Friends 2025 Holiday Advent Calendar

INSTRUCTION MANUAL - MODEL HKT0868

Introduction

This manual provides instructions for the proper setup, operation, and care of your Hello Kitty and Friends 2025 Holiday Advent Calendar. This product is designed to provide daily surprises leading up to the holiday season, featuring collectible figures and accessories.

Recommended Age: 6 years and up.

Product Overview

The Hello Kitty and Friends 2025 Holiday Advent Calendar contains 24 unique surprises, including 18 collectible 2-inch figures, 18 accessories, and 6 festive decorations. Characters featured include Hello Kitty, My Melody, Kuromi, Cinnamoroll, Pompompurin, Keroppi, Batz-maru, and Tuxedo Sam.



Figure 1: Front of the Advent Calendar packaging.

Setup

1. **Unboxing:** Carefully remove the advent calendar from its outer packaging.
2. **Positioning:** Place the advent calendar on a flat, stable surface where it can be easily accessed daily.
3. **Prepare the Scene:** Locate the included Pop Off Card. This card can be detached and used to create a festive backdrop for your figures and accessories. Follow the perforations to carefully remove the card.



Figure 2: Rear view of the Advent Calendar, illustrating the numbered doors for daily opening.



Figure 3: Example of a holiday scene created using the Pop Off Card and collected items.

Operating (Daily Use)

1. **Daily Surprise:** Starting on the first day of your countdown, locate the door marked with the corresponding number.
2. **Open Door:** Gently press or tear along the perforations of the numbered door to open it.
3. **Retrieve Item:** Carefully remove the surprise item from inside the compartment.
4. **Display and Play:** Add your new figure, accessory, or decoration to your holiday scene. Many accessories are designed to be held by the figures, allowing for mix-and-match customization.



Figure 4: All figures, accessories, and decorations included in the calendar.

Maintenance

- **Cleaning:** To clean figures and accessories, gently wipe with a soft, dry cloth. For stubborn dirt, a slightly damp cloth may be used, followed by immediate drying. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store figures and accessories in a cool, dry place away from direct sunlight to prevent fading or damage.
- **Handling:** Handle figures and accessories with care to avoid breakage, especially small parts.

Troubleshooting

- **Missing Item:** If an item is missing from a compartment, double-check the packaging and surrounding area. If still missing, contact customer support.
- **Damaged Item:** In the event of a damaged item, please retain all packaging and contact customer support for assistance.

- **Cardboard Accessories:** Some accessories are made of cardboard. Handle these with extra care to prevent bending or tearing.

Specifications

Brand	Jazwares
Model Number	HKT0868
UPC	191726901105
Item Type	Figures
Material Type	Plastic
Number of Pieces	42 (18 figures, 18 accessories, 6 decorations)
Item Dimensions (L x W x H)	1 x 1 x 1 inches (individual figure/accessory, approximate)
Item Weight	1.65 Kilograms (total package)
Assembly Required	No
Batteries Required	No

Safety Information

No specific safety warnings are applicable beyond the recommended age of 6 years and up. This product contains small parts which may pose a choking hazard for children under 3 years of age. Adult supervision is recommended during play.

Warranty and Support

This product is manufactured by Jazwares, LLC. For any questions, concerns, or support regarding your Hello Kitty and Friends Advent Calendar, please contact Jazwares customer service directly. Please refer to the product packaging for the most current contact information or visit the official Jazwares website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DLLL4689

More documents and user manuals: **https://manuals.plus/**