



[Manuals.plus](#) /

› [Honeywell](#) /

› Honeywell F2 Sunturalux™ 3000LM LED Floor Lamp Instruction Manual

Honeywell HWL-F2WT

Honeywell F2 Sunturalux™ 3000LM LED Floor Lamp Instruction Manual

Model: HWL-F2WT | Brand: Honeywell

1. INTRODUCTION

Thank you for choosing the Honeywell F2 Sunturalux™ 3000LM LED Floor Lamp. This versatile 2-in-1 torchiere floor lamp is designed to provide optimal lighting for various environments, from ambient room illumination to focused task lighting. Featuring remote and touch control, adjustable color temperatures (2700K-5000K), and 6 dynamic RGB modes, this lamp offers a customizable lighting experience. Its eye-caring full-spectrum LEDs ensure comfortable and healthy vision.



Image: The Honeywell F2 Sunturalux LED Floor Lamp, showcasing its sleek design and included remote control.

2. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not operate the lamp with a damaged cord or plug.
- Ensure the lamp is placed on a stable, level surface to prevent tipping.
- Do not expose the lamp to water or moisture. This product is not water resistant.
- Keep the lamp away from heat sources and direct sunlight.
- Do not attempt to disassemble or modify the lamp. There are no user-serviceable parts inside.
- Unplug the lamp from the power outlet before cleaning or when not in use for extended periods.
- This lamp is for indoor use only.

3. PACKAGE CONTENTS

Verify that all components are present before assembly:

- Floor Lamp (main unit)
- Remote Control
- Power Adapter
- Assembly accessories (screws, Allen wrench)
- User Manual

4. ASSEMBLY INSTRUCTIONS

Assembly of the Honeywell F2 Floor Lamp is straightforward. Follow these steps:

1. Align the lamp head with lamp pole 1 and secure it with screw A.
2. Align lamp pole 1 with lamp pole 2 and secure it with screw B.
3. Tighten lamp pole 2 with lamp pole 3.
4. Tighten lamp pole 3 with lamp pole 4.
5. Align lamp pole 4 with the base and tighten it.
6. Connect the power adapter to the lamp's power input port located at the base.
7. Plug the power adapter into a standard wall outlet.



Image: Visual guide illustrating the five steps to assemble the Honeywell F2 Floor Lamp, from attaching the head to the base.

Assembly Video

Video: An official product video from Honeywell Smart Lighting demonstrating the assembly process and various lighting modes of the floor lamp.

5. OPERATING INSTRUCTIONS

5.1. Adjusting Light Direction

The lamp head can be tilted from 85° to 270° and rotated to direct light as needed. This 2-in-1 design allows for both upright (torchiere effect) for ambient room lighting and downlight for focused tasks like reading or working.

2-IN-1 ADJUSTABLE BEAM 3000LM UP & DOWN LIGHT



Image: The lamp head demonstrating its adjustable tilt range for both uplighting and downlighting.

5.2. Control Methods

The lamp can be controlled using either the included remote control or the integrated touch control panel on the lamp pole.

Remote Control

The remote control allows you to adjust settings from up to 32 feet away. Functions include:

- **On/Off:** Power the lamp on or off.
- **Brightness +/-:** Adjust the main light brightness (stepless dimming from 5% to 100%).
- **Color Temperatures +/-:** Cycle through 5 white light color temperatures (2700K warm to 5000K crisp daylight).
- **RGB Light On/Off:** Turn the RGB ambient light on or off.
- **RGB Gradient Mode:** Activate a smooth color transition effect.
- **Pre-set Modes:** Select from 6 dynamic RGB lighting effects: Movie Mode, Game Mode, Reading Mode, Leisure Mode, RGB Color Changing Mode.

Touch Control

A touch-sensitive panel is located on the lamp pole for convenient manual adjustments:

- **On/Off:** Tap to power on/off.
- **Color Temperature Cycle:** Tap to cycle through white light color temperatures.
- **Smooth Brightness Dimming:** Long press to smoothly adjust brightness.
- **RGB Mode Adjustment:** Tap to cycle through RGB modes.



Image: The remote control and the touch-sensitive control panel on the lamp pole, detailing their respective functions.

5.3. Brightness and Color Temperature

The main light offers stepless brightness adjustment from 5% to 100% and 5 color temperature settings (2700K, 3500K, 4000K, 5000K, 5700K) to suit your preference.

EYE-FRIENDLY LIGHTING FOR READING

Large Light Panel Lighting Radiates Throughout The Living Room



Image: Examples of the lamp's 5 adjustable color temperatures and its stepless dimming capability.

5.4. RGB Lighting Modes

The lamp features 6 dynamic RGB lighting effects to create various atmospheres:

- Gradient Flow
- Gentle Breathing
- Chill Viewing Mode
- Focused Reading Mode
- Energizing Game Mode
- Pure Relaxation Mode

You can also adjust the brightness and speed of the colors within these modes.

6 DIFFERENT COMBINATIONS OF RGB LIGHTING CREATE THE PERFECT AMBIENCE



Image: Visual representations of the 6 distinct RGB lighting modes, demonstrating their application in different room settings.

6. KEY FEATURES

- **2-in-1 Manual Uplight/Downlight:** The lamp head can be positioned straight up for a torchiere effect, bouncing soft, ambient light off the ceiling, or bent down for focused task lighting. The head tilts from 85° to 270° for multiple angles.
- **Super Bright Illumination:** Equipped with 180 high-quality Sunturalux Full Spectrum LEDs, delivering a powerful 3000 lumens. The large 10.8-inch light panel provides wide, even light distribution.
- **Eye-Caring Technology:** Full-spectrum LEDs offer natural, sunlight-like quality (CRI≥92) for accurate colors and reduced eye strain. Features RG0 (blue light safe) and anti-strobe technology for healthy vision during extended use.
- **Convenient Control:** Operate the lamp with the included remote control (up to 32 feet range) or the integrated touch control panel on the pole.
- **Customizable Ambiance:** Choose from 5 white light color temperatures (2700K-5000K) and 6 vibrant RGB color modes to match any mood or activity.
- **Memory Function:** The lamp remembers your last brightness setting when turned off and on.

7. PRODUCT SPECIFICATIONS

Feature	Specification
Model Name	HWL-F2WT
Brand	Honeywell
Light Source Type	LED (180 Sunaturalux Full Spectrum LEDs)
Brightness	3000 Lumens (Max)
Wattage	40 watts
Color Temperature	2700K-5000K (5 levels)
RGB Modes	6 dynamic modes
Control Method	Remote, Touch
Remote Range	Up to 32 feet
Product Dimensions	17.5"D x 5.59"W x 13.7"H
Item Weight	10.23 pounds (4.65 Kilograms)
Material	Iron, Aluminum, ABS, PC
Power Source	Corded Electric
Assembly Required	Yes

8. MAINTENANCE

To ensure the longevity and optimal performance of your Honeywell F2 Floor Lamp, follow these maintenance guidelines:

- **Cleaning:** Always unplug the lamp before cleaning. Use a soft, dry cloth to wipe down the lamp's surfaces. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or electronic components.
- **LEDs:** The LED light source is integrated and not user-replaceable. Do not attempt to replace the LEDs.
- **Storage:** If storing the lamp for an extended period, unplug it and store it in a cool, dry place, preferably in its original packaging to protect it from dust and damage.

9. TROUBLESHOOTING

If you encounter any issues with your lamp, refer to the following common problems and solutions:

- **Lamp does not turn on:**
 - Ensure the power adapter is securely plugged into both the lamp and a working wall outlet.
 - Check if the wall outlet is functioning by plugging in another device.
 - Verify that the remote control battery is not depleted.
- **Remote control is not responding:**

- Check and replace the remote control battery if necessary.
- Ensure there are no obstructions between the remote and the lamp.
- Try operating the lamp using the touch control panel to confirm lamp functionality.

- **Light flickers or is inconsistent:**

- Ensure the power connection is stable and secure.
- Avoid plugging the lamp into an outlet controlled by a dimmer switch not designed for LED lighting.

If the problem persists after trying these solutions, please contact customer support.

10. WARRANTY AND SUPPORT

This Honeywell F2 Sunturalux™ 3000LM LED Floor Lamp comes with a **2-year manufacturer's warranty**. For warranty claims, technical support, or any inquiries regarding your product, please refer to the contact information provided in your product packaging or visit the official Honeywell Smart Lighting website.

Please retain your proof of purchase for warranty purposes.