

## CAL 8B

# Generic CAL 8B Calculagraph 8 Channel Digital Reminder Chef Timing User Manual

## 1. INTRODUCTION

---

This manual provides essential information for the proper setup, operation, and maintenance of your Generic CAL 8B Calculagraph 8 Channel Digital Reminder Chef Timing device. Please read these instructions carefully before using the product to ensure safe and efficient operation.

## 2. PRODUCT OVERVIEW

---

The Generic CAL 8B Calculagraph is an 8-channel digital timer designed for professional kitchen environments, offering precise timing for multiple tasks simultaneously. It features a durable stainless steel frame and intuitive touch controls.

### Key Features:

- Durable stainless steel frame construction.
- Eight independent digital display windows for simultaneous timing.
- Each time window can be set independently for reminder functions.
- Time setting range from 0 to 99 minutes and 59 seconds.
- User-friendly touch buttons for control.

### Components:

- CAL 8B Digital Timer Unit
- Power Cord
- Mounting Brackets (2 pieces)



Figure 2.1: The CAL 8B Digital Timer unit, including its power cord and two mounting brackets.

### 3. SETUP

---

Follow these steps to set up your CAL 8B Digital Timer:

1. **Unpacking:** Carefully remove all components from the packaging. Verify that all items listed in the "Components" section are present.
2. **Mounting (Optional):** If desired, use the provided mounting brackets to secure the timer to a suitable surface. Ensure the surface is stable and can support the device.
3. **Power Connection:** Connect the power cord to the timer unit and then plug it into a standard 220V 50/60Hz electrical outlet. The timer will power on automatically.



Figure 3.1: The CAL 8B Digital Timer showing the power cord connection and mounting brackets.

#### 4. OPERATING INSTRUCTIONS

---

The CAL 8B features eight independent timing channels, each with its own digital display. The control panel includes touch buttons for setting and managing timers.



Figure 4.1: Close-up of the CAL 8B control panel, highlighting the 8 digital displays and control buttons.

### Control Panel Buttons:

- **TIME:** Used to select a specific channel for time setting.
- **REMINDER:** Activates or deactivates the reminder function for the selected channel.
- **ON/OFF:** Powers the unit on or off, or starts/stops a timer.
- **INCREASE (▲):** Increases the time value during setting.
- **DECREASE (▼):** Decreases the time value during setting.

### Setting a Timer:

1. **Select Channel:** Press the **TIME** button repeatedly until the desired channel (1-8) is selected. The display for the selected channel may flash or indicate it's ready for input.
2. **Set Time:** Use the **INCREASE (▲)** and **DECREASE (▼)** buttons to set the desired time in minutes and seconds. The time can be set from 00:00 to 99:59.
3. **Start Timer:** Once the time is set, press the **ON/OFF** button to start the countdown for that channel.
4. **Reminder Function:** To enable or disable the reminder for a channel, select the channel using the **TIME** button and then press the **REMINDER** button.
5. **Stopping a Timer:** To stop a running timer, select the channel and press the **ON/OFF** button.

## 5. MAINTENANCE

---

Proper maintenance ensures the longevity and optimal performance of your CAL 8B Digital Timer.

- **Cleaning:** Wipe the stainless steel frame and control panel with a soft, damp cloth. Avoid using abrasive cleaners or solvents, which can damage the surface or electronic components.
- **Storage:** When not in use for extended periods, store the timer in a clean, dry place away from direct sunlight and extreme temperatures.
- **Power Cord:** Regularly inspect the power cord for any signs of damage. If the cord is damaged,

discontinue use and contact support.

## 6. TROUBLESHOOTING

---

If you encounter issues with your CAL 8B Digital Timer, please refer to the following common solutions:

- **Device Not Powering On:**

- Ensure the power cord is securely plugged into both the timer and a functional 220V electrical outlet.
- Check if the outlet is receiving power by plugging in another device.

- **Timer Not Responding to Button Presses:**

- Ensure your fingers are clean and dry when using the touch buttons.
- Try pressing the buttons firmly and directly.
- If the device is unresponsive, try unplugging it for a few seconds and then plugging it back in to reset it.

- **Incorrect Time Display:**

- Re-check the time setting procedure as described in Section 4.

For issues not covered here, please contact customer support.

## 7. SPECIFICATIONS

---

Feature	Specification
Input Voltage	220V 50/60Hz
Power Consumption	2W
Number of Channels	8 Channel
Timer Type	Digital Timers
Time Setting Range	0 to 99 minutes and 59 seconds
Fixed Time (Max)	>24 hours

## 8. WARRANTY AND SUPPORT

---

Specific warranty details for the Generic CAL 8B Calculagraph are not provided in this manual. For information regarding warranty coverage, returns, or technical support, please contact the seller or manufacturer directly through your purchase platform.