

- Manuals.plus /
- › EF ECOFLOW /
- › EF ECOFLOW Wave 2 Portable Air Conditioner Bag User Manual

EF ECOFLOW WAVE2-BAG

EF ECOFLOW Wave 2 Portable Air Conditioner Bag

Model: WAVE2-BAG

PRODUCT OVERVIEW

The EF ECOFLOW Wave 2 Portable Air Conditioner Bag is designed to provide enhanced portability and protection for your EF ECOFLOW Wave 2 Portable Air Conditioner. This grey bag ensures secure transport and storage, making it easier to move your air conditioner wherever it's needed. It is specifically engineered to accommodate the Wave 2 unit, offering a dedicated solution for its transport needs.

PRODUCT IMAGES



Front view of the EF ECOFLOW Wave 2 Portable Air Conditioner Bag in grey, showcasing its zippered main compartment and sturdy handles.



The EF ECOFLOW Wave 2 Portable Air Conditioner Bag with the Wave 2 air conditioner unit partially inserted, demonstrating how the unit fits inside the bag.

## SETUP

1. **Unpack the Bag:** Carefully remove the Wave 2 Portable Air Conditioner Bag from its packaging. Inspect for any signs of damage.
2. **Prepare the Air Conditioner:** Ensure your EF ECOFLOW Wave 2 Portable Air Conditioner is powered off and disconnected from any power sources. Allow it to cool down if it has been recently in operation.
3. **Insert the Air Conditioner:** Open the main zippered compartment of the bag. Gently slide the Wave 2 air conditioner unit into the bag, ensuring it is properly seated and aligned. The bag is designed to fit the unit snugly.
4. **Secure the Bag:** Close the main zipper completely. Ensure all flaps and straps (if any) are properly secured to prevent the unit from shifting during transport.

## OPERATING

The Wave 2 Portable Air Conditioner Bag is primarily for transport and protection. It does not affect the operation of the air conditioner itself.

- **Carrying:** Use the integrated handles to lift and carry the bag. Ensure a firm grip, especially when the air conditioner is inside.
- **Storage:** When not in use, the bag provides a protective cover for your air conditioner, shielding it from dust and minor impacts. Store in a cool, dry place.
- **Access:** While the air conditioner is in the bag, access to its controls and vents may be limited or require partial unzipping. For full operation, it is recommended to remove the unit from the bag.

## MAINTENANCE

- **Cleaning:** To clean the bag, wipe the exterior with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Allow the bag to air dry completely before storing or re-using.
- **Storage:** Store the bag in a dry, cool place away from direct sunlight when not in use.
- **Inspection:** Periodically inspect the zippers, seams, and handles for any signs of wear or damage. Address any issues promptly to maintain the bag's integrity.

## TROUBLESHOOTING

| Problem                                | Possible Cause                                    | Solution                                                                                                                                                  |
|----------------------------------------|---------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Air conditioner does not fit in bag.   | Incorrect model of air conditioner.               | Ensure you are using the EF ECOFLOW Wave 2 Portable Air Conditioner. This bag is specifically designed for that model.                                    |
| Zipper is stuck or difficult to close. | Fabric caught in zipper; zipper teeth misaligned. | Gently pull the fabric away from the zipper path. If teeth are misaligned, try to realign them carefully. Do not force the zipper.                        |
| Bag appears damaged after transport.   | Excessive force or sharp objects during handling. | The bag provides protection against minor impacts. For significant damage, contact customer support. Avoid dropping or exposing the bag to sharp objects. |

## SPECIFICATIONS

| Feature            | Detail                      |
|--------------------|-----------------------------|
| Manufacturer       | EcoFlow                     |
| Part Number        | WAVE2-BAG                   |
| Item Weight        | 1 pounds                    |
| Product Dimensions | 31.5 x 22.83 x 16.93 inches |
| Item Model Number  | WAVE2-BAG                   |
| Color              | Gray                        |

| Feature             | Detail     |
|---------------------|------------|
| Pattern             | Solid      |
| Included Components | Wave 2 Bag |

## WARRANTY INFORMATION

The EF ECOFLOW Wave 2 Portable Air Conditioner Bag comes with a **1-Year Limited Warranty**. This warranty covers defects in materials and workmanship under normal use. For detailed terms and conditions, please refer to the official EF ECOFLOW warranty policy or contact customer support.

## CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact EF ECOFLOW customer service through their official website or the contact information provided with your product purchase. You can visit the official EF ECOFLOW store on Amazon for more information:[EF ECOFLOW Store](#)

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0DLNGVJQB>

More documents and user manuals: <https://manuals.plus/>