Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl RSF-DY080-0502100US GDP GTA62-0502100US

Onerbl AC-DC Adapter Instruction Manual

Brand: Onerbl | Model: RSF-DY080-0502100US GDP GTA62-0502100US

Introduction

The Onerbl AC-DC Adapter is designed to provide reliable power for your compatible devices, including various PhoneSoap UV Cell Phone Sanitizer Box models. This power supply converts AC power from electrical outlets into the DC power required by your device, enabling both operation and battery charging. Manufactured with high-quality materials, this adapter is tested to ensure compatibility and performance.

Safety Information

- Ensure the adapter's voltage and current ratings match your device's requirements before use.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to disassemble or modify the adapter.
- Unplug the adapter from the wall outlet when not in use for extended periods.
- Keep out of reach of children.

Package Contents

- 1 x Onerbl AC-DC Adapter
- Multiple Adapter Tips (various sizes for broad compatibility)



Image: Front and side view of the Onerbl AC-DC Adapter, showing the US plug and the barrel connector cable.

Setup

1. **Identify the Correct Adapter Tip:** Select the appropriate adapter tip from the included set that matches the power input port of your PhoneSoap device or other compatible electronic device.
2. **Connect the Tip to the Adapter Cable:** Firmly attach the selected adapter tip to the barrel connector end of the Onerbl AC-DC adapter cable. Ensure a secure connection.
3. **Plug into Your Device:** Insert the connected adapter tip into the power input port of your PhoneSoap UV Cell Phone Sanitizer Box or other device.
4. **Connect to Power Outlet:** Plug the Onerbl AC-DC adapter into a standard 100-240V AC wall outlet.



Image: The Onerbl AC-DC Adapter plugged into a device, demonstrating a typical usage scenario.

Operating Instructions

Once properly connected, the Onerbl AC-DC Adapter will automatically provide power to your device. If your device has a battery, the adapter will initiate charging. Refer to your device's specific manual for indicators of charging status.

Maintenance

- **Cleaning:** Disconnect the adapter from power and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.

Troubleshooting

- **Device Not Powering On/Charging:**
  - Ensure the adapter is securely plugged into both the wall outlet and your device.

- Verify that the correct adapter tip is used and is firmly connected.
- Check if the wall outlet is functional by plugging in another device.
- Confirm that your device's power requirements (voltage and current) match the adapter's specifications.

- **Adapter Feels Warm:** It is normal for the adapter to feel slightly warm during operation. If it becomes excessively hot, disconnect it immediately and contact support.

Specifications

Input Voltage	100-240 Volts (AC)
Output Voltage	5 Volts (DC)
Output Current	2 Amps
Wattage	36.5 watts
Connector Type	Barrel Connector (with multiple tips)
Special Feature	Short Circuit Protection
Color	Black
Cable Length	76 inches (approx. 193 cm)




Image: The Onerbl AC-DC Adapter showing its approximate dimensions: 2.6 inches length, 1.6 inches width, 1.2 inches height, and a cable length of 76 inches.

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DLNH2YT3

More documents and user manuals: **https://manuals.plus/**