



[Manuals.plus](#) /

› [MCombo](#) /

› MCombo 62.2" Reclining Loveseat HL198M1 Instruction Manual

MCombo HL198M1

MCombo 62.2" Reclining Loveseat HL198M1 Instruction Manual

Model: HL198M1

INTRODUCTION

Thank you for choosing the MCombo 62.2" Reclining Loveseat. This power loveseat recliner features an adjustable headrest, USB A & C charge ports, and a wall-hugger design for space-saving convenience. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your new furniture.



Image: The MCombo 62.2" Reclining Loveseat in Navy Blue, showcasing its modern design.

SAFETY INFORMATION

All foam and upholstered surfaces meet flammability standards. Keep away from open flames or high heat sources. Do not operate if power cord is damaged. Supervise children and pets to avoid entrapment risks. Always use the recliner as intended and follow the instructions provided.

PACKAGE CONTENTS

Before assembly, ensure all components are present:

- Armrests (Left and Right)
- Left Backrest
- Right Backrest
- Left Base
- Right Base

- Accessories Box (containing power adapter, cables, and small parts)
- Instruction Manual

SETUP AND ASSEMBLY

Assembly is required and designed to be straightforward, typically taking a novice about 25 minutes. No additional tools are needed. It is recommended that two people assist with assembly for easier handling of components.

Assembly Steps Overview:

1. Unpack all components and verify against the package contents list.
2. Attach the wooden legs to the base sections.
3. Connect the left and right base sections.
4. Slide the backrests onto the corresponding base sections until they lock into place.
5. Connect all electrical wiring as per the wiring diagram in the manual.
6. Plug the power adapter into a wall outlet.

Your browser does not support the video tag.

Video: Assembly Guide for Power Recliner Sofa HL198. This video demonstrates the step-by-step process for assembling your MCombo power recliner loveseat.



Image: An illustration showing the various components of the MCombo loveseat and their connection points during assembly.

OPERATING INSTRUCTIONS

Power Reclining Mechanism

Use the control buttons located on the armrest to adjust the reclining position. The loveseat offers standard TV modes and a full 145° recline for maximum comfort. The forward-gliding mechanism allows for full recline even when placed close to a wall (zero wall hugger feature).

Adjustable Power Headrest

The headrest can be adjusted from 0-90° using the dedicated buttons on the control panel. This feature ensures optimal neck and head support whether you are sitting upright, watching TV, or fully reclined.




Health, Safety, Comfort

CertiPUR-US certified High-Density Sponge Filling

Image: A person adjusting the power headrest for personalized neck support.

USB A & C Charge Ports

Each armrest is equipped with dual USB A and Type C charge ports, allowing you to conveniently charge your mobile devices while relaxing.



Solid Wood Feet

Floor protection and effortless daily cleaning made possible.


Image: Close-up view of the integrated USB A and Type C charging ports on the armrest.

Home Button Function

Press the 'Home' button on the control panel to return the loveseat to its original, upright position from any recline setting. This process takes approximately 22 seconds.

True Zero-Clearance
saving space, dust-proof.

VS



False Zero-Clearance Sofa



Image: The control panel on the armrest, highlighting the home button and recline controls.

Your browser does not support the video tag.

Video: MCombo Wall Hugger Power Loveseat Recliner HL198. This video demonstrates the wall-hugger feature and smooth reclining motion of the loveseat.

Your browser does not support the video tag.

Video: Zero Wall Power Recliner Sofa with Headrest. This video highlights the zero-wall clearance design and the adjustable headrest functionality.

MAINTENANCE

To maintain the appearance and longevity of your MCombo Reclining Loveseat, follow these care instructions:

- **Cleaning:** Wipe clean with a dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Fabric Care:** The fabric is OEKO-TEX (Standard 100) certified, ensuring it is free from harmful substances. Regular light vacuuming can help remove dust and debris.

- **Mechanism:** Periodically check all connections and moving parts to ensure they are secure. Do not lubricate the reclining mechanism unless specifically instructed by MCombo support.



Each Armrest Has Buttons Home Button

Press the home button, the chair smoothly returns to its original position in just **22** seconds

Image: A close-up of the Navy Blue fabric, highlighting its texture and OEKO-TEX Standard 100 certification.

TROUBLESHOOTING

If you encounter any issues with your MCombo Reclining Loveseat, refer to the following common problems and solutions:

- **Loveseat does not recline:** Ensure the power cord is securely plugged into both the loveseat and a functioning wall outlet. Check for any kinks or damage in the power cord.
- **Reclining motion is slow or jerky:** This is often normal for power recliners, designed for safety. If the motion becomes excessively slow or inconsistent, check for obstructions around the mechanism.
- **Headrest not adjusting:** Verify that the power connection is secure. Ensure no objects are obstructing the headrest mechanism.
- **USB ports not charging:** Confirm the loveseat is powered on and plugged in. Try a different USB cable or device to rule out device-specific issues.

- **Unusual noises during operation:** Check for loose connections or foreign objects caught in the reclining mechanism. If noises persist, discontinue use and contact customer support.

For issues not covered here, please contact MCombo customer support.

SPECIFICATIONS

Feature	Detail
Brand	MCombo
Model Number	HL198M1 (6160-HL198M1)
Product Dimensions (D x W x H)	37.4"D x 62.2"W x 26.8"H
Reclined Length	68.5 Inches
Seat Depth	19.7 Inches
Seat Height	18.7 Inches
Weight Limit	350 Pounds per seat
Seating Capacity	2
Item Weight	220.7 Pounds
Upholstery Fabric Type	Chenille
Frame Material Type	Wood (FSC Certified)
Seat Fill Material	Foam (CertiPUR-US Certified)
Additional Features	Adjustable Headrest, Recliner, Space Saving (Wall Hugger), USB Charging Ports
Reclining Position Count	3
Minimum Required Door Width	18.1 Inches



Image: Detailed diagram showing the dimensions of the MCombo Reclining Loveseat in various positions.

WARRANTY AND SUPPORT

Your MCombo Reclining Loveseat is backed by a **2-year limited warranty**. This warranty includes free replacements for:

- Reclining Mechanisms
- Electrical Systems
- Upholstery & Cushions
- Wood/Metal Frame Structures

For detailed warranty terms and conditions, please refer to the full warranty document included with your purchase.

Customer Support

For any questions, assistance with assembly, troubleshooting, or warranty claims, please contact MCombo customer support. Contact information can typically be found on the MCombo website or through your purchase platform.

