

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Chefhandy](#) /

› [Chefhandy Baby Wipe Warmer with UV Light Sanitizer and 3 Heat Modes \(Model BWW-G7300\) - Instruction Manual](#)

Chefhandy BWW-G7300

Chefhandy Baby Wipe Warmer with UV Light Sanitizer and 3 Heat Modes

Model: BWW-G7300

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

INTRODUCTION

Thank you for choosing the Chefhandy Baby Wipe Warmer. This device is designed to provide warm, moist, and sanitized wipes for your baby's comfort during diaper changes. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Image: The Chefhandy Baby Wipe Warmer in green, featuring a digital display and control buttons on the lid.

IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not immerse the unit in water or other liquids.
- Unplug from outlet when not in use and before cleaning.
- Do not operate with a damaged cord or plug.
- Keep out of reach of children.
- Use only as intended for warming baby wipes.
- Ensure the unit is placed on a stable, flat surface.
- Do not block ventilation openings.

PRODUCT COMPONENTS

The Chefhandy Baby Wipe Warmer consists of the following main parts:

- Main Unit with Lid
- Control Panel (Auto, Sanitize, Night Light, Power buttons, Digital Display)
- Wipe Dispensing Slot
- Power Adapter



Image: Diagram illustrating the various components and features of the wipe warmer, including the control panel and wipe dispensing area.

SETUP INSTRUCTIONS

1. **Unpack the Unit:** Carefully remove the wipe warmer from its packaging.
2. **Placement:** Place the unit on a flat, stable, and dry surface, away from water sources.
3. **Connect Power:** Plug the power adapter into the unit, then into a standard electrical outlet.
4. **Load Wipes:**

- Open the lid of the warmer.
- Place a full pack of baby wipes (up to 100 wipes) into the warmer, preferably with their original packaging to maintain moisture.
- Pull the first wipe through the dispensing slot on the lid.
- Close the lid securely.

Heats Evenly + Keeps Wipes Moist

Surround Heating, faster and more even, say goodbye to cold wipes




Image: A hand loading a pack of baby wipes into the open Chefhandy wipe warmer, demonstrating the large capacity.

OPERATING INSTRUCTIONS

Power On/Off

- Press the **Power** button once to turn the unit on. The digital display will illuminate.
- To turn off, press and hold the **Power** button for 3 seconds.



Image: A close-up of a finger pressing the power button on the control panel of the wipe warmer.

Temperature Control

The unit offers three temperature modes:

- **Mode 1:** 100°F (38°C)
- **Mode 2:** 113°F (45°C)
- **Mode 3:** 131°F (55°C)

Press the **Auto** button repeatedly to cycle through the temperature settings. The selected temperature will be displayed on the digital screen.



Soft Night Light
Make Everynight diaper changes easy

Image: The Chefhandy wipe warmer displaying different temperature ranges (100-109°F, 113-122°F, 131-140°F) with arrows indicating surround heating.

UV Light Sanitizer

The integrated UV light sanitizer helps ensure wipes are clean. There are three sanitization duration options:

- 3 minutes (default)
- 5 minutes
- 8 minutes

Press the **Sanitize** button. The digital screen will display "3" for 3 minutes. Press the button again to cycle through 5 and 8 minutes. The UV light will activate for the selected duration.

EPA Establishment Number: 97442-CHN-1.



Image: A close-up of a finger pressing the sanitize button on the control panel of the wipe warmer, with a visual representation of germs being eliminated.

Night Light Function

Activate the night light for visibility during nighttime diaper changes without needing bright room lights.

- Press the **Night Light** button once to turn the night light on.
- Press it again to turn the night light off.

Put In Wipes With The Packing

Designed For 99% Of Wet Wipes Holds Up To 100 Wipes



Image: The Chefhandy wipe warmer with its night light illuminated, positioned next to a baby's crib in a dimly lit room, facilitating nighttime diaper changes.

Dispensing Wipes

Wipes are dispensed from the top slot. The transparent window allows you to monitor the remaining wipe quantity.



Image: A close-up view of the transparent window on the front of the wipe warmer, showing the "Baby Wipes" label and the UV light glow.

MAINTENANCE AND CARE

- **Cleaning:** Unplug the unit before cleaning. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Wipe Moisture:** The surround heating system is designed to maintain wipe moisture. For best results, keep wipes in their original packaging inside the warmer.
- **Storage:** If storing for an extended period, unplug the unit, empty any wipes, clean it, and store in a cool, dry place.

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Unit does not power on.	Not plugged in; power outlet issue; unit malfunction.	Ensure power cord is securely plugged into unit and outlet. Test outlet with another device. If problem persists, contact customer support.
Wipes are not warm.	Incorrect temperature setting; unit not on long enough; lid not closed properly.	Check temperature setting and adjust if necessary. Allow 1-2 hours for wipes to reach desired temperature. Ensure lid is fully closed.
Wipes are drying out.	Lid not closed properly; wipes not in original packaging; low moisture content in wipes.	Ensure lid is securely closed after each use. Keep wipes in their original packaging inside the warmer. Consider using wipes with higher moisture content.
UV sanitizer not working.	Sanitize button not pressed; unit malfunction.	Press the Sanitize button to activate. Ensure a duration is selected. If still not working, contact customer support.

PRODUCT SPECIFICATIONS

- **Model Number:** BWW-G7300
- **Product Dimensions:** 8.2 x 5.5 x 3.5 inches
- **Item Weight:** 1.5 pounds
- **Material Composition:** ABS
- **Heating Modes:** 3 (100°F, 113°F, 131°F)
- **Sanitizer:** UV Light with 3/5/8 minute options (EPA Establishment Number: 97442-CHN-1)
- **Additional Features:** Night Light, Silent Operation, Transparent Window, One-Handed Operation
- **Capacity:** Up to 100 wipes

WARRANTY AND SUPPORT

Chefhandy products come with a manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Chefhandy website.

If you experience any issues or have questions regarding your Chefhandy Baby Wipe Warmer, please contact our customer support team:

- **Online Support:** Visit the [Chefhandy Store on Amazon](#).

- **Email:** support@chefhandy.com
- **Phone:** 1-800-XXX-XXXX

Please have your model number (BWW-G7300) and purchase date ready when contacting support.