

[manuals.plus](#) /› [Xgody](#) /› [Xgody S200 Flip Phone User Manual](#)

Xgody S200

Xgody S200 Flip Phone User Manual

Model: S200

1. INTRODUCTION

Welcome to the Xgody S200 Flip Phone user manual. This guide provides detailed instructions to help you set up, operate, and maintain your new phone. The Xgody S200 is designed for simplicity and convenience, featuring large buttons, a clear 2.4-inch display, and essential functions like SOS emergency calls, FM radio, and a flashlight, making it ideal for users seeking an easy-to-use mobile device.



Image: The Xgody S200 Flip Phone in its open position, displaying its large keypad and a clear screen. The phone is gold-colored.

2. PRODUCT OVERVIEW

Familiarize yourself with the components of your Xgody S200 Flip Phone.

1300mAh Large Capacity Battery

Super long standby time, no need for frequent charging



1300mAh




Image: A diagram of the Xgody S200 Flip Phone highlighting the 1300mAh battery, flashlight, 3.5mm headphone port, and Type-C charging port.

Key Features:

- **Large Buttons and Clear Display:** Easy to see and press for comfortable operation.
- **Flip Design:** Protects the screen and prevents accidental dialing.
- **1300 mAh Battery:** Provides extended standby time.
- **Type-C Charging Port:** For convenient and fast charging.
- **Dual SIM Support:** Manage two phone numbers simultaneously.
- **SOS Emergency Function:** Quickly contact pre-set emergency numbers.
- **Integrated Flashlight:** For illumination in dark environments.
- **FM Radio:** Enjoy radio broadcasts without headphones.
- **Bluetooth:** For connecting to wireless accessories.
- **0.8 MP Camera:** Capture simple photos.

3. SETUP

3.1. Battery Installation and Charging

1. Open the back cover of the phone.
2. Insert the 1300 mAh Lithium-ion battery into its compartment, ensuring the contacts align.
3. Replace the back cover.
4. Connect the Type-C charging cable to the phone's charging port and plug the other end into a power adapter.
5. Allow the phone to charge fully before first use. A full charge typically takes a few hours.



Image: The Xgody S200 Flip Phone connected to a Type-C charger, illustrating the charging process.

3.2. SIM Card and SD Card Installation

The Xgody S200 supports dual SIM cards and an SD card for expanded storage.

1. Remove the back cover and the battery.
2. Locate the SIM card slots. The phone typically supports two SIM cards (e.g., standard or micro SIM).
3. Carefully insert your SIM card(s) into the designated slots, ensuring the gold contacts face downwards and the cut corner aligns correctly.
4. If using an SD card for additional storage, insert it into the SD card slot.
5. Replace the battery and the back cover.



Image: The Xgody S200 Flip Phone with visual indicators for its dual SIM card capability and foldable design.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

- **To Power On:** Press and hold the **Power/End Call** button (usually red) until the screen lights up.
- **To Power Off:** Press and hold the **Power/End Call** button until the power-off options appear, then select "Power Off".

4.2. Making and Receiving Calls

• To Make a Call:

1. Enter the phone number using the keypad.
2. Press the **Call/Send** button (usually green) to initiate the call.

- **To Answer a Call:** When the phone rings, press the **Call/Send** button.
- **To End a Call:** Press the **Power/End Call** button.

Phone volume is loud and clear

It is more convenient for the elderly to hear the conversation clearly when calling!



Image: An elderly woman using the Xgody S200 Flip Phone, demonstrating its loud and clear volume feature for improved call clarity.

4.3. SOS Emergency Calls

The SOS function allows you to quickly dial up to 5 pre-set emergency contacts.

1. Setting Up SOS Numbers:

- Navigate to the "SOS Settings" menu.
- Add up to 5 emergency contact numbers (e.g., family members, doctor, first aid).

2. Activating SOS:

In an emergency, press and hold the dedicated **SOS button** (if present, or a designated key like the 'OK' button as per some descriptions) for a few seconds. The phone will automatically dial the pre-set numbers in sequence until one is answered.

SOS Emergency Calls

Support 5 Family Numbers
--Guarantee The Safety of The Elderly




Image: The Xgody S200 Flip Phone illustrating its SOS emergency call feature, which supports calling up to 5 family numbers for safety.

4.4. Other Functions

- **Flashlight:** Press and hold the designated flashlight button or a specific key (e.g., '0' or a side button) for 3 seconds to turn the flashlight on/off.
- **FM Radio:** Access the FM Radio application from the main menu. You may need to connect headphones (not always required for this model) to act as an antenna for better reception.
- **Bluetooth:** Go to "Settings" > "Bluetooth" to enable and pair with other Bluetooth devices.
- **Camera:** Open the "Camera" application to take photos. The phone features a 0.8 MP camera.
- **Alarm, Calendar, Sound Recorder:** These applications can be found in the main menu for daily utility.



**Exclusive flashlight
Make life more convenient!**



**Press for 3 seconds to turn
on the light immediately**

Image: The Xgody S200 Flip Phone demonstrating its built-in flashlight feature, providing illumination.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the phone's screen and body. Avoid using liquid cleaners or abrasive materials.
- **Battery Care:**
 - Avoid extreme temperatures, which can reduce battery life.
 - Do not leave the phone charging for excessively long periods after it is fully charged.
 - If the phone will not be used for an extended period, charge it to about 50% before storing.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and moisture.
- **Software Updates:** While specific software update guarantees are not available for this model, ensure the phone's software is up-to-date if prompted, to benefit from performance improvements and security patches.

6. TROUBLESHOOTING

If you encounter issues with your Xgody S200, refer to the following common problems and solutions.

Problem	Possible Solution
Phone does not power on	<ul style="list-style-type: none"> Ensure the battery is correctly installed and charged. Connect the charger and try powering on again. If the battery is removable, try removing and reinserting it.
No network signal	<ul style="list-style-type: none"> Check if the SIM card is correctly inserted. Ensure you are in an area with network coverage. Restart the phone. Contact your network provider to confirm service status.
Cannot make or receive calls	<ul style="list-style-type: none"> Verify network signal strength. Check if the SIM card is active and has sufficient credit/plan. Ensure call barring or flight mode is not enabled.
Charging issues	<ul style="list-style-type: none"> Ensure the charger and cable are not damaged. Try using a different compatible Type-C charger. Check if the charging port is clean and free of debris.
Poor call quality	<ul style="list-style-type: none"> Move to an area with better network reception. Ensure the speaker and microphone are not obstructed. Adjust the call volume.

7. SPECIFICATIONS

Detailed technical specifications for the Xgody S200 Flip Phone.

Feature	Detail
Brand	Xgody
Model Name	S200
Form Factor	Flip Phone
Operating System	Android (Basic OS for feature phones)
Screen Size	2.4 Inches
Resolution	320 x 240
Battery Capacity	1300 mAh Lithium-ion
Charging Port	Type-C
SIM Support	Dual SIM

Feature	Detail
Network Technology	2G (GSM)
Camera	0.8 MP
Connectivity	Bluetooth
Additional Features	FM Radio, Flashlight, SOS Function, Alarm, Calendar, Sound Recorder

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the retailer where you purchased the Xgody S200 Flip Phone. You may also visit the official Xgody website for further assistance.

Related Documents - S200

 X31 Mobile Phone <small>User Manual</small>	<p>XGODY X31 Mobile Phone User Manual</p> <p>User manual for the XGODY X31 mobile phone, covering product overview, getting started, settings, and troubleshooting.</p>
 X60 Mobile Phone <small>User Manual</small>	<p>X60 Mobile Phone User Manual - Getting Started and Troubleshooting</p> <p>Comprehensive user manual for the X60 Mobile Phone, covering setup, basic operations, troubleshooting common issues, and FCC compliance information. Learn how to install SIM cards, power on/off, manage battery, take screenshots, and resolve connectivity or performance problems.</p>
 X32 Mobile Phone <small>User Manual</small>	<p>XGODY X32 Mobile Phone User Manual</p> <p>Comprehensive user guide for the XGODY X32 smartphone, covering product overview, setup, settings, and troubleshooting. Available in English, German, Spanish, French, and Italian.</p>

 <p>Manufacturer: SHENZHEN XGODY GROUP LTD. Production Site: Room 401, 16th Industrial Building, Guanlan Avenue, Bafen Community, Pudong New Area, Shenzhen, China Phone: +86 13926842827 Zip Code: 518050 Office Website: www.xgody.com</p> <p>QR codes:  </p>	<p>XGODY X36 Mobile Phone User Manual</p> <p>Comprehensive user manual for the XGODY X36 mobile phone, covering setup, features, and troubleshooting. Includes manufacturer details and support links.</p>
 <p>ANDROID TABLET QUICK START GUIDE Model: N01</p>	<p>XGODY N01 Android Tablet Quick Start Guide</p> <p>Get started with your XGODY N01 Android Tablet. This guide provides essential setup, operational, and connectivity information for users.</p>
	<p>XGODY Tablet User Manual - Setup, Features, and Troubleshooting Guide</p> <p>Comprehensive user guide for the XGODY Tablet, covering setup, basic operations, connectivity, app management, troubleshooting, and technical specifications. Learn how to maximize your XGODY tablet experience.</p>

Documents - Xgody – S200

EU Declaration of Conformity

This declaration of conformity is issued under the sole responsibility of the manufacturer.

Manufacturer:
Business Name: Shenzhen Xinglong Technology Co., Ltd.
Address: Room 303, Building 5, No. 54-6, Guanlan Avenue, Xincun Community, Fucheng Street, Longhua District, Shenzhen, Guangdong, China
Country: China

Product Name: Cell phone
Model No.: X17,X18,S21,S22,S23,Mate 60,Mate 70,A54,X31,S200,Y13 Pro
Trade Name: XGODY

We declare that the product described above, which this declaration of conformity refers to, is in conformity with the relevant Union harmonization legislation:
RED Directive 2014/53/EU

Through the technical standards/specifications specified below:
EN 60065 V12.3.1,EN 60950-1:2006+A11:2009+A2:2011+A3:2013+A4:2015
EN 60065 V12.3.2,EN 60950-2:2006+A11:2009+A2:2011+A3:2013
EN 60065 V12.3.3,EN 60950-3:2006+A11:2009+A2:2011+A3:2013
EN IEC 62686-1:2014+A11:2014

The technical body, Shenzhen STI Testing Technology Co.,Ltd, performed the EU-type examination in accordance with Annex IV, Article 4(2) of Council Directive 2014/53/EU, and issued the EU-type examination report No. STI-2024-04564545004.

The CE marking as shown below can be a fixed on the product after preparation of necessary conformity documentation as stipulated in CE Marking Directive 93/46/EEC.

Harmonized standards: 

Person responsible for making this declaration
Name/Position: Robin Wu/Compliance Management Engineer
Shenzhen, China
(place) 2024-02-08
(Date)



[EU Declaration of Conformity for XGODY Cell Phones](#)

This EU Declaration of Conformity certifies that XGODY cell phone models X17, X18, S21, S22, S23, Mate 60, Mate 70, A54, X31, S200, and Y13 Pro comply with the RED Directive 2014/53/EU and relevant harmonized standards for safety and performance.
lang:en **score:20** filesize: 938.33 K page_count: 1 document date: 2024-07-04



Periferiche compatibili con TIM I love games

Marcia	Modello
Acer	A1-A11
Acer	A1-A20
Acer	A20
Acer	Aspire A3
Acer	A33-A09
Acer	AS1
Acer	AS1-179
Acer	AS1-A15
Acer	AS1-A16
Acer	AS1-A17
Acer	AS1-A18
Acer	AS1-A19
Acer	AS1-A20
Acer	AS1-A21
Acer	AS1-A22
Acer	AS1-A23
Acer	AS1-A24
Acer	AS1-A25
Acer	AS1-A26
Acer	AS1-A27
Acer	AS1-A28
Acer	AS1-A29
Acer	AS1-A30
Acer	AS1-A31
Acer	AS1-A32
Acer	AS1-A33
Acer	AS1-A34
Acer	AS1-A35
Acer	AS1-A36
Acer	AS1-A37
Acer	AS1-A38
Acer	AS1-A39
Acer	AS1-A40
Acer	AS1-A41
Acer	AS1-A42
Acer	AS1-A43
Acer	AS1-A44
Acer	AS1-A45
Acer	AS1-A46
Acer	AS1-A47
Acer	AS1-A48
Acer	AS1-A49
Acer	AS1-A50
Acer	AS1-A51
Acer	AS1-A52
Acer	AS1-A53
Acer	AS1-A54
Acer	AS1-A55
Acer	AS1-A56
Acer	AS1-A57
Acer	AS1-A58
Acer	AS1-A59
Acer	AS1-A60
Acer	AS1-A61
Acer	AS1-A62
Acer	AS1-A63
Acer	AS1-A64
Acer	AS1-A65
Acer	AS1-A66
Acer	AS1-A67
Acer	AS1-A68
Acer	AS1-A69
Acer	AS1-A70
Acer	AS1-A71
Acer	AS1-A72
Acer	AS1-A73
Acer	AS1-A74
Acer	AS1-A75
Acer	AS1-A76
Acer	AS1-A77
Acer	AS1-A78
Acer	AS1-A79
Acer	AS1-A80
Acer	AS1-A81
Acer	AS1-A82
Acer	AS1-A83
Acer	AS1-A84
Acer	AS1-A85
Acer	AS1-A86
Acer	AS1-A87
Acer	AS1-A88
Acer	AS1-A89
Acer	AS1-A90
Acer	AS1-A91
Acer	AS1-A92
Acer	AS1-A93
Acer	AS1-A94
Acer	AS1-A95
Acer	AS1-A96
Acer	AS1-A97
Acer	AS1-A98
Acer	AS1-A99
Acer	AS1-A100
Acer	AS1-A101
Acer	AS1-A102
Acer	AS1-A103
Acer	AS1-A104
Acer	AS1-A105
Acer	AS1-A106
Acer	AS1-A107
Acer	AS1-A108
Acer	AS1-A109
Acer	AS1-A110
Acer	AS1-A111
Acer	AS1-A112
Acer	AS1-A113
Acer	AS1-A114
Acer	AS1-A115
Acer	AS1-A116
Acer	AS1-A117
Acer	AS1-A118
Acer	AS1-A119
Acer	AS1-A120
Acer	AS1-A121
Acer	AS1-A122
Acer	AS1-A123
Acer	AS1-A124
Acer	AS1-A125
Acer	AS1-A126
Acer	AS1-A127
Acer	AS1-A128
Acer	AS1-A129
Acer	AS1-A130
Acer	AS1-A131
Acer	AS1-A132
Acer	AS1-A133
Acer	AS1-A134
Acer	AS1-A135
Acer	AS1-A136
Acer	AS1-A137
Acer	AS1-A138
Acer	AS1-A139
Acer	AS1-A140
Acer	AS1-A141
Acer	AS1-A142
Acer	AS1-A143
Acer	AS1-A144
Acer	AS1-A145
Acer	AS1-A146
Acer	AS1-A147
Acer	AS1-A148
Acer	AS1-A149
Acer	AS1-A150
Acer	AS1-A151
Acer	AS1-A152
Acer	AS1-A153
Acer	AS1-A154
Acer	AS1-A155
Acer	AS1-A156
Acer	AS1-A157
Acer	AS1-A158
Acer	AS1-A159
Acer	AS1-A160
Acer	AS1-A161
Acer	AS1-A162
Acer	AS1-A163
Acer	AS1-A164
Acer	AS1-A165
Acer	AS1-A166
Acer	AS1-A167
Acer	AS1-A168
Acer	AS1-A169
Acer	AS1-A170
Acer	AS1-A171
Acer	AS1-A172
Acer	AS1-A173
Acer	AS1-A174
Acer	AS1-A175
Acer	AS1-A176
Acer	AS1-A177
Acer	AS1-A178
Acer	AS1-A179
Acer	AS1-A180
Acer	AS1-A181
Acer	AS1-A182
Acer	AS1-A183
Acer	AS1-A184
Acer	AS1-A185
Acer	AS1-A186
Acer	AS1-A187
Acer	AS1-A188
Acer	AS1-A189
Acer	AS1-A190
Acer	AS1-A191
Acer	AS1-A192
Acer	AS1-A193
Acer	AS1-A194
Acer	AS1-A195
Acer	AS1-A196
Acer	AS1-A197
Acer	AS1-A198
Acer	AS1-A199
Acer	AS1-A200
Acer	AS1-A201
Acer	AS1-A202
Acer	AS1-A203
Acer	AS1-A204
Acer	AS1-A205
Acer	AS1-A206
Acer	AS1-A207
Acer	AS1-A208
Acer	AS1-A209
Acer	AS1-A210
Acer	AS1-A211
Acer	AS1-A212
Acer	AS1-A213
Acer	AS1-A214
Acer	AS1-A215
Acer	AS1-A216
Acer	AS1-A217
Acer	AS1-A218
Acer	AS1-A219
Acer	AS1-A220
Acer	AS1-A221
Acer	AS1-A222
Acer	AS1-A223
Acer	AS1-A224
Acer	AS1-A225
Acer	AS1-A226
Acer	AS1-A227
Acer	AS1-A228
Acer	AS1-A229
Acer	AS1-A230
Acer	AS1-A231
Acer	AS1-A232
Acer	AS1-A233
Acer	AS1-A234
Acer	AS1-A235
Acer	AS1-A236
Acer	AS1-A237
Acer	AS1-A238
Acer	AS1-A239
Acer	AS1-A240
Acer	AS1-A241
Acer	AS1-A242
Acer	AS1-A243
Acer	AS1-A244
Acer	AS1-A245
Acer	AS1-A246
Acer	AS1-A247
Acer	AS1-A248
Acer	AS1-A249
Acer	AS1-A250
Acer	AS1-A251
Acer	AS1-A252
Acer	AS1-A253
Acer	AS1-A254
Acer	AS1-A255
Acer	AS1-A256
Acer	AS1-A257
Acer	AS1-A258
Acer	AS1-A259
Acer	AS1-A260
Acer	AS1-A261
Acer	AS1-A262
Acer	AS1-A263
Acer	AS1-A264
Acer	AS1-A265
Acer	AS1-A266
Acer	AS1-A267
Acer	AS1-A268
Acer	AS1-A269
Acer	AS1-A270
Acer	AS1-A271
Acer	AS1-A272
Acer	AS1-A273
Acer	AS1-A274
Acer	AS1-A275
Acer	AS1-A276
Acer	AS1-A277
Acer	AS1-A278
Acer	AS1-A279
Acer	AS1-A280
Acer	AS1-A281
Acer	AS1-A282
Acer	AS1-A283
Acer	AS1-A284
Acer	AS1-A285
Acer	AS1-A286
Acer	AS1-A287
Acer	AS1-A288
Acer	AS1-A289
Acer	AS1-A290
Acer	AS1-A291
Acer	AS1-A292
Acer	AS1-A293
Acer	AS1-A294
Acer	AS1-A295
Acer	AS1-A296
Acer	AS1-A297
Acer	AS1-A298
Acer	AS1-A299
Acer	AS1-A300
Acer	AS1-A301
Acer	AS1-A302
Acer	AS1-A303
Acer	AS1-A304
Acer	AS1-A305
Acer	AS1-A306
Acer	AS1-A307
Acer	AS1-A308
Acer	AS1-A309
Acer	AS1-A310
Acer	AS1-A311
Acer	AS1-A312
Acer	AS1-A313
Acer	AS1-A314
Acer	AS1-A315
Acer	AS1-A316
Acer	AS1-A317
Acer	AS1-A318
Acer	AS1-A319
Acer	AS1-A320
Acer	AS1-A321
Acer	AS1-A322
Acer	AS1-A323
Acer	AS1-A324
Acer	AS1-A325
Acer	AS1-A326
Acer	AS1-A327
Acer	AS1-A328
Acer	AS1-A329
Acer	AS1-A330
Acer	AS1-A331
Acer	AS1-A332
Acer	AS1-A333
Acer	AS1-A334
Acer	AS1-A335
Acer	AS1-A336
Acer	AS1-A337
Acer	AS1-A338
Acer	AS1-A339
Acer	AS1-A340
Acer	AS1-A341
Acer	AS1-A342
Acer	AS1-A343
Acer	AS1-A344
Acer	AS1-A345
Acer	AS1-A346
Acer	AS1-A347
Acer	AS1-A348
Acer	AS1-A349
Acer	AS1-A350
Acer	AS1-A351
Acer	AS1-A352
Acer	AS1-A353
Acer	AS1-A354
Acer	AS1-A355
Acer	AS1-A356
Acer	AS1-A357
Acer	AS1-A358
Acer	AS1-A359
Acer	AS1-A360
Acer	AS1-A361
Acer	AS1-A362
Acer	AS1-A363
Acer	AS1-A364
Acer	AS1-A365
Acer	AS1-A366
Acer	AS1-A367
Acer	AS1-A368
Acer	AS1-A369
Acer	AS1-A370
Acer	AS1-A371
Acer	AS1-A372
Acer	AS1-A373
Acer	AS1-A374
Acer	AS1-A375
Acer	AS1-A376
Acer	AS1-A377
Acer	AS1-A378
Acer	AS1-A379
Acer	AS1-A380
Acer	AS1-A381
Acer	AS1-A382
Acer	AS1-A383
Acer	AS1-A384
Acer	AS1-A385
Acer	AS1-A386
Acer	AS1-A387
Acer	AS1-A388
Acer	AS1-A389
Acer	AS1-A390
Acer	AS1-A391
Acer	AS1-A392
Acer	AS1-A393
Acer	AS1-A394
Acer	AS1-A395
Acer	AS1-A396
Acer	AS1-A397
Acer	AS1-A398
Acer	AS1-A399
Acer	AS1-A400
Acer	AS1-A401
Acer	AS1-A402
Acer	AS1-A403
Acer	AS1-A404
Acer	AS1-A405
Acer	AS1-A406
Acer	AS1-A407
Acer	AS1-A408
Acer	AS1-A409
Acer	AS1-A410
Acer	AS1-A411
Acer	AS1-A412
Acer	AS1-A413
Acer	AS1-A414
Acer	AS1-A415
Acer	AS1-A416
Acer	AS1-A417
Acer	AS1-A418
Acer	AS1-A419
Acer	AS1-A420
Acer	AS1-A421
Acer	AS1-A422
Acer	AS1-A423
Acer	AS1-A424
Acer	AS1-A425
Acer	AS1-A426
Acer	AS1-A427
Acer	AS1-A428
Acer	AS1-A429
Acer	AS1-A430
Acer	AS1-A431
Acer	AS1-A432
Acer	AS1-A433
Acer	AS1-A434
Acer	AS1-A435
Acer	AS1-A436
Acer	AS1-A437
Acer	AS1-A438
Acer	AS1-A439
Acer	AS1-A440
Acer	AS1-A441
Acer	AS1-A442
Acer	AS1-A443
Acer	AS1-A444
Acer	AS1-A445
Acer	AS1-A446
Acer	AS1-A447
Acer	AS1-A448
Acer	AS1-A449
Acer	AS1-A450
Acer	AS1-A451
Acer	AS1-A452
Acer	AS1-A453
Acer	AS1-A454
Acer	AS1-A455
Acer	AS1-A456
Acer	AS1-A457
Acer	AS1-A458
Acer	AS1-A459
Acer	AS1-A460
Acer	AS1-A461
Acer	AS1-A462
Acer	AS1-A463
Acer	AS1-A464
Acer	AS1-A465
Acer	AS1-A466
Acer	AS1-A467
Acer	AS1-A468
Acer	AS1-A469
Acer	AS1-A470
Acer	AS1-A471
Acer	AS1-A472
Acer	AS1-A473
Acer	AS1-A474
Acer	AS1-A475
Acer	AS1-A476
Acer	AS1-A477
Acer	AS1-A478
Acer	AS1-A479
Acer	AS1-A480
Acer	AS1-A481
Acer	AS1-A482
Acer	AS1-A483
Acer	AS1-A484
Acer	AS1-A485
Acer	