

VEVOR 9176WD

VEVOR Electronic Dartboard Cabinet Instruction Manual

MODEL: 9176WD

Introduction

Welcome to your VEVOR Electronic Dartboard Cabinet. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your dartboard cabinet. Please read this manual thoroughly before use and retain it for future reference.

Package Contents

Verify that all items listed below are present in your package:

- 1 x Dartboard Cabinet
- 12 x Soft Tip Darts
- 60 x Replaceable Dart Needles
- 1 x Power Adapter
- 6 x Screws
- 6 x Plastic Expansion Kits
- 1 x Install Paper Card
- 1 x User Manual

VEVOR
TOUGH TOOLS. HALF PRICE



EASY MOUNTING TIP



68" / 1.73 m

96" / 2.44 m

Image description: An illustration showing all included components: the dartboard cabinet, 12 soft tip darts, 60 replaceable dart needles, a power adapter, 6 screws, 6 plastic expansion kits, and an installation paper card.

Safety Information

Always use soft-tip darts with this electronic dartboard to prevent injury and damage to the board. Ensure the dartboard is securely mounted before play. Keep small parts away from children. Do not modify the product or use unauthorized accessories.

Setup and Installation

Follow these steps for proper installation of your dartboard cabinet:

1. **Choose Location:** Select a suitable wall space for mounting. Ensure there is enough clear space around the dartboard for safe play.
2. **Mark Mounting Points:** Use the provided installation paper card to mark the drilling points on the wall.

3. **Drill Holes:** Drill holes at the marked points and insert the plastic expansion kits.
4. **Mount Cabinet:** Secure the dartboard cabinet to the wall using the provided screws. Ensure it is level and firmly attached.
5. **Dartboard Height:** The center of the dartboard (bullseye) should be 68 inches (1.73 meters) from the floor.
6. **Throwing Line Distance:** The recommended throwing line distance is 96 inches (2.44 meters) from the face of the dartboard.



Image description: A diagram illustrating the recommended mounting height for the dartboard (68 inches / 1.73 meters to the bullseye) and the throwing line distance (96 inches / 2.44 meters from the dartboard face).

Operating Instructions

This section details how to operate your VEVOR Electronic Dartboard Cabinet.

Powering On

Connect the power adapter to the dartboard and plug it into a standard electrical outlet. The LED display will illuminate.

Game Selection

The dartboard offers 40 games with 590 variations. Use the control panel buttons to navigate through the game options and select your desired game. Refer to the game list printed on the dartboard for details.

Player Selection

The dartboard supports 1 to 8 players. Select the number of players before starting a game.

Electronic Scoring

The bright LED display automatically tracks scores, eliminating the need for manual scorekeeping.

ELECTRONIC SCORING

Keep track of the game with fun

THE SCORE

Double Segment=Score x 2

Triple Segment=Score x 3

Inner Bullseye=Score 50

Outer Bullseye=Score 25

Single Segment=Score x 1



BRIGHT LED DISPLAY

Delivers a clear view of scoring, eliminating manual scorekeeping



Image description: A close-up view of the electronic dartboard's LED display showing player scores and game information. It also illustrates how scores are calculated: Double Segment = Score x 2, Triple Segment = Score x 3, Inner Bullseye = 50, Outer Bullseye = 25, Single Segment = Score x 1.

Sound Adjustment

The sound settings are adjustable. Use the dedicated buttons on the control panel to increase or decrease the volume or mute the sound.

Dart Usage

Use only the provided soft-tip darts. The 13.5-inch dartboard features honeycomb holes designed to minimize bounce-outs and ensure darts stick firmly.



13.5" Dartboard with honeycomb holes
Hit the target firmly, not easily miss it



Steel tip darts tend to hurt your kids

SAFER SOFT DARTBOARD & DARTS

Won't cause accidental injury to your kids

Image description: A detailed view of the 13.5-inch soft dartboard with honeycomb holes, designed for darts to hit firmly. It contrasts soft-tip darts with steel-tip darts, highlighting the safety aspect of soft tips.

Maintenance

Proper maintenance ensures the longevity and performance of your dartboard cabinet.

- **Cleaning:** Wipe the cabinet and dartboard surface with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- **Dart Tips:** Replace worn or damaged dart needles promptly using the provided replaceable dart needles.
- **Storage:** When not in use, close the cabinet doors to protect the dartboard from dust and damage. The retro-style cabinet is designed to be dust-proof.

ALL ACCESSORIES INCLUDED




Image description: The VEVOR dartboard cabinet with its doors closed, showcasing its retro wood-grain finish and dust-proof design, complementing a living room decor.

Troubleshooting

If you encounter issues, refer to the following common problems and solutions.

- **Dartboard not powering on:**

- Check power connection: Ensure the power adapter is securely plugged into both the dartboard and the electrical outlet.
- Check outlet: Test the electrical outlet with another device to confirm it is functional.

- **Darts not registering score:**

- Check dart tips: Ensure darts have intact soft tips. Replace if damaged.
- Throwing technique: Ensure darts are thrown with sufficient force to penetrate the segment holes.

- **Sound issues:**

- Adjust volume: Use the volume control buttons on the dartboard.

- Mute function: Check if the mute function is activated.

Specifications

Feature	Detail
Model Number	9176WD
Brand	VEVOR
Material	MDF, Plastic
Dartboard Diameter	13.5 inches / 34.3 cm
Product Dimensions (L x W x H)	50 x 50 x 6.2 cm (19.7 x 19.7 x 2.4 inches)
Item Weight	4.6 kg (10.14 lbs)
Number of Games	40 Games, 590 Variations
Players Supported	1 to 8
UPC	197988811848







Warranty and Support

For warranty information or technical support, please contact VEVOR customer service. Refer to the product packaging or the VEVOR official website for contact details.

Recycling and Disposal

When the product reaches the end of its lifespan, please dispose of it responsibly according to local regulations. Do not dispose of electronic waste with general household waste.

Related Documents - 9176WD

	<p>VEVOR Electronic Dartboard Model 99153 - User Manual and Game Guide</p> <p>Comprehensive user manual and game guide for the VEVOR Electronic Dartboard, Model 99153. Learn about setup, safety, game rules, and operations.</p>
	<p>Jumbo Soccer Darts - Setup and Game Guide</p> <p>A comprehensive guide to setting up and playing the VEVOR Jumbo Soccer Darts inflatable game. Includes step-by-step instructions, safety guidelines, and product information for this fun outdoor activity.</p>
	<p>VEVOR Jumbo Soccer Darts - Inflatable Game Set with Air Blower & Accessories</p> <p>Set up and enjoy the VEVOR Jumbo Soccer Darts inflatable game. This guide covers setup, included items, safety instructions, maintenance, and proper disposal for this fun outdoor activity.</p>
	<p>Jumbo Soccer Darts - Fun Inflatable Game by VEVOR</p> <p>Set up and play the VEVOR Jumbo Soccer Darts game. Includes inflatable dartboard, balls, axes, boomerangs, pumps, and accessories. Follow easy setup and safety instructions for hours of family fun.</p>
	<p>VEVOR Electrical Enclosure Installation and Warranty Guide</p> <p>This guide provides detailed instructions for installing and using VEVOR TIP series electrical enclosures. It covers features, specifications, installation steps for locks, DIN rails, mounting plates, and wall mounting pendants, along with warranty information.</p>
	<p>VEVOR Sports Roll & Score Arcade Game SSG-05/SSG-06 Assembly Manual & User Guide</p> <p>Detailed assembly instructions and user guide for the VEVOR Sports Roll & Score Arcade Game (Models SSG-05, SSG-06). Includes safety information and support resources.</p>