

[Manuals.plus](#) /

› [BINBOND](#) /

› BINBOND Men's Multifunction Chronograph Watch (Model YXC-US-G3103-QJ) Instruction Manual

BINBOND YXC-US-G3103-QJ

BINBOND Men's Multifunction Chronograph Watch Instruction Manual

Model: YXC-US-G3103-QJ

1. INTRODUCTION

Thank you for choosing the BINBOND Men's Multifunction Chronograph Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read it carefully to ensure optimal performance and longevity of your watch.

This watch features a high-precision automatic movement, a chronograph function, moon phase display, and luminous hands for visibility in low light conditions. It is designed for daily wear and business occasions.

2. PRODUCT OVERVIEW

The BINBOND Multifunction Chronograph Watch combines classic design with practical features. Its robust stainless steel construction and intricate dial offer both durability and style.



BINBOND Men's Multifunction Chronograph Watch in its packaging.



BINBOND Men's Multifunction Chronograph Watch worn on a wrist.

Your browser does not support the video tag.

Official product video showcasing the BINBOND Men's Multifunction Chronograph Watch and its features.

3. SETUP

3.1 Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to its outermost position.
2. **Set the time:** Rotate the crown to adjust the hour and minute hands to the correct time. Pay attention to the 24-hour sub-dial to distinguish between AM and PM for accurate date change.
3. **Push in the crown:** Once the time is set, push the crown back into its original position to start the watch movement.

3.2 Adjusting the Bracelet

Your watch comes with a tool for adjusting the stainless steel bracelet. To resize the bracelet:

1. **Identify removable links:** Look for small arrows on the inside of the bracelet links, indicating the direction to push out the pins.
2. **Use the adjustment tool:** Place the bracelet in the tool and align the pin with the tool's pusher. Gently push the pin out in the direction of the arrow.
3. **Remove or add links:** Remove the necessary number of links to achieve a comfortable fit. To add links, reverse the process.
4. **Reassemble:** Reinsert the pins in the opposite direction of the arrows, ensuring they are fully seated.

The hidden butterfly buckle provides a secure and comfortable fit once the bracelet is properly sized.

4. OPERATING INSTRUCTIONS

4.1 Automatic Movement

This watch is powered by an automatic movement, meaning it winds itself with the motion of your wrist. For initial setup or if the watch has stopped due to lack of wear, gently shake it for about 30 seconds or manually wind it by rotating the crown clockwise while it is in its normal, pushed-in position (if applicable to the specific movement) until the second hand starts moving.

4.2 Chronograph Function

The watch features a chronograph with multiple sub-dials:

- **24-hour/Moon Phase Sub-dial:** Displays the current time in a 24-hour format and indicates day/night.
- **Minute Hand Sub-dial:** Measures elapsed minutes during chronograph operation.
- **Second Hand Sub-dial:** Measures elapsed seconds during chronograph operation.

To operate the chronograph:

1. **Start:** Press the top pusher button to start the chronograph. The minute and second sub-dials will begin to move.
2. **Stop:** Press the top pusher button again to stop the chronograph. The elapsed time will be displayed on the sub-dials.
3. **Reset:** Press the bottom pusher button to reset the chronograph hands to zero.

4.3 Luminous Display

The watch hands and hour markers are treated with a luminous material. After exposure to light, they will glow in dark environments, allowing for easy time reading. The intensity and duration of the glow depend on the exposure time and intensity of light.

5. MAINTENANCE

5.1 Water Resistance

This watch is rated for 3ATM (30 meters) water resistance. This means it is suitable for daily use, such as hand washing, light rain, and accidental splashes. It is **not** suitable for showering, bathing, swimming, diving, or any water sports where it might be submerged for extended periods or subjected to high water pressure.

- Ensure the crown is fully pushed in before any contact with water.

- Do not operate the crown or pushers while the watch is wet or submerged.



Key features of the BINBOND watch: 30M waterproof, high hardness mirror, stainless steel band, and HD luminous function.

5.2 Cleaning

To maintain the appearance of your watch:

- Wipe the case and bracelet regularly with a soft, dry cloth.
- For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish.

5.3 Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields, which can affect the accuracy of the automatic movement.

6. TROUBLESHOOTING

- **Watch stops or runs inaccurately:** As an automatic watch, it requires sufficient wrist movement to stay wound. If the watch stops, wear it for several hours or gently shake it to restart the movement. If the issue persists, it may require professional inspection.
- **Condensation inside the crystal:** If you notice condensation under the watch crystal, this indicates a breach in water resistance. Immediately take the watch to a qualified watch repair professional to prevent further damage.
- **Bracelet difficult to adjust:** Ensure you are pushing the pins in the correct direction as indicated by the arrows on the links. If you encounter difficulty, seek assistance from a jeweler.

7. SPECIFICATIONS



Diagram illustrating the dimensions and specifications of the BINBOND watch.

Feature	Specification
Model Number	YXC-US-G3103-QJ
Movement Type	Automatic
Display Type	Analog
Case Material	Stainless Steel
Band Material	Stainless Steel
Crystal Material	Hardlex
Case Diameter	45 mm
Case Thickness	13 mm
Band Width	22 mm
Band Length	26 cm
Clasp Type	Double Locking Foldover Clasp
Water Resistance	30 Meters (3ATM)
Additional Features	Chronograph, Luminous Display, Moon Phase

8. WARRANTY AND SUPPORT

BINBOND offers a 2-year movement warranty for this watch. We also provide 30-day unconditional returns and exchanges for watches. For warranty claims, product support, or any inquiries, please contact the seller or refer to your purchase documentation.

9. IMPORTANT SAFETY INFORMATION

- Keep the watch away from strong magnetic fields, as they can affect the accuracy of the automatic movement.
- Avoid exposing the watch to extreme temperatures (hot or cold) for prolonged periods.
- Do not attempt to open the watch case yourself, as this may void the warranty and compromise water resistance.
- Keep the watch out of reach of small children to prevent accidental ingestion of small parts.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question